



ELITE SERIES SURGICAL TABLES
MAINTENANCE MANUAL



MODEL ELITE 6000N/6001N
AND ALL BATTERY MODELS

Table of Contents

SECTION I HYDRAULIC SYSTEM	1
1-1. General.....	1
1-2. Component Operation	3
a. Motor/Pump Operation	3
b. Pressure Relief Valve	3
c. Mini-Valves	4
d. Mini-valve in Neutral Position	4
e. Mini-Valve Right Port Activated	5
f. Mini-Valve Left Port Activated	5
g. Hydraulic Cylinders (Slave Cylinders)	6
h. Elevation Cylinder Return Circuit	7
i. Brake System	8
j. Emergency Brake Release	9
k. Flex/Reflex System	9
1-3. Hydraulic Adjustments	10
a. Fluid Level.	10
b. Bleeding The Hydraulic System	10
c. Pressure Relief Valve	10
d. Speed Controls.....	10
SECTION II MECHANICAL TABLE ADJUSTMENTS	12
2-1. Back Section Gear Mesh Adjustment	12
2-2. Hydraulic Cylinder Adjustment	12
a. Back Section	12
b. Leg Section	12
2-3. Split-Leg Section Horizontal Adjustments (Model 6000)	13
2-4. Adjustable Brake Feet	13
SECTION III HYDRAULIC TROUBLESHOOTING	14
3-1. Precautions	14
3-2. Troubleshooting Notes	14
3-3. ELEVATION DIAGNOSIS CHART	15
3-4. TRENDELENBURG DIAGNOSIS CHART	16
3-5. LATERAL - TILT DIAGNOSIS CHART	17
3-6. FLEX SYSTEM DIAGNOSIS CHART	18
3-7. BACK SECTION DIAGNOSIS CHART	19
3-8. LEG SECTION DIAGNOSIS CHART	20
3-9. BRAKE CIRCUIT DIAGNOSIS CHART	21
3-10. Flexible Hose Identification and Placement.....	22

Although current at time of publication, SKYTRON's policy of continuous development makes this manual subject to change without notice.

Table of Contents (continued)

SECTION IV ELECTRICAL SYSTEM	23
4-1. General.....	23
4-2. Components	23
4-3. Battery Model Components	23
SECTION V ELECTRICAL SYSTEM TROUBLESHOOTING	24
5-1. Troubleshooting Notes	24
5-2. Main Switch	24
5-3. Pendant Control	26
5-4. Relay Box.....	27
5-5. Solenoids.....	29
5-6. Motor/Pump Assembly	31
5-7. Return To Level Micro-Switches	32A
5-8. Troubleshooting	32A
SECTION VI -6001B- BATTERY MODEL, ELECTRICAL TROUBLESHOOTING.....	33
6-1. General.....	34
6-2. Troubleshooting Notes	34
6-3. Main Switch	35
6-4. Batteries	35
6-5. Battery Charging Box	36
6-6. Pendant Control	37
6-7. Auxiliary Switches	39
6-8. Relay Box.....	40
6-9. Main Wire Harness Continuity Tests.....	41
6-10. Solenoids.....	43
6-11. Motor/Pump Assembly	44
SECTION VII -6001NB- BATTERY MODEL, ELECTRICAL TROUBLESHOOTING	46
7-1. General.....	46
7-2. Troubleshooting Notes	46
7-3. Main Switch	48
7-4. Batteries	48
7-5. Battery Charging Box/AC120V Transformer	49
7-6. Switch-Over Relay	50
7-7. Pendant Control	51
7-8. Auxiliary Switches	53
7-9. Relay Box.....	54
7-10. Main Wire Harness Continuity Tests.....	56
7-11. Solenoids.....	57
7-12. Motor/Pump Assembly	58
SECTION VIII ELECTRICAL SYSTEM ADJUSTMENTS	60
8-1. Relay Box Adjustments Models 6001N & 6001NB	60
8-2. Relay Box Adjustments Model 6001B	61

SECTION I HYDRAULIC SYSTEM

1-1. General

NOTE

Electro-Hydraulic System

The hydraulic system (with the exception of the hydraulic cylinders and hoses) is contained within the base of the table. The hydraulic valves and pump are electrically controlled by the use of a hand-held push button pendant control. The power requirements for the table are 120 VAC, 5 amp, 60 Hz.

The table contains the following components. Refer to the block diagrams (figures 1-1 & 1-2) for relationship.

a. Oil Reservoir - Main oil supply. Approximately two quarts.

Continuing development of the Model 6000/6001 Table has resulted in several changes. However, the basic operation of the internal components remains the same. Figure 1-1 depicts the hydraulic system of the early models and figure 1-2 depicts the later "N" series models. **This manual covers the 6000N/6001N series (Serial Number 6001N-1992-1 & Later) and all battery model tables.**

b. Motor/Pump Assembly - A positive displacement gear type pump provides the necessary oil pressure and volume.




Figure 1-1. Hydraulic Block Diagram (Early Models)

c. Pressure Relief Valve - Provides an alternate oil path when the hydraulic cylinders reach the end of their stroke.

d. Electro/Hydraulic Mini-Valve Assemblies - These direct the fluid to the appropriate hydraulic cylinders.

e. Hydraulic Lines, Fittings, Connections - They provide a path for the hydraulic oil.

f. Hydraulic Cylinders - They convert the hydraulic fluid pressure and volume into mechanical motion.




Figure 1-2. Hydraulic Block Diagram Model 6001N

1-2. Component Operation

a. Motor/Pump Operation

The motor/pump assembly is a gear type pump that provides the oil pressure and volume for the entire hydraulic system. The pump has an inlet side and an outlet side. The inlet side is connected to the reservoir which provides the oil supply. The reservoir has a very fine mesh screen strainer which prevents foreign material from entering the oil system.

The output line of the pump is connected to the main oil galley which is internal and common to all the hydraulic mini-valves and pressure relief valve. Also, common to the hydraulic mini-valves and pressure relief valve is an oil galley that internally connects to the oil reservoir to provide a return path for the hydraulic oil. See figure 1-3.




Figure 1-3.

b. Pressure Relief Valve

This device provides an alternate oil path when the hydraulic cylinders reach the end of their stroke and the pump continues to run. If this path were not provided, the pump motor would stall because the oil cannot be compressed. The pressure relief valve is directly connected to the mini-valve bodies and shares both the common internal main pressure oil galley, and the return oil galley, that internally connect to the reservoir.

The main component of the valve is an adjustable spring loaded plunger that is pushed off from its

seat by the oil pressure. The oil then flows back into the reservoir. Turning the adjustment nut clockwise increases the amount of oil pressure required to open the valve, and turning it counterclockwise decreases the amount of oil pressure. (See adjustment section for specification.)




Figure 1-4. Pressure Relief Valve Not Functioning




Figure 1-5. Pressure Relief Valve Functioning

c. Mini-Valves

The operation of the mini-valves is identical for all table functions except the elevation and Single Action Brake circuits. These two hydraulic circuits use a 3-way (single check valve) type mini-valve. All other functions use a 4-way (dual check valve) type mini-valve.

Either type mini-valve is controlled by two pushing type, electrically operated solenoids. The solenoids push the spool valve (located in the lower portion of the valve) one way or the other. This motion opens the main supply galley (which has pump pressure) allowing the oil to flow through the various parts of the mini-valve to the function. The spool valve also opens an oil return circuit which allows the oil to return to the oil reservoir.

The main components of the mini-valve and their functions are listed below:

1. Spool Valve - Opens the main oil galley (pump pressure) to either mini-valve outlet depending on which direction the spool valve is pushed. Also it provides a return path for the oil returning back into the reservoir.

2. Pilot Plunger - There are two plungers in a four-way mini-valve (one in a 3-way mini-valve), one under each check valve. The purpose of the pilot plungers is to mechanically open the return check valve allowing the oil to return back into the reservoir.

3. Check Valve - Two are provided in each four-way mini-valve to seal the oil in the cylinders and oil lines and prevent any movement of the table. One check valve is provided in a 3-way mini-valve.

4. Speed Adjustments - There are two speed adjustments in each mini-valve. They are needle valve type controls which restrict the volume of oil returning back into the reservoir, thereby controlling the speed of the table surface movement. A 3-way mini-valve has only one speed adjustment.

The speed controls are always located in the return oil circuit. This prevents uncontrolled movement of the piston in the slave cylinder due to one side of the piston being loaded with hydraulic pressure and the other side having no load.

Also, by using this control method, it doesn't matter what size cylinder and piston is used because the speed can be controlled by restricting the return oil. If the pump puts out more volume to a certain slave cylinder than the speed control is allowing to go back to the reservoir, the pressure relief valve provides an alternate path for the pump oil.

d. Mini-Valve in Neutral Position

(No fluid flow) See figure 1-6.

1. Spool Valve Centered - This closes off both oil pressure and oil return galleys.

2. Pilot Plungers Both Closed - The pilot plungers control the opening of the check valves. If they are closed, the check valves must be closed.

3. Check Valves - Both check valves are closed trapping the oil in the cylinder and oil lines.

4. Speed Adjustment - When the mini-valve is in the neutral position, the speed adjustment does not affect anything because there is not any oil flow.




Figure 1-6. Mini-Valve in Neutral Position

e. Mini-Valve Right Port Activated

(See figure 1-7)

Slave Cylinder Piston Moves to Left
Right Mini-Valve Port is Supply Line
Left Mini-Valve Port is Return Line




Figure 1-7. Mini-Valve Right Port Activated

1. Spool Valve - Pushed to the left by electric solenoid. This opens the internal oil pressure gallery allowing the fluid to go through the check valve and on to the cylinder. Also, the spool valve opens the oil return line providing an oil path through the internal oil galley back to the reservoir.

2. Pilot Plunger Valve - Left pilot plunger valve is pushed up by the incoming oil pressure mechanically opening the check valve located above it in the return circuit. This action allows the oil from the left side of the slave cylinder to go back into the reservoir. The right pilot plunger valve is not affected in this operation mode.

3. Check Valves - Both check valves are opened in this operation mode. The right check valve is pushed open by the oil pressure created by the pump. The oil then continues to go through the lines and pushes the slave cylinder piston to the left. At the same time, the left check valve is held open mechanically by the pilot plunger providing a return path for the oil through the mini-valve back to the reservoir.

4. Speed Adjustment - The right speed control (output side) does not have any effect in this operation mode because the oil is routed around the speed adjustment through a by-pass valve and then to the output port. The left speed adjustment controls the speed of the table function by restricting the amount of oil going back into the reservoir.

f. Mini-Valve Left Port Activated

(See figure 1-8.)

Slave Cylinder Piston Moves to Right
Left Mini-Valve Port is Supply Line
Right Mini-Valve Port is Return Line




Figure 1-8. Mini-Valve Left Port Activated

1. Spool Valve - Pushed to the right by electric solenoid. This opens the internal oil pressure gallery allowing the fluid to go through the check valve and on to the cylinder. Also, the spool valve opens the oil return line providing an oil path through the internal oil galley back to the reservoir.

2. Pilot Plunger Valve - Right pilot plunger valve is pushed up by the incoming oil pressure mechanically opening the check valve located above it in the return circuit. This action allows the oil from the right side of the slave cylinder to go back into the reservoir. The left pilot plunger valve is not affected in this operation mode.

3. Check Valves - Both check valves are opened in this operation mode. The left valve is pushed open by the oil pressure created by the pump. The oil then continues to go through the lines and pushes the slave cylinder piston to the right. At the same time, the right check valve is held open mechanically by the pilot plunger providing a return path for the oil through the mini-valve back to the reservoir.

4. Speed Adjustment - The left speed control (output side) does not have any effect in this operation mode because the oil is routed around the speed adjustment through a by-pass valve and then to the output port. The right speed adjustment controls the speed of the table function by restricting the amount of oil going back to the reservoir.

g. Hydraulic Cylinders (Slave Cylinders)

There are several different types of hydraulic cylinders used in the table that activate the control functions. With the exception of the elevation and brake cylinders, all operate basically the same way. The control functions are listed below: (See figure 1-9.)

- Back Section--2, double action cylinders
- Leg Section--2, double action cylinders
- Trendelenburg--1, double action cylinder
- Lateral Tilt--1, double action cylinder
- Elevation--1, single action cylinder
- Brakes--4, single action cylinders




Figure 1-9. Cylinder Placement

1. Back Section and Leg Section Cylinders - The double action cylinders are closed at one end and have a movable piston with hydraulic fluid on both sides. Connected to this piston is a ram or shaft that exits out of the other end of the cylinder. Through the use of either a gear, or clevis and pin arrangement, this ram is connected to a movable table surface. The movable surface can be moved one way or the other by pumping hydraulic fluid into the cylinder on either side of the piston. Obviously, if oil is pumped into one side of the cylinder, a return path must be provided for the oil on the other side. See figure 1-10.




Figure 1-10. Back Section Cylinder

2. Trendelenburg Cylinder Assembly - This cylinder / piston arrangement has rack teeth cut into the top of each piston. These teeth mesh with a pinion gear that is connected directly to the table side frames. The pinion gear shaft and table side frames are supported by bearings at either side. When hydraulic fluid is pumped into one side of the cylinder, the pistons are pushed in one direction, moving the pinion gear and table side frames with them. Oil pressure can be applied to either side of the piston, making the table tilt end for end. See figure 1-11.




Figure 1-11. Trendelenburg Cylinder Assy.

In order to remove any looseness or play in the table top, the trendelenburg pistons are made in two pieces as shown in figure 1-12. This arrangement eliminates any gear lash between the piston teeth and the table pinion gear due to oil pressure always being present on both sides of the pistons.




Figure 1-12. Trendelenburg Cylinder Pistons

3. Lateral Tilt Assembly - The lateral tilt assembly consists of two cylinders, pistons and connecting rods. The connecting rods attach to the lateral tilt lever which connects to the table side frames. When hydraulic fluid is pumped into one cylinder, the piston and connecting rod pushes the lateral tilt lever which tilts the table top to one side. To tilt the table top in the opposite direction, fluid is pumped into the opposite cylinder. See figure 1-13.




Figure 1-13. Lateral Tilt Cylinder Assembly

4. Elevation Cylinder - This single action cylinder does not have hydraulic fluid on both sides of the piston. It depends on the weight of the table top assembly to lower it.

The cylinder is set in the center of the elevation main column. The cylinder is elevated by the driven force of the oil pressure. When lowering, the oil that is accumulated in the cylinder is returned to the oil reservoir through the mini-valve due to the table top weight.

A slider support assembly is used to support the weight of the upper table section. A stainless steel shroud covers the flexible hydraulic hoses and slider. See figure 1-14.




Figure 1-14. Elevation Cylinder Assembly

5. Brake Cylinders - The brake cylinders are single action type similar to the elevation cylinder. The movable piston's ram is connected to a brake pad. See figure 1-15. Oil pumped into the top of the cylinder pushes the piston down raising the table base off its casters. An internal return spring on the bottom of the piston, pushes the piston up to return the oil through the mini-valve to the reservoir.




Figure 1-15. Single Action Brake Cylinder

h. Elevation Cylinder Return Circuit

Three-way (single check valve type) mini-valves control both the elevation and return circuits. The elevation circuit operation within the mini-valve is identical to the operation of the four-way valves previously described (inlet pressure opens the check valve allowing the oil to enter the cylinder). In the return position, inlet pressure pushes the pilot plunger up and opens the return check valve. See figure 1-16. The open check valve allows a path for the oil in the elevation cylinder to return to the reservoir. When the pilot plunger valve is opened, the continuing pump pressure opens the pressure relief valve which provides a return oil path to the reservoir.

The mini-valve used in the elevation circuit contains only one check valve (all four-way mini-valves use two check valves). The check valve is used to trap the oil in the elevation cylinder thereby supporting the table top. When the top is being lowered the check valve is mechanically held open by the pilot plunger through pump pressure.




Figure 1-16. Elevation Return Circuit

i. Brake System

The brake system consists of the following components: (figure 1-17)

1. Single action slave cylinders (4 each).
2. 3-way (single check valve type) mini-valve.
3. Manually controlled emergency brake release.
4. Plumbing terminal, flexible hoses, copper lines and "O" rings.
5. Portions of the electrical system.




Figure 1-17. Brake System Block Diagram

Each corner of the cast-iron table base has a hydraulic brake cylinder. These single action cylinders are hydraulically connected in parallel to the mini-valve and all four are activated together. It is normal for one corner of the table to raise before the others due to the weight distribution of the table.

On early models the brakes are activated when the "elevation-up" button on the pendant control is pushed and held down. The brakes are completely set when the elevation function (table top) starts to move upward.

Later models use an electronic timer in the relay box so that when any function on the pendant control is pushed momentarily the pump/motor and brake system mini-valve is activated and the brake cylinders are completely set. The electronic timer runs for approx. 8-10 seconds.

The brakes are released by pushing the BRAKE UNLOCK button momentarily. An electronic timer in the relay box activates the brake function hydraulic mini-valve and pump/motor.

When activated, the return hydraulic circuit operates similar to the elevation cylinder return circuit. Return springs inside the single action brake cylinders retract the brake pads and provide the pressure to return the hydraulic oil back to the reservoir. The electronic timer operates the return circuit for approximately 8-10 seconds.

j. Emergency Brake Release

The emergency brake release is simply a manually operated bypass valve connected in parallel to the brake cylinders and the oil reservoir. See figure 1-18. When the valve is opened (turned counter-clockwise) a return circuit for the brake hydraulic fluid is opened. The return springs force the pistons up pushing the hydraulic oil back into the reservoir and retracting the brake pads.




Figure 1-18.

IMPORTANT

- The emergency brake release valve must be tightened securely when not in use.
- If the emergency brake release valve has been operated, the UNLOCK button on the pendant control may have to be pressed before brakes will lock again.

If the emergency brake release valve is open or loose, two conditions could occur:

1. The brakes will release slowly- depending on how loose the valve is, this could take anywhere from a few minutes to several hours.

2. None of the table functions will operate properly if the valve is wide open. All of the hydraulic fluid from the pump is simply pumped through the brake bypass circuit because that is the easiest path for the oil to follow.

k. Flex/Reflex System

The Flex/Reflex system on the early model tables consists of two hydraulic systems (trendelenburg and back section) operating simultaneously. When the system is activated by the pendant control, both the trendelenburg and back section mini-valves are activated and the hydraulic cylinders operate in parallel.

The Flex/Reflex system used on the present tables incorporates an additional mini-valve (7 total) which connects the trendelenburg and back section hydraulic systems in a series. When FLEX is activated by the pendant control, the Flex/Reflex mini-valve opens the oil pressure path to the Reverse Trendelenburg piston. The return oil path from the trendelenburg piston is routed through the back section cylinder to the mini-valve return port. See figure 1-19.




Figure 1-19. Flex/Reflex System

1-3. Hydraulic Adjustments

a. Fluid Level.

The fluid level should be approximately 1/2" below the filler hole or gasket surface. If additional fluid is needed, remove the filler vent cap with a phillips screwdriver and add fluid through this opening using a funnel. See figure 1-20.

NOTE

The elevation cylinder should be completely down and all the other control functions in their neutral position when checking oil level.




Figure 1-20.

The type of oil that should be used is Mobil DTE #25 or equivalent. This is a very high quality hydraulic oil. The table requires approximately two quarts of oil to operate properly.

b. Bleeding The Hydraulic System

To purge the air from the hydraulic system, operate each function back and forth at least two or three times.

NOTE

Whenever a hydraulic line or component is replaced, bleed the air out of the lines using the pump pressure before making the final connection. Then operate the function until it stalls in both directions.

c. Pressure Relief Valve

The pressure relief valve is adjusted by turning the adjustment nut until the desired pressure is reached.

To adjust:

1. Remove the blind cap and attach a hydraulic pressure gauge to the main oil galley using a 6mm plumbing bolt. See figure 1-21.




Figure 1-21.

2. Raise the table top until the piston reaches the end of its stroke and stalls. Observe reading on pressure gauge and turn the adjustment nut (clockwise to increase oil pressure, counterclockwise to decrease) until desired reading is obtained. Pressure should be 80KG/CM² -1138 PSI.

d. Speed Controls

The speed controls restrict the volume of oil returning back to the reservoir thereby controlling the speed of each control function.

All four-way mini-valves, have two speed controls located in the ends of each valve body. All three-way mini-valves have only one speed control.

One speed control adjusts one direction of a particular function and the opposite speed control adjusts the other direction. They are adjustable by using a small straight blade screwdriver and turning the adjustment screw clockwise to decrease the speed and counterclockwise to increase the speed. Refer to figure 1-22.




Figure 1-22.

Any control function should move in either direction at the same rate. If the rate of a certain function is too slow, open the speed control slightly and recheck. Use the second hand on a watch and time a particular function. Match that time in the opposite direction by opening or closing the speed control. Approximate operating times are as follows:

Lateral Tilt	7 seconds
Back Up	25 seconds
Back Down	15 seconds

A pressure gauge should be used to set the speed of the back section, trendelenburg and flex control functions.

To adjust:

1. Attach the pressure gauge onto the main oil galley as shown in figure 1-21.
2. The gauge should read the following values when operating the various control functions in either direction. Turn the speed controls until desired values are obtained.

Back Section	Up	65KG/CM†-925PSI
	Dn	65KG/CM†-925PSI
Trendelenburg	Up	65KG/CM†-925PSI
	Dn	65KG/CM†-925PSI
Flex		70KG/CM†-995PSI
Reflex		70KG/CM†-995PSI

NOTE

When adjusting Flex/Reflex speed controls, set Reflex last.

Elevation - There is not a speed adjustment for raising the table. The speed control will only affect the rate of descent and it should equal the rate of elevation.

SECTION II MECHANICAL TABLE ADJUSTMENTS

2-1. Back Section Gear Mesh Adjustment

The gear mesh is adjusted by the use of an eccentric cam. This cam moves the gear teeth closer together to eliminate gear lash. This adjustment arrangement compensates for any wear between the gears that might occur.

To adjust:

Loosen the cam locking nut and allen set screw. Use a spanner wrench to rotate the eccentric cam. Use firm pressure on the spanner wrench. See figure 2-1. Tighten the locking nut and set screw when adjustment is complete.




Figure 2-1. Eccentric Cam Adjustment

2-2. Hydraulic Cylinder Adjustment

Back & Foot / Leg Sections

The hydraulic cylinder rams that control both the back and foot / leg sections must move together so that these sections are not twisted when operated. This is accomplished by the use of eccentric cams that move the cylinder bodies fore and aft to adjust their effective stroke.

NOTE

Adjust gear mesh before adjusting eccentric cams for the back section.

a. Back Section

Position the back section all the way up until it stalls. Both sides of the back section should stop

moving at the same time and should not show any signs of twisting.

Any twisting or flexing of the back section as it approaches the stalled position indicates that one of the cylinders is not reaching its fully extended position at the same time as the other. This condition would require an adjustment.

To adjust:

Loosen the cam locking nuts located inside the table side frames. Use a spanner wrench to turn the cylinder eccentric cams as required to shift either cylinder fore or aft as needed so no twisting or flexing of the back section is observed when it is stalled in the full up position. See figure 2-2.




Figure 2-2. Back Section Adjustment

b. Leg Section (Model 6001)

Position the leg section all the way up. Both sides of the leg section should stop moving at the same time and should not show any signs of twisting.

Any twisting or flexing of the leg section as it approaches the stalled position indicates that one of the cylinders is not reaching its fully extended position at the same time as the other and an adjustment is required.

To adjust:

Loosen the cam locking nuts located inside the table side frames. Use a spanner wrench to turn the cylinder eccentric cams as required to shift either cylinder fore or aft as needed so no twisting or flexing of the leg section is observed when it is stalled in the above horizontal position. Tighten locking nuts when proper adjustment is achieved. See figure 2-3.




Figure 2-3. Leg Section Adjustment

2-3. Split-Leg Section Horizontal Adjustments (Model 6000)

Both leg sections should be level or even with each other when the table top is in the horizontal position. If they are not, an adjustment is necessary on the leg that is not level.

To adjust:

1. Loosen the three small allen head bolts that are visible from the outside of the table.
2. Loosen the allen head bolt located on the inside of the table frame.
3. Loosen the jam nut and turn the adjusting bolt located under the table side frame as required until the leg sections are even with each other and level with the table top. See figure 2-4.
4. Tighten the adjusting nut and all of the allen head bolts when the adjustment is complete.




Figure 2-4. Horizontal Adjustment

2-4. Adjustable Brake Feet

(S.N. 6000-1986-3-000 to 6000-1988-12-000)

To compensate for non level floors, some early tables were equipped with adjustable brake feet. The two adjustable brake feet are located as shown in figure 2-5. To adjust the feet, activate the brake system until the brakes are completely set. Insert a 7/32" pin punch into the access hole on the adjustable foot requiring adjustment and rotate the foot as needed. See figure 2-5.




Figure 2-5. Adjustable Brake Feet

SECTION III HYDRAULIC TROUBLESHOOTING

3-1. Precautions

Before attempting to troubleshoot any hydraulic problem on the table, please read through the precautions and notes below.

CAUTION

When disconnecting any of the hydraulic lines, fittings, joints, hoses, etc., for the following control functions, be sure these table surfaces are in their down position or completely supported.

- Elevation
- Back Section
- Leg Section

When working on the trendelenburg or lateral tilt hydraulic circuits, be sure to support the table top. When working on the brake system make sure the brakes are completely retracted.

CAUTION

Failure to follow these precautions may result in an uncontrolled oil spray and damage to the table or personal injury.

3-2. Troubleshooting Notes

When troubleshooting a table malfunction, first determine the following:

1. Does the problem affect all control functions?
2. Does the problem affect only one control function?
3. If the problem affects one control function is it in both directions?
4. Is the problem intermittent?
5. Is the problem no movement of a table surface or does the table surface lose position?

Once the problem has been determined, concentrate on that particular hydraulic circuit or control function.

Listed below are the hydraulic components that are common with all hydraulic circuits. If there is a problem with any of them, it could affect all control functions.

1. Motor/Pump Assembly
2. Reservoir
3. Pressure Relief Valve
4. Certain Oil Lines and Galleys

If there was a problem in the following components, only one control function would normally be affected.

1. Mini-Valve
2. Slave Cylinder
3. Oil Lines

NOTE

Whenever a hydraulic line or component is replaced, bleed the air out of the lines using the pump pressure before making the final connection. After all connections are tight, cycle the control function back and forth two or three times to purge the remaining air from the system.

IMPORTANT

When installing new "O" rings use hydraulic oil to thoroughly lubricate the "O" rings and cylinder. Keep everything clean.

Each complete oil circuit is shown on the following pages. When troubleshooting a particular function, refer to the appropriate oil circuit diagram and the list of possible problems

3-3. ELEVATION DIAGNOSIS CHART

Problem	Reason
Table will not elevate properly	Pressure Relief Valve Not Set Properly Low on Oil Spool Valve Not Centered Defective Pump Defective Mini-Valve Defective Solenoid or Wiring Defective Relay Box or Pendant Control
Table will not descend properly	Incorrect Speed Adjustment Bad Check Valve Spool Valve Not Centered Galled Slider Assembly Defective Solenoid or Wiring Defective Relay Box or Pendant Control
Table loses elevation	Bad Check Valve Leaking Mini-Valve Loose Fittings, Joints, Hoses Leaking "O" Ring Inside Cylinder




Figure 3-1. Elevation Circuit

3-4. TRENDELENBURG DIAGNOSIS CHART

Problem	Reason
Trendelenburg function moves improperly	Incorrect Speed Adjustment Spool Valve Not Centered Bad Check Valves Low on Oil Pinched Hose Defective Mini-Valve Pressure Relief Valve Not Set Properly Bad Solenoid or Wiring Defective Relay Box or Pendant Control
Trendelenburg function chatters or loses position	Defective or Dirty Check Valve Oil Leakage in Circuit Air Inside Cylinder Pinched Hose Low on Oil




Figure 3-2. Trendelenburg Circuit

3-5. LATERAL TILT DIAGNOSIS CHART

<p>Problem</p> <p>Lateral tilt function moves improperly</p>	<p>Reason</p> <p>Incorrect Speed Adjustment</p> <p>Spool Valve Not Centered</p> <p>Bad Check Valves</p> <p>Low on Oil</p> <p>Pinched Hose</p> <p>Defective Mini-Valve</p> <p>Pressure Relief Valve Not Set Properly</p> <p>Bad Solenoid</p> <p>Defective Relay Box or Pendant Control</p>
<p>Lateral tilt function chatters or loses position</p>	<p>Defective or Dirty Check Valves</p> <p>Oil Leakage in Circuit</p> <p>Air Inside Cylinder</p> <p>Pinched Hose</p> <p>Low on Oil</p>




Figure 3-3. Lateral Tilt Circuit

3-6. FLEX SYSTEM DIAGNOSIS CHART

Problem
Back Section or Trendelenburg function moves improperly

Reason
Incorrect Speed Adjustment (Trendelenburg, Back section or Flex - check with gauge)
Spool Valve Not Centered
Bad Check Valves
Low on Oil
Pinched Hose
Defective Mini-Valve
Pressure Relief Valve Not Set Properly
Bad Solenoid
Defective Relay Box or Pendant Control

IMPORTANT

If Flex System does not function properly, check the back section and trendelenburg functions before adjusting the flex system.

Problem
Back Section or Trendelenburg function chatters or loses position

Reason
Defective or Dirty Check Valves
Oil Leakage in Circuit
Air Inside Cylinder
Pinched Hose
Low on Oil




Figure 3-4. Flex System Circuit

3-7. BACK SECTION DIAGNOSIS CHART

Problem	Reason
Back Section function moves improperly	Incorrect Speed Adjustment Spool Valve Not Centered Bad Check Valves Low on Oil Pinched Hose Defective Mini-Valve Pressure Relief Valve Not Set Properly Bad Solenoid Defective Relay Box or Pendant Control
Back Section function chatters or loses position	Defective or Dirty Check Valves Oil Leakage in Circuit Air Inside Cylinder Pinched Hose Low on Oil




Figure 3-5. Back Section Circuit

3-8. LEG SECTION DIAGNOSIS CHART

Problem	Reason
Leg function moves improperly	Incorrect Speed Adjustment Spool Valve Not Centered Bad Check Valves Low on Oil Pinched Hose Defective Mini-Valve Pressure Relief Valve Not Set Properly Bad Solenoid Defective Relay Box or Pendant Control
Leg function chatters or loses position	Defective or Dirty Check Valves Oil Leakage in Circuit Air Inside Cylinder Pinched Hose Low on Oil




Figure 3-6. Leg Section Circuit

3-9. BRAKE CIRCUIT DIAGNOSIS CHART

Problem
Brakes will not set properly

NOTE

If brakes have been released with the Emergency Brake Release Valve, brakes will not reset until BRAKE UNLOCK Circuit has been activated.

Reason
Emergency Brake Release Valve Open or Defective
Spool Valve Not Centered
Bad Check Valve
Low on Oil
Pressure Relief Valve Not Set Properly
Pinched Hose
Defective Mini-Valve
Defective Relay Box or Pendant Control

Brakes Will Not Stay Locked

Emergency Brake Release Valve Open or Defective
Defective or Dirty Check Valve
Oil Leakage in Circuit
Leaking "O" Ring Inside Cylinder

Brakes will not retract properly

Incorrect Speed Adjustment
Bad Check Valve
Spool Valve Not Centered
Defective Mini-Valve
Pinched Hose
Defective Solenoid or Wiring
Defective Relay Box or Pendant Control




Figure 3-7. Brake System Circuit

3-10. Flexible Hose Identification and Placement

The following figures will show the correct placement of the flexible hydraulic hoses used in the table and their respective number codes.

Figure 3-8 shows the hose connections to the plumbing terminal.




Figure 3-8. Main Plumbing Terminal

Figure 3-9 shows the placement of the short flexible hoses which connect to the back section cylinders.




Figure 3-9. Back Section Hoses

Figure 3-10 shows the placement of the short flexible hoses which connect to the leg section cylinders.




Figure 3-10. Leg Section Hoses

Figure 3-11 shows the placement and number code for the long flexible hoses which connect from the plumbing terminal to the front and rear pivot blocks.

NOTE

The number codes will be stamped into the elevation clamp ring and the plumbing terminal.




Figure 3-11. Pivot Block Hoses

Figure 3-12 shows the placement and number code for the long flexible hoses that connect from the elevation clamp ring to the plumbing terminal.




Figure 3-12. Elevation Clamp Ring Hoses

SECTION IV ELECTRICAL SYSTEM

4-1. General

The complete electrical system (with the exception of the hand-held pendant control and the return circuit micro-switches) is contained within the base of the table. The pump motor and the hydraulic valves are controlled electrically with the pendant control.

The electrically operated functions are as follows:

- ELEVATION - Up and Down
- TRENDELENBURG - Head up and down
- LATERAL TILT - Right and left
- BACK SECTION - Up and Down
- LEG SECTION - Up and Down
- FLEX / REFLEX
- RETURN TO LEVEL
- BRAKE UNLOCK - Brake release

The power requirements are 120 VAC, 60 Hz, fuse protected. The main power on-off switch is an enclosed DPST type and the power cord is a three-wire, fifteen foot long, UL listed cord with a three-prong hospital grade plug.

4-2. Components

Refer to figure 4-1 for the relationship of the electrical components.

a. Wires, Connectors, Switches, Fuse - These provide the path for the various electrical circuits.

b. Relay Box - Contains the step down transformer, full wave rectifier, and relay switches. The relay switches are activated by the pendant control and in turn energize the solenoid.

c. Hand-Held Pendant Control - Closes micro-switches to activate relay box. Operates on 5 VDC.

d. Solenoids - These electrically open and close the hydraulic ports of the mini-valve to direct the fluid to the correct cylinders. They operate on 120 VAC.

e. Motor/Pump Assembly - 120 VAC, 60 HZ, 200 Watt capacitor induction motor.

4-3. Battery Model Components

The functions of the battery model tables are the same as the standard 120 VAC models. The electrical components and operation however, vary greatly between the two models. To simplify the troubleshooting procedures, the battery model tables are covered separately in Section VI for the model 6001B and Section VII for the model 6001NB.

SECTION V ELECTRICAL SYSTEM TROUBLESHOOTING

5-1. Troubleshooting Notes

The basic operation of each component will be defined along with a drawing and explanation on how to check it out.

NOTE

This section does not cover the battery table components. They are covered separately in Section 6 and 7.

Certain defective components could cause the entire table to stop functioning or only one control function to stop. It would depend on what part of the component failed. Other defective components would only cause one control function to stop.

The following defective components could cause all control functions to be affected:

- a. Motor/Pump Assembly (starting capacitor)
- b. Main Switch Circuit and Wiring

The following defective components could cause all control functions to be affected or only one control function:

- a. Relay Box
- b. Pendant Control

The component listed below would only affect one control function:

Solenoid

When troubleshooting an electrical circuit, start at the problem and work back to the power source.

5-2. Main Switch

The main power supply, 120 VAC, 60 HZ, comes in through the power cord and through the main switch. The main switch opens both lines when in the "OFF" position. An 8 amp or two 10 amp fuses are used to protect the complete electrical system and are located next to the main switch.

a. Main Switch Test

The following test will determine if line voltage is applied to connector CN4, which in turn would power the table.

1. Plug the power cord into the 120VAC power supply (wall receptacle) and turn ON the main switch.

2. Disconnect connector CN4 from the relay box. See figure 5-1. Leave all other connectors connected.




Figure 5-1. Main Power Test

CAUTION

Line voltage (120 VAC) will be measured in this test. Do not touch uninsulated connector pins or meter test leads.

3. Use an AC voltmeter capable of measuring 120 VAC and measure the voltage between pins 1 and 2 (black and white wires) located in connector CN4. See figure 5-2. You should receive line voltage 120 VAC.




Figure 5-2. Connector CN4




Figure 4-1. 6001N Electrical Circuit Block Diagram

b. Test Results

If you do not receive the correct voltage measurement, the problem would have to be in the wires, main switch, fuses, or power cord. If the correct voltage is obtained, everything is good up to this point and the problem would have to be in another area.

5-3. Pendant Control

The Pendant Control consists of 13 or 14 micro-switches (buttons). When any of the circuits are completed (by depressing a control button) the appropriate relay contacts (located in the relay box) close applying 120V potential to the appropriate solenoid to operate the mini-valve and the pump/motor. The Pendant Control has only 5-6 volts applied to it.

a. Pendant Control Test

The following test will determine if the micro-switches inside the Pendant Control are functioning correctly.

1. Unplug the pendant control from the base of the table. You will be checking the cord side connector.

2. Use an ohmmeter R x 1 scale and check the continuity between pin 1 and pins 4 through 19. See figure 5-3.

3. Ohmmeter must show continuity between the pins that are indicated when the appropriate buttons are pressed.

NOTE

Pins 2 and 3 are connected to the LED (power on light on the pendant control) and cannot be checked with an ohmmeter. Pin 19 is used on -KR models only. Pins 17 & 18 are not used.




Figure 5-3. Pendant Control Test

b. Test Results:

If you do not receive continuity between any of the pins, either the micro-switch in the Pendant Control is defective or a wire is broken. Either of these problems can be repaired easily.

If you receive correct readings with the meter, the Pendant Control is okay.

c. Wiring Harness Test

The following test checks the wires leading from the relay box connector CN8 to the 19 pin connector table socket. These wires apply low voltage to the pendant control buttons.

1. The power cord should be plugged into the wall socket and the main switch turned ON.
2. Disconnect the pendant control from the base connector. All other connectors should be connected.
3. Use a DC voltmeter 10V scale and measure the following pins located in the 19 pin table base connector. See figure 5-4.

NOTE

Pin 19 will have no voltage potential unless one of the return-to-level micro-switches are activated, i.e. trend or tilt (KR models). Pins 17 & 18 are not used.




Figure 5-4. Table Base Connector

d. Test Results:

If you do not receive the correct voltage reading, the wiring or connector pins may be faulty. Disconnect connector CN8 from the relay box and using

an ohmmeter, test the continuity between the corresponding pins in connectors CN8 and the table base connector. See figure 5-5. If the correct readings are obtained, this part of the circuit is okay.




Figure 5-5. Base Connector Continuity Test

5-4. Relay Box

The 120 volt power supply is directly connected to the relay contacts. When these contacts are closed, 120 volts is supplied to the solenoids which are mounted on the hydraulic mini-valves. One relay is used to supply 120V to the pump/motor and is always activated no matter what control function is selected. The brake locking circuit relay is also activated when any control function other than BRAKE UNLOCK is *initially* selected.

Also, inside the relay box is a step-down transformer and full-wave rectifier which decreases the line voltage to 5.5 volts. This low voltage potential controls the relays by the use of the hand-held pendant control buttons. Basically the relays enable a 5.5 volt potential to control the 120 volt circuit.

The following tests will determine if the relay box is functioning correctly.

a. Relay Box Input Connector CN4

1. Plug the power cord into the 120 VAC power supply (wall receptacle) and turn the main switch ON. Leave all connectors connected.

CAUTION

Line voltage (120 VAC) will be measured in this test. Do not touch uninsulated connector pins or meter test leads.

2. Use an AC voltmeter capable of measuring 120 volts and measure the voltage between pins 1 (white) and 2 (black) of connector CN4 for input voltage. See figure 5-6. Meter should read line voltage 120 VAC.

3. Activate any table function with the Pendant Control and using an AC voltmeter, test the voltage at pins 3 and 4 of CN4 for output to the pump. Meter should read 120 VAC.




Figure 5-6. Connector CN4

b. Test Results:

If you do not receive the correct meter readings, the relay box or wiring is defective. If the correct readings are obtained, this part of the relay box is okay. Proceed to the next step.

c. Relay Box Output Connector CN8

This test checks the low voltage applied to the pendant control buttons.

1. The power cord should be plugged into the wall receptacle and main switch turned ON.

2. Disconnect Pendant Control connector. All other connectors should be connected.

3. Using a DC voltmeter, measure the voltage between pin 1(+) and pins 4 through 19(-) of the table base connector. See figure 5-4. Meter should read 5-6 volts.

d. Test Results:

If you do not receive the correct meter readings, the relay box or wiring is defective. If the correct readings are obtained, this part of the relay box is okay. Proceed to the next step.

e. Relay Box Output Connectors CN6 & CN7

This test checks the high voltage (120V) that is used to energize the solenoids.

CAUTION

120 VAC will be measured in this test. Do not touch uninsulated connector pins or meter test leads.

1. The power cord should be plugged into the wall receptacle and main switch turned ON.

2. Disconnect the motor connector CN15. All other connectors should be connected. Test connectors CN6 and CN7 from the back while attached to the relay box.

3. Activate each of the Pendant Control buttons and using an AC voltmeter capable of measuring 120VAC, measure the voltage between the appropriate connector pins located in connector CN6 or CN7. See figure 5-7. Polarity of meter test leads is not important. Meter should read 120VAC.




Figure 5-7. Relay Box Output Connectors CN6 and CN7

f. Test Results:

If you do not receive the correct meter readings, the relay box or wiring is defective and should be replaced.

NOTE

Before deciding the relay box is defective, check the wires and pins in the connector blocks to make sure they are not loose or making a bad connection with their mate.

5-5. Solenoids

The solenoids are energized by 120 volt potential that is controlled by the relays located inside the relay box.

The solenoid windings are protected from excessive heat with an internal thermal fuse that will open after approximately seven (7) minutes of continuous operation. The solenoid must be replaced if the internal thermal fuse has been blown. The solenoids are mounted directly on either side of the hydraulic mini-valves and push the spool valve in one direction or the other depending upon which solenoid is activated.

a. Solenoid Test

The following tests check the voltage applied to the solenoids and the resistance of the solenoid coil.

NOTE

If a solenoid does not function when the pendant control button is pushed, the problem could be the pendant control, the relay box, or the solenoid.

NOTE

Each solenoid is controlled with 120V source coming from the relay box. This source can easily be checked by measuring the voltage at the 2 pin connector in question.

CAUTION

Line voltage will be measured in this test. Do not touch uninsulated connector pins or meter test leads.

b. Step #1

1. Plug the table cord into the wall receptacle and turn main switch ON.

2. Disconnect the 2 pin connector from the solenoid in question. See figure 5-8.

3. Use a voltmeter capable of measuring 120 VAC and measure the voltage across the 2 pin connector. Polarity of meter leads is not important.

NOTE

The appropriate pendant control button must be pushed during this test. The motor will run when this test is performed, and the brake locking solenoid will be activated by any function other than UNLOCK.

c. Test Results:

If you do not receive the correct voltage, the problem could be in the wires leading to connectors CN6 and CN7. The problem could also be in the relay box or the Pendant Control (refer to appropriate section for troubleshooting).

If the correct voltage is obtained, everything is good up to that point and the problem is more than likely the solenoid.

d. Step #2

The solenoid can be checked out using an ohmmeter R x 1 scale.

1. Measure the resistance between the two pins of the connector in question. See figure 5-8. Connector being tested must be disconnected. Polarity of meter leads is not important.

2. The meter should read approximately 80-90 ohms at room temperature.

5-6. Motor/Pump Assembly

The electric motor is a capacitor start type with a rating of 120 VAC, 200 watts. The field windings are protected with a thermal protector that will open the winding circuit if the motor is run continuously for approximately 10 minutes. This protector will take about 10 minutes to automatically reset. The oil pump unit is attached to the bottom of the motor and is a gear type displacement pump with a pumping capacity of .4 liter per min. The Motor/Pump Assembly is mounted on an insulated motor plate in the base of the table. The starting capacitor is mounted along side the motor/pump assembly

a. Motor/Pump Test

The following tests will check the voltage applied to the motor and the resistance of the motor field windings.

CAUTION

Line voltage will be measured in this test. Do not touch uninsulated connector pins or meter test leads.

b. Step #1

1. Plug the power cord into 120 VAC power supply (wall receptacle). Turn main switch ON.

2. Disconnect the 3 pin connector CN15 at the motor. Leave all other connectors connected. See figure 5-9.




Figure 5-9.

3. Use a voltmeter capable of measuring 120 VAC and measure the following connector pins in connector CN15. See figure 5-10.




Figure 5-10. Connector CN15

c. Test Results:

If you do not receive the correct meter readings, the problem could be in the wires, connectors, relay box, or main switch (refer to appropriate section for troubleshooting).

If the correct voltage is obtained, everything is good up to that point and the problem could be either the motor or the starting capacitor.

d. Step #2

If the starting capacitor is shorted or grounded, the motor will not run. Capacitors very seldom fail, and it requires a dielectric tester to accurately test one. However, an ohmmeter can be used to determine if the capacitor will store a low voltage charge and most of the time this is adequate.

1. Turn the main switch OFF.

2. Connector CN15 should be disconnected.


3. Use the R x 100 scale of the ohmmeter and touch pins 2 and 3 of connector CN15. See figure 5-10.

e. Test Results:

The meter needle should move up scale and then back down to infinity. This would indicate that the capacitor is storing an electrical charge.

NOTE

The capacitor may have to be discharged first (by shorting pins 2 and 3 together) before you will be able to see the ohmmeter needle swing up the scale.



PIN NO	METER
1 - 2	Approx. 5 ohms
1 - 3	Approx. 4 ohms
2 - 3	Approx. 8 ohms

Figure 5-11. Pump Connector CN15

f. Step #3

The motor windings can be statically checked for resistance using an ohmmeter.

1. Turn main power switch OFF.
2. Connector CN15 should be disconnected.
3. Use the R x 1 scale of the ohmmeter and measure the resistance between the pins located in the pump connector CN15. See figure 5-11.

g. Test Results:

If you do not receive the correct meter readings, the motor or wiring is defective.

5-7. Return-to-Level Micro-Switches.

The return-to-level feature is activated by a single button on the pendant control and automatically levels the major table functions, lateral tilt, trendelenburg, back section, and leg section.

The return-to-level system consists of 6 micro-switches, 2 electrical connectors, and the related wiring. The micro-switches are mounted on or adjacent to the function they control and are wired for normally open or normally closed operation. The micro-switches are lever actuated and can be adjusted at the individual switch mounting brackets. See figure 5-12.

The micro-switches operate on low voltage, and control the function circuits (pump/motor and ap-

propriate solenoid valves) when activated by the pendant control RETURN button.

The micro-switches are wired to the relay box through a riser cord and to the 15 pin connector CN2. See figure 5-12 for switch location and identification.

5-8. Troubleshooting

If a problem is suspected in the return circuits, disconnect the connector CN2 from the Relay Box to eliminate the circuits. Ensure that all table functions operate properly using the Pendant Control. If the functions do not work properly using the Pendant Control, refer to the appropriate test section and make all needed repairs before working on the return circuits.




Figure 5-12.

NOTE

It is normal for the back section to move up if the RETURN button is pushed when connector CN2 is disconnected from the relay box.

operation at the appropriate pin numbers for the micro-switch in question as shown in figures 5-14 through 5-18.

NOTE

Be sure to isolate the circuit when making continuity checks.

All of the micro-switches are connected to the relay box via a wiring harness and the micro-switch riser cord using connectors CN2 and CN10. Connector CN10 is located under the slider shroud in the same area as the hydraulic hoses. Connector CN2 plugs into the relay box and is the most convenient location to make circuit continuity checks. See figure 5-13 for connector pin locations.

NOTE

If you do not receive the proper continuity results at connector CN2 it does not necessarily mean the micro-switch is defective. There could be a problem with the riser cord between connectors CN2 and CN10, or in the wiring from the switch to connector CN10. Further tests will have to be made to determine the exact problem.

a. Switch Test

Turn Main Power ON, lock the table brakes, and place the table top sections in a level position. Disconnect connector CN2 from the relay box and using an ohmmeter, test the wiring and switch





Figure 5-13. Return Micro-Switch Test



NS-1. Trendelenburg

Test at pins 1 & 9

Table Position	Switch Position	Meter Reading
Level	Open	Infinity
Head Up	Open	Infinity
Head Dn	Closed	0

When table is in Trendelenburg Position, NS-1 brings the top back to level.


NS-2. Reverse Trendelenburg

Test at pins 2 & 9

Table Position	Switch Position	Meter Reading
Level	Open	Infinity
Head Up	Closed	0
Head Dn	Open	Infinity

When table is in Reverse Trendelenburg Position, NS-2 brings the top back to level.

Figure 5-14. Trendelenburg Return Switches



NS-3. Lateral Tilt-Left

Test at pins 3 & 9

Table Position	Switch Position	Meter Reading
Level	Open	Infinity
Tilt-Right	Open	Infinity
Tilt -Left	Closed	0

When table is in Tilt-Left Position, NS-3 brings the top back to level.


NS-4. Lateral Tilt-Right

Test at pins 4 & 9

Table Position	Switch Position	Meter Reading
Level	Open	Infinity
Tilt-Right	Closed	0
Tilt-Left	Open	Infinity

When table is in Tilt-Right Position, NS-4 brings the top back to level.

Figure 5-15. Lateral Tilt Return Switches



NS-5. Back Section Down
Test at pins 5 & 14

Table Position	Switch Position	Meter Reading
Level	Closed	0
Back-Dn	Open	Infinity
Back-Up	Closed	0

When the Back Section is Down, NS-5 brings the Back Section Up to level.

NS-6. Back Section Up
Test at pins 6 & 14

Table Position	Switch Position	Meter Reading
Level	Open	Infinity
Back-Dn	Open	Infinity
Back-Up	Closed	0

When the Back Section is Up, NS-6 brings the Back Section Down to level.

Figure 5-16. Back Section Return Switches

b. Switch Adjustment.

If proper readings are not obtained during test or if table does not properly return to level, use the following procedure to adjust the switches.

1. Apply table brakes and (using a level) level the table top using the TRENDELENBURG and LATERAL-TILT function buttons on the pendant control.

2. Carefully loosen the switch retaining screws, and adjust the switches as needed. See figure 5-17.




Figure 5-17. Micro-Switch Adjustment.

SECTION VI -6001B- BATTERY MODEL, ELECTRICAL TROUBLESHOOTING




Figure 6-1. Electrical Circuit Block Diagram, Model 6001B

6-1. General

The battery table components operate on 24VDC. The internal charging system also incorporates the components to transform the 120VAC input to 24VDC output to the components.

The Model designation **6001B** is for all battery tables with a Serial Number of 6001B-1992-2 & Prior. The designation **6001NB** is for all battery models with the Serial Number of 6001NB-1992-3 & Later.

The two models can be easily identified by the position of the Main Power switch. The power switch is on the top of the base on the 6001B models. See figure 6-2.

NOTE

This section covers the electrical troubleshooting for the 6001B model ONLY.

Electrical Troubleshooting for the 6001NB is covered in section 7.

6-2. Troubleshooting Notes

The basic operation of each component will be defined along with a drawing and explanation on how to check it out.

Certain defective components could cause the entire table to stop functioning or only one control function to stop. It would depend on what part of the component failed. Other defective components would only cause one control function to stop.

The following defective components could cause all control functions to be affected:

- a. Motor/Pump Assembly
- b. Main Switch Circuit and Wiring

The following defective components could cause all control functions to be affected or only one control function:

- a. Relay Box
- b. Pendant Control

The component listed below would only affect one control function:

Solenoid

When troubleshooting an electrical circuit, start at the problem and work back to the power source.

NOTE

On the battery model tables, troubleshooting should begin by switching the operating mode. For example; if a function fails when attempting to operate the table in the AC120V mode, switch to the BATTERY mode. If the function now operates, the problem is probably located between the power cord and the relay box. If the function also fails when in battery operation, use the auxiliary switches to operate the function. If the function now operates, the problem is probably in the pendant control, connectors or wiring from the pendant control to the relay box.




Figure 6-2. Model Identification

6-3. Main Switch

The main power supply, 120VAC, 60 HZ, comes in through the power cord and through the main switch. The main switch opens both lines when in the "OFF" position. An 8 amp fuse is used to protect the complete electrical system and is located next to the main switch. See figure 6-2.

a. Main Switch Test

The following test will determine if line voltage is applied to connector CN12, which in turn would supply 120VAC power to the table.

1. Plug the power cord into the 120VAC supply (wall receptacle) and turn the main switch ON.
2. Disconnect connector CN12. See figure 6-1. Leave all other connectors connected.

CAUTION

Line voltage (120 VAC) will be measured in this test. Do not touch uninsulated connector pins or meter test leads.

3. Use an AC voltmeter capable of measuring 120 VAC and measure the voltage between pins 1 and 2 (black and white wires) located in connector CN12. See figure 6-3. You should receive line voltage 120 VAC.

Connector CN12 Color Code

Pin 1 Black	Pin 4 Black
Pin 2 White	Pin 5 Red
Pin 3 Yellow	Pin 6 Blue




Figure 6-3. Connector CN12 Test

b. Test Results

If the correct voltage is obtained, everything is good up to this point and the problem would have to be in another area.

If you do not receive the correct measurements, the problem would have to be in the wires, main switch, fuses, or power cord.

Check the continuity from the power cord connector CN13, through the fuses, switch and wiring to connector CN12. Remove the power cord, disconnect CN12, turn the Main Power Switch ON, and test as shown in figure 6-4.




Figure 6-4. CN12 to CN13 Continuity Test

6-4. Batteries

The BATTERY operating mode is powered by two 12 volt batteries connected in series to provide the 24 volt operating power.

The battery system voltage should be 24VDC with a range of 22VDC to 26VDC. If the battery charge level falls below 23.5 volts the BATTERY operation indicator on the pendant control will blink indicating that the batteries require recharging. The built-in charging system automatically keeps the batteries at the proper charge level when the AC120V operating mode is ON. The charging system will operate while the table is being operated in the AC120V mode.

a. Battery System Test

1. Disconnect the main power cord and using a DC voltmeter, test the voltage of each individual battery at its terminals. Meter should read 12VDC \pm 1V.

2. To accurately test the batteries, they must be tested under a full load. Disconnect the main power cord and make sure all other connectors are connected.

3. Turn BATTERY power ON and elevate the table to its full up position.

4. Continue to press the TABLE UP button on the pendant control so that the pump motor continues to run and using a DC voltmeter, check the voltage drop of each battery individually. See figure 6-5.

5. Meter should read $12\text{VDC} \pm 1\text{VDC}$.




Figure 6-5.

b. Test Results

A reading of 11 volts or below indicates the battery needs charging.

After batteries have been fully charged, repeat the full load test. If either battery's voltage drops below 11VDC it should be replaced.

6-5. Battery Charging Box

The Battery Charging Box contains the battery charging system as well as the transformer and components for the AC120V operation.

a. Battery Charging Box Test

1. Confirm 120VAC input at CN12 using Main Switch test in 6-3a.

2. With AC120V power ON, use a DC voltmeter to test pin 3(+) and pin 4(-) of CN12. DO NOT disconnect connector CN12. See figure 6-6

3. Meter should read $26.5 \pm 1\text{VDC}$.




Figure 6-6. Connector CN12 Test

4. Test pin 5(+) and pin 6(-) of CN12 with DC voltmeter to test operation of CHARGING indicator light (next to power cord connector).

5. Meter should read approximately 26.5 VDC if charger is operating. If batteries are fully charged there will be under 5 volts at pins 5 and 6.

b. Test Results

If you do not receive the correct readings, the charger or the transformer may be defective.

c. Charging System Output Adjustment

If output reading at pins 3 and 4 is not $26.5 \pm 1\text{VDC}$, the output can be adjusted at the variable resistor VR-R59 on the circuit board inside the Charging Box. See figure 6-7. Turn the adjuster clockwise to decrease the voltage. Counterclockwise to increase the voltage.

NOTE

The battery connector CN16 must be disconnected to adjust the battery charger output.




Figure 6-7

6-6. Pendant Control

The Pendant Control consists of 14 micro-switches (buttons). When any of the circuits are completed (by depressing a function button) the appropriate relay contacts (located in the relay box) close and a 24V potential is applied to the solenoid to operate the hydraulic mini-valve. The 6001B Pendant Control has 24 volts applied to it.

2. Use an ohmmeter R x 1 and check the continuity between pin 1 and 4 through 16 while pressing the appropriate button. Also test between pins 18 and 19. See figure 6-8.

3. Ohmmeter must show continuity between the pins that are indicated when the appropriate buttons are pressed.

a. Pendant Control Test

The following test will determine if the micro-switches inside the Pendant Control are functioning correctly.

1. Unplug the 19 pin Pendant Control connector from the base of the table. You will be checking the cord side connector.

NOTE

Pins 2 and 3 are connected to the LEDs (AC120V and BATTERY indicator lights on the pendant control) and cannot be checked with an ohmmeter.




Figure 6-8. Pendant Control Test

b. Test Results:

If you do not receive continuity between any of the pins, either the micro-switch in the Pendant Control is defective or a wire is broken. Either of these problems can be repaired easily.

If you receive correct readings with the meter, there is nothing wrong with the Pendant Control.

c. LED Test

The BATTERY and AC120V power ON indicators can be checked with an LED tester. Test BATTERY indicator at pin 1(+) and pin 2(-) of 19 pin Pendant Control connector. Test AC120V indicator at pin 1(+) and pin 3(-). See figure 6-6.

If no LED tester is available the LEDs can be tested by applying voltage to the appropriate pins. To avoid damage to the LED a 1.5K ohm resistor must be placed between the power source and the connector pins. See figure 6-9.





Figure 6-9. LED Test

d. Wiring Harness Test

The following test checks the wires leading from the relay box connector to the 19 pin connector table socket. These wires apply voltage to the pendant control buttons.

1. Activate the AC120V operating mode.
2. Disconnect the pendant control from the table base connector. All other connectors should be connected.
3. Use a DC voltmeter and measure the following pins located in the 19 pin table base connector. See figure 6-10.




+ TEST LEAD	- TEST LEAD	DC VOLTS
1	4 - 16	24
18	19	24

Figure 6-10. Table Connector

e. Test Results:

If you do not receive the correct voltage reading, the wiring or connector pins may be faulty. Disconnect connector CN1 from the Relay Box and using an ohmmeter, test the continuity between the corresponding pins in connectors CN1 and CN14. See figure 6-11. If the correct readings are obtained, this part of the circuit is okay and the problem may be in the relay box.



CN - 14 PIN NO	CN - 1 WIRE COLOR	CN - 14 PIN NO	CN - 1 WIRE COLOR
1	Red/White	12	Grey
2	White	13	White/Grey
3	Black	14	White/Yellow
4	Red	15	Purple/White
5	White/Red	16	Black/White
6	Yellow	17	
7	Brown	18	White/Purple
8	White/Brown	19	Blue/Yellow
9	Blue/White		
10	Orange		
11	White/Orange		

Figure 6-11. Base Connector Continuity Test

6-7. Auxiliary Switches

The following tests will determine if the auxiliary switches are functioning properly.

a. Switch Test

Disconnect connector CN9 at the Relay Box and using an ohmmeter check for continuity between pin 23 and pins 4 through 28 while activating the appropriate switch. See figure 6-12. Meter should read 0 ohms.

b. Test Results

If proper meter readings are not received, test the individual switches as necessary. Using an ohm-

meter, test the operation of an individual switch with the (+) test lead at the center terminal of the switch and the (-) test lead at the terminal opposite the direction of the switch actuation. See figure 6-13. Meter should read 0 ohms. If the switches check out, the problem would have to be in the wiring or connector CN9.




Figure 6-13. Auxiliary Switch Test






Figure 6-12. Auxiliary Switch Connector CN9

6-8. Relay Box

The power supply is directly connected to the relay contacts. When these contacts are closed, 24 volts is supplied to the solenoids which are mounted on the hydraulic mini-valves. One relay is used to supply power to the pump/motor and is always activated no matter what control function is selected. The brake locking circuit relay is also activated when any control function other than BRAKE UNLOCK is *initially* selected.

The following tests will determine if the relay box is functioning correctly.

a. Checking Relay Box Input Power

1. Plug the power cord into the 120VAC supply (wall receptacle). Disconnect connector CN4, leave all other connectors connected.

2. Using a DC voltmeter, test input power for both the BATTERY and AC120V operating modes. See figure 6-14. Meter should read approximately 24-28 volts in BATTERY mode and 26.5 ± 1 volts in AC120V mode.

BATTERY mode	AC120V mode
pin1=(+)	pin 5=(+)
pin2=(-)	pin 6=(-)

Connector CN4 Color Code

Pin 1 White	Pin 5 Yellow
Pin 2 Black	Pin 6 Black
Pin 3 Red	Pin 7 Blue
Pin 4 Blue	




Figure 6-14. Relay Box Input

b. Test Results:

If you do not receive the correct meter readings, the problem is in the input wiring, connectors or

components. If the correct readings are obtained, proceed to the next step.

c. Checking Output to Pump

1. Connect all connectors and activate either BATTERY or AC120V operating mode.

2. Test CN4 at pin 3(+) and pin 4(-) with a DC voltmeter. DO NOT disconnect connector CN4. Meter should read approximately 24 volts when any function button is activated. Refer to figure 6-14 for pin locations.

d. Checking Output to Pendant Control

NOTE

The Relay Box connectors CN1 (Pendant Control), CN8 (Auxiliary Base Connector), and CN9 (Auxiliary Switches) are interchangeable.

1. Disconnect the Pendant Control connector from the base connector, connect all other connectors and use a DC voltmeter to measure the following sockets located in the table base connector CN14. See figure 6-15 for pin locations.

NOTE

A fine wire or a paper clip may be needed to accurately test the small sockets in the connector. The connector is low voltage and there is no danger of electrical shock.





Figure 6-15. Connector CN14

e. Test Results:

If you do not receive the correct meter readings, the relay box or wiring is defective. If the correct readings are obtained, this part of the relay box is okay. Proceed to the next step.

f. Checking Output to Solenoids

This test checks the voltage that is used to energize the solenoids.

**NOTE**

- The Brake Lock function is activated by pressing any function button (except BRAKE UNLOCK). A timer in the Relay Box allows continuous output for about 7 seconds. If the brakes are already locked, no output is provided.

- The BRAKE UNLOCK button activates another timer in the relay box which allows continuous output for the brake release function for approximately 7 seconds. If the brakes are already released (using the BRAKE UNLOCK button) no output is provided.

1. Activate either BATTERY or AC120V operating mode.

2. Test connectors CN6 and CN7 from the back while attached to the relay box. All connectors should be connected.

3. Activate each of the pendant control buttons and measure the output voltage for the corresponding connector pins with a DC voltmeter. See figure 6-16.

g. Test Results:

If you do not receive the correct meter readings, the relay box is defective and should be replaced.

NOTE

Before deciding the relay box is defective, check the wires and pins in the connector blocks to make sure they are not loose or making a bad connection with their mate.

CN6			
OPERATION BUTTONS	+ TEST LEAD	- TEST LEAD	DC VOLTS
Table Up	1	2	24
Table Down	3	4	24
Trend	5	6	24
Rev Trend	7	8	24
Back Up	9	10	24
Back Down	11	12	24

CN7			
OPERATION BUTTONS	+ TEST LEAD	- TEST LEAD	DC VOLTS
Tilt Right	1	2	24
Tilt Left	3	4	24
Log Up	5	6	24
Log Down	7	8	24
Brake Set	9	10	24
Brake Unlock	11	12	24

Figure 6-16. Connector CN6 or CN7

NOTE

If the battery power is ON and no table functions have been activated for approximately 3 minutes, the power off circuit will interrupt the battery power.

6-9. Main Wire Harness Continuity Tests

If correct meter readings are not received in tests between components, before replacing the components, test the Main Wire Harness to be sure all connectors and wires are making a good connection.

a. CN4 to CN16 Test

1. Disconnect connectors CN4 and CN10. Leave all other connectors connected.

2. Using an ohmmeter, test for continuity between pins 1 and 2 of CN4 and pins 1 and 2 of CN10. See figure 6-17.

NOTE

The 15 amp battery protection fuse is in the line between CN4 pin 1 and CN10 pin 1. Test the continuity of the fuse if correct meter reading is not received.




Figure 6-17

b. CN4 to CN11 Test

1. Disconnect connectors CN4 and CN11. Leave all other connectors connected.

2. Using an ohmmeter, test for continuity between pins 3 and 4 of CN4 and pins 1 and 2 of CN11. See figure 6-18.




Figure 6-18

c. CN4 to CN12 Test

1. Disconnect connectors CN4 and CN12. Leave all other connectors connected.

2. Using an ohmmeter, test for continuity between pins 5 and 6 of CN4 and pins 3 and 4 of CN12. See figure 6-19.




Figure 6-19.

6-10. Solenoids

The solenoids are energized by 24 volt potential that is controlled by the relays located inside the relay box.

The solenoid windings are protected from excessive heat with an internal thermal fuse that will open after approximately seven (7) minutes of continuous operation. The solenoid must be replaced if the internal thermal fuse has been blown. The solenoids are mounted directly on either side of the hydraulic mini-valves and push the spool valve in one direction or the other depending upon which solenoid is activated.

a. Solenoid Test

The following tests will check the voltage applied to the solenoids and the resistance of the solenoid coil.

NOTE

If a solenoid does not function when the pendant control button is pushed, the problem could be the pendant control, the relay box, or the solenoid.

NOTE

Each solenoid operates on a 24V source from the relay box. This source can be checked by measuring the voltage at the 2 pin connector in question.

b. Test #1

1. Activate either BATTERY or AC120V operating mode.

2. Disconnect the 2 pin connector from the solenoid in question, all other connectors should be connected. See figure 6-20.

3. Use a DC voltmeter and measure the voltage across the 2 pin connector. Pin 1(+), and pin 2(-). Meter should read approximately 24-28 volts.

NOTE

The appropriate pendant control button must be pushed during this test. The motor will run when this test is performed, and the brake locking solenoid will be activated by any function other than MOVE.




Figure 6-20. Solenoid Test

c. Test Results:

If you do not receive the correct voltage, the problem could be in the wires leading down to the connector. The problem could also be in the relay box or the Pendant Control (refer to appropriate section for troubleshooting).

If the correct voltage is obtained, everything is good up to that point and the problem is more than likely the solenoid.

d. Test #2

The solenoid can be checked out using an ohmmeter R x 1 scale.

1. Measure the resistance between the two pin connector in question as shown in figure 6-20. Connector must be disconnected. Polarity of meter leads is not important.

2. The meter should read approximately 16 ohms at room temperature.

3. Measure the resistance between either pin and ground.

4. Meter should read infinity.

e. Test Results:

If the solenoid does not check out with the meter, it is more than likely defective and must be replaced.

NOTE

Whenever there are several components of the same type, a defective unit can also be detected by substituting a known good unit or wire connector. In some cases this may be faster than using a multi-meter.

6-11. Motor/Pump Assembly

The hydraulic pump motor is a 24 volt DC electric motor. The oil pump unit is attached to the bottom of the motor and is a gear type displacement pump with a pumping capacity of .4 liter per min. The Motor/Pump Assembly is mounted on insulators in the base of the table.

a. Motor/Pump Test

1. Disconnect motor connector CN11. Leave all other connectors connected and activate either BATTERY or AC120V operating mode.

2. Activate any function and use a DC voltmeter to measure across the two pin connector. Pin 1(+) and pin 2(-). See figure 6-21. Meter should read 24-28 volts.




Figure 6-21. Motor Input Voltage

NOTE

If the pump has been activated continuously for 1-1/2 to 2 minutes, the thermal relay will interrupt the power to the pump.

b. Thermal Relay Test

The Thermal Relay is used to interrupt the current flow to the pump motor to protect it from possible damage due to overheating.

1. Turn OFF both BATTERY and AC120V operating modes.

2. Use an ohmmeter to test for continuity between terminals 7 and 8 on the Thermal Relay. See figure 6-22.




Figure 6-22. Thermal Relay

3. The Thermal Relay should reset itself after approximately one minute if it is in the AUTO mode (this is the normal factory setting). If the relay fails to reset itself, check to make sure that the reset button is held IN with the small metal plate. See figure 6-23.




Figure 6-23.

4. The Thermal Relay should activate after 1-1/2 to 2 minutes of continuous pump operation. If necessary, adjust the thermal cut-out time by turning the adjustment screw clockwise to increase the time, counterclockwise to decrease the time. Refer to figure 6-22.

c. Test Results:

If you do not receive the correct meter readings, the problem could be in the wires, connectors, relay box, or main switch (refer to that section for troubleshooting).

If the correct voltage is obtained, everything is good up to that point and the problem could be the motor.

d. Motor Resistance Test

The motor can be statically checked for resistance using an ohmmeter. This test is not 100% accurate because you are checking the motor with very low voltage from the meter and without any load.

1. Using an ohmmeter R x 1 scale, measure the resistance between the two pins of CN11. See figure 6-24.

2. The meter should read 1 to 2 ohms at room temperature.

3. Measure the resistance between either pin and ground.

4. Meter should read infinity.




Figure 6-24. Motor Connector CN11

e. Test Results:

If you do not receive the correct meter readings, the motor or wiring is defective.

6001NB

SECTION VII -6001NB- BATTERY MODEL, ELECTRICAL TROUBLESHOOTING

7-1. General

The battery table components operate on 24VDC. The internal charging system also incorporates the components to transform the 120VAC input to 24VDC output to the components.

The Model designation **6001B** is for all battery tables with a Serial Number of 6001B-1992-2 & Prior. The designation **6001NB** is for all battery models with the Serial Number of 6001NB-1992-3 & Later.

The two models can be easily identified by the position of the Main Power switch. The power switch is on the lower front of the base on the 6001NB models. See figure 7-2.

NOTE

This section covers the electrical troubleshooting for the 6001NB model ONLY.

Electrical Troubleshooting for the 6001B is covered in section 6.

7-2. Troubleshooting Notes

The basic operation of each component will be defined along with a drawing and explanation on how to check it out.

Certain defective components could cause the entire table to stop functioning or only one control function to stop. It would depend on what part of the component failed. Other defective components would only cause one control function to stop.

The following defective components could cause all control functions to be affected:

- a. Motor/Pump Assembly
- b. Main Switch Circuit and Wiring

The following defective components could cause all control functions to be affected or only one control function:

- a. Relay Box
- b. Pendant Control

The component listed below would only affect one control function:

- Solenoid

When troubleshooting an electrical circuit, start at the problem and work back to the power source.

NOTE

•On the battery model tables, troubleshooting should begin by switching the operating mode. For example; if a function fails when attempting to operate the table in the AC120V mode, switch to the BATTERY mode. If the function now operates, the problem is probably located between the power cord and the relay box. If the function also fails when in battery operation, use the auxiliary switches to operate the function. If the function now operates, the problem is probably in the pendant control, connectors or wiring from the pendant control to the relay box.

•All connector pins are numbered usually with very small numbers.




Figure 7-2. Model Identification

6001NB




Figure 7-1. Electrical Circuit Block Diagram, Model 6001NB

7-3. Main Switch

The main power supply, 120 VAC, 60 HZ, comes in through the power cord and through the main switch. The main switch opens both lines when in the "OFF" position. Two 10 amp fuses are used to protect the complete electrical system and are located next to the main switch. See figure 7-2.

a. Main Switch Test

The following test will determine if line voltage is applied to connector CN15, which in turn would supply 120VAC power to the table.

1. Plug the power cord into the 120VAC supply (wall receptacle) and turn the main switch ON.
2. Disconnect connector CN15. See figure 7-1. Leave all other connectors connected.

CAUTION

Line voltage (120 VAC) will be measured in this test. Do not touch uninsulated connector pins or meter test leads.

3. Use an AC voltmeter capable of measuring 120 VAC and measure the voltage between pins 1 and 2 (black and white wires) located in connector CN15. See figure 7-3. You should receive line voltage 120 VAC.




Figure 7-3. Connector CN15 Test

b. Test Results

If the correct voltage is obtained, everything is good up to this point and the problem would have to be in another area.

If you do not receive the correct measurements, the problem would have to be in the wires, main switch, fuses, or power cord.

Check the continuity from the power cord connector ICN1, through the fuses, switch and wiring to

connector CN15. Remove the power cord, disconnect CN15 (black and white wires), and test as shown in figure 7-4.




Figure 7-4. CN15 to ICN1 Continuity Test

7-4. Batteries

The BATTERY operating mode is powered by two 12 volt batteries connected in series to provide the 24 volt operating power.

The battery system voltage should be 24VDC at a range of 22VDC to 26VDC. If the battery charge level falls below 23.5 volts the BATTERY operation indicator on the pendant control will blink indicating that the batteries require recharging. The built-in charging system automatically keeps the batteries at the proper charge level when the AC120V operating mode is ON. The charging system will operate while the table is being operated in the AC120V mode.

a. Battery System Test

1. Disconnect the main power cord and using a DC voltmeter, test each individual battery at its terminals. Meter should read 12VDC ± 1V.

2. To accurately test the batteries, they must be tested under a full load. Disconnect the main power cord and make sure all other connectors are connected.

3. Turn BATTERY power ON and elevate the table to its full up position.

4. Continue to press the TABLE UP button on the pendant control so that the pump motor continues to run and using a DC voltmeter, check the voltage drop of each battery individually. See figure 7-5.

5. Meter should read 12VDC ± 1VDC.




Figure 7-5.

b. Test Results

A reading of 11 volts or below indicates the battery needs charging.

After batteries have been fully charged, repeat the full load test. If either battery's voltage drops below 11VDC it should be replaced.

7-5. Battery Charging Box/AC120V Transformer

The Battery Charging Box contains the battery charging system as well as the components for AC120V operation (except the transformer).

a. Transformer Test

1. Confirm 120VAC input at CN15 using Main Switch test in 7-3a.
2. Connect CN15, disconnect CN18 (brown and red wires) and using an AC voltmeter, test the transformer output at CN18. See figure 7-6.
3. Meter should read 22VAC.




Figure 7-6. Connector CN18 Test

b. Test Results

If the correct voltage is obtained, everything is good up to this point and the problem would have to be in another area.

If you do not receive the correct measurements, the problem may be in the wires, connectors, or transformer. The transformer is located in the rear of the base under the stainless steel base cover. The stainless steel cover will have to be disconnected and lifted from the base for access to the transformer for further testing.

c. Battery Charging Box Test

1. Make sure all connectors are connected and turn AC120V operation ON. Using a DC voltmeter, test pin 3(+) and pin 4(-) of CN51. DO NOT disconnect connector CN51. See figure 7-7.




Figure 7-7. Connector CN51

2. Meter should read 26.5 ± 1 VDC.
3. Test pin 5(+) and pin 6(-) of CN51 with DC voltmeter to test operation of CHARGING indicator light (next to power cord connector).
4. Meter should read 26.5 ± 1 VDC if charger is operating. If batteries are fully charged there will be under 5 volts at pins 5 and 6.

d. Test Results

If you do not receive the correct readings, the charger system, connectors, wires, or the transformer may be defective.

e. Charging System Output Adjustment

If output reading at pins 3 and 4 is not $26.5 \pm 1VDC$, the output can be adjusted at the variable resistor VR-R59 on the circuit board inside the Charging Box. See figure 7-8. Turn the adjuster clockwise to decrease the voltage. Counterclockwise to increase the voltage.

NOTE

The battery connectors must be disconnected to adjust the battery charger output.




Figure 7-8

7-6. Switch-Over Relay

a. Switch-Over Relay in OFF Position

The Switch-Over Relay supplies the 24 volt input power from either the BATTERY or AC120V operating modes to the relay box for table operation. In the normal OFF position, BATTERY power is supplied to the relay box. See figure 7-9.




Figure 7-9. Relay in OFF Position

b. Switch-Over Relay in Activated Position

When the AC120V mode is activated by the main switch, a signal from the relay box activates the Switch-Over Relay. The relay then supplies the AC operating mode output power to the relay box and also activates the battery charging circuit. See figure 7-10.

NOTE

The battery charging circuit is only operational when the table is in the AC120V operating mode.




Figure 7-10. Relay in Activated Position

c. Switch-Over Relay Test

Using a DC voltmeter, test the operation of the relay in both the OFF (AC120V- OFF) and Activated (AC120V - ON) positions. See figure 7-11.

NOTE

The Switch-Over Relay mounting block may have to be removed from the base for test access.

OFF: (AC120V - OFF)
 term. 7(-) and term. 1(+) = 24 to 28VDC
 term. 7(-) and term. 6(+) = 0VDC

Activated: (AC120V - ON)
 term. 7(-) and term. 6(+) = $26.5 \pm 1VDC$

6001NB

a. Pendant Control Test

The following test will determine if the micro-switches inside the Pendant Control are functioning correctly.

1. Unplug the 24 pin Pendant Control connector from the base of the table. You will be checking the cord side connector.

2. Use an ohmmeter R x 1 and check the continuity between pins 1 and pins 4 through 19 while pressing the appropriate button. Also test between pins 21 and 22. See figure 7-12.

3. Ohmmeter must show continuity between the pins that are indicated when the appropriate buttons are pressed.




Figure 7-11. Switch-Over Relay

7-7. Pendant Control

The Pendant Control consists of 14 or 15 micro-switches (buttons). When any of the circuits are completed (by depressing a function button) the appropriate relay contacts (located in the relay box) close and a 24V potential is applied to the solenoid to operate the hydraulic mini-valve and to the hydraulic pump motor. The 6001NB Pendant Control has 5 volts applied to it.

NOTE

Pins 2 and 3 are connected to the LEDs (AC120V and BATTERY indicator lights on the pendant control) and cannot be checked with an ohmmeter. Pin 19 is used on -KRB Models ONLY. Pins 17, 18, 20, 23 & 24 are NOT USED.




Figure 7-12. Pendant Control Test

b. Test Results:

If you do not receive continuity between any of the pins, either the micro-switch in the Pendant Control is defective or a wire is broken. Either of these problems can be repaired easily.

If you receive correct readings with the meter, there is nothing wrong with the Pendant Control.

c. LED Test

The BATTERY and AC120V power ON indicators can be checked with an LED tester. Test BATTERY indicator at pin 1(+) and pin 2(-) of 24 pin Pendant Control connector. Test AC120V indicator at pin 1(+) and pin 3(-). See figure 7-12.

If no LED tester is available the LEDs can be tested by applying 5 volts to the appropriate pins. To avoid damage to the LED a 330 ohm resistor must be placed between the power source and the connector pins. See figure 7-13.



Figure 7-13. LED Test


d. Wiring Harness Test

The following test checks the wires leading from the relay box connector to the 24 pin connector table socket. These wires apply low voltage to the pendant control buttons.

1. Activate the AC120V operating mode.
2. Disconnect the pendant control from the table base connector. All other connectors should be connected.
3. Use a DC voltmeter and measure the following pins located in the 24 pin table base connector CN13. See figure 7-14.

NOTE

- A fine wire or a paper clip may be needed to accurately test the small sockets in the connector. The connector is low voltage and there is no danger of electrical shock.
- Pin 19 will have no voltage potential unless one of the return-to-level micro-switches are activated.




+ TEST LEAD	-TEST LEAD	DC VOLTS
1	3 - 16, 19	5.5
21	22	24

Figure 7-14. Table Base Connector

e. Test Results:

If you do not receive the correct voltage reading, the wiring or connector pins may be faulty. Disconnect connector CN1 from the Relay Box and using an ohmmeter, test the continuity between the corresponding pins in connectors CN1 and CN13. See figure 7-15. If the correct readings are obtained, this part of the circuit is okay and the problem may be the relay box.



CN - 14 PIN NO	CN - 1 WIRE COLOR	CN - 14 PIN NO	CN - 1 WIRE COLOR
1	Red/White	12	Grey
2	White	13	White/Grey
3	Black	14	White/Yellow
4	Red	15	Purple/White
5	White/Red	16	Black/White
6	Yellow	17	Not Used
7	Brown	18	Not Used
8	White/Brown	19	Not Used
9	Blue/White	20	Not Used
10	Orange	21	Blue/Red
11	White/Orange	22	Brown/White

Figure 7-15. Base Connector Continuity Test

7-8. Auxiliary Switches

The following tests will determine if the auxiliary switches are functioning properly.

a. Switch Test

Disconnect connector CN9 at the Relay Box and using an ohmmeter check for continuity at the connector pins (pin 1A common) while activating the appropriate switch. See figure 7-16. Meter should read 0 ohms.

b. Test Results

If proper meter readings are not received, test the individual switches as necessary. Using an ohm-

meter, test the operation of an individual switch with the (+) test lead at the center terminal of the switch and the (-) test lead at the terminal opposite the direction of the switch actuation. See figure 7-17. Meter should read 0 ohms. If the switches check out, the problem would have to be in the wires or connector CN9.







Figure 7-17. Auxiliary Switch Test



PIN NO.	COLOR	PIN NO.	COLOR
1(1A)	Red/White	14(7B)	
2(1B)		15(8A)	
3(2A)		16(8B)	
4(2B)	Red	17(9A)	
5(3A)	White/Red	18(9B)	
6(3B)	Yellow	19(10A)	
7(4A)	White/Yellow	20(10B)	White/Black
8(4B)	Brown	21(11A)	
9(5A)	White/Brown	22(11B)	Purple/White
10(5B)	Orange	23(12A)	
11(6A)	White/Orange	24(12B)	
12(6B)	Grey	25(13A)	
13(7A)	White/Grey	26(13B)	

Figure 7-16. Auxiliary Switch Connector CN9

7-9. Relay Box

The power supply is directly connected to the relay contacts. When these contacts are closed, 24 volts is supplied to the solenoids which are mounted on the hydraulic mini-valves. One relay is used to supply power to the pump/motor and is always activated no matter what control function is selected. The brake locking circuit relay is also activated when any control function other than BRAKE UNLOCK is *initially* selected.

Also, inside the 6001NB relay box is a step-down transformer and full-wave rectifier which decreases the voltage to 5-6 volts. This low voltage potential controls the relays by the use of the hand-held pendant control buttons. Basically the relays enable a 5-6 volt potential to control the 24 volt circuit.

The following tests will determine if the relay box is functioning correctly.

a. Checking Relay Box Input Power

1. Plug the power cord into the 120VAC supply (wall receptacle). Disconnect connector CN4, leave all other connectors connected.

2. Using a DC voltmeter, test input power for both the BATTERY and AC120V operating modes. See figure 7-18. Meter should read approximately 24 -28 volts.

BATTERY mode	AC120V mode
pin 1=(+)	pin 5=(+)
pin 2=(-)	pin 6=(-)

Connector CN4 Color Code

Pin 1 Red	Pin 5 White
Pin 2 Blue	Pin 6 Black
Pin 3 Yellow	Pin 7 Yellow
Pin 4 Blue	




Figure 7-18. Relay Box Input

b. Test Results:

If you do not receive the correct meter readings, the problem is in the input wiring, connectors or components. If the correct readings are obtained, proceed to the next step.

c. Checking Output to Pump

1. Disconnect pump connector CN12, connect all other connectors and activate the AC120V operating mode.

2. Test CN12 at pin 1(+) and pin 2(-) with a DC voltmeter. Meter should read approximately 24-28 volts when any function button is activated. If no voltage is present, use an ohmmeter to test the continuity from CN12 to CN4 (yellow and blue wires). Refer to figure 7-18 for pin locations.

d. Checking Output to Pendant Control

NOTE

The Relay Box connectors CN1 (Pendant Control), and CN8 (Auxiliary Base Connector), are interchangeable.

1. Disconnect the Pendant Control connector from the base connector, connect all other connectors and use a DC voltmeter to measure the following sockets located in the table base connector CN13. See figure 7-19.

NOTE

•A fine wire or a paper clip may be needed to accurately test the small sockets in the connector. The connector is low voltage and there is no danger of electrical shock.

•To make sure all operating modes are OFF, connect the pendant control, turn AC120V power OFF at the main switch, wait approximately 5 seconds to make sure BATTERY operating mode is not activated and disconnect the pendant control.

2. With the AC120V and BATTERY operating modes in the OFF position, test connector CN13 at pin 1(+) and pins 2 through 16(-). Meter should

read 0VDC. Test at pin 21(+) and 22(-), meter should read 24-28VDC.

3. With AC120V power ON (Main Power Switch activated), test connector CN13 at pin 1(+) and pins 3 through 16(-). Meter should read 5-6VDC.

4. Activate BATTERY operating mode by switching Main Power Switch OFF and momentarily placing a jumper wire between pin 21 and pin 22. Test pin 1(+) and pins 2 through 16(-). Meter should read 0VDC for pin 3; 5-6VDC for pins 2 and 4 through 16.




Figure 7-19. Table Base Connector CN13

e. Test Results:

If you do not receive the correct meter readings, the relay box or wiring is defective. Test appropriate wires and connectors as necessary. If the correct readings are obtained, this part of the relay box is okay. Proceed to the next step.

f. Checking Output to Solenoids

This test checks the voltage that is used to energize the solenoids.


1. Activate either BATTERY or AC120V operating mode.

NOTE

- The Brake Lock function is activated by pressing any function button (except BRAKE UNLOCK). A timer in the Relay Box allows continuous output for about 7 seconds. If the brakes are already locked, no output is provided.
- The BRAKE UNLOCK button activates another timer in the relay box which allows continuous output for the brake release function for approximately 7 seconds. If the brakes are already released (using the BRAKE UNLOCK button) no output is provided.

2. Test connectors CN6 and CN7 from the back while attached to the relay box. All connectors should be connected.

3. Activate each of the pendant control buttons and measure the output voltage for the corresponding connector pins with a DC voltmeter. See figure 7-20.



CN6

OPERATION BUTTONS	+ TEST LEAD	- TEST LEAD	DC VOLTS
Table Up	1	2	24
Table Down	3	4	24
Trend	5	6	24
Rev Trend	7	8	24
Back Up	9	10	24
Back Down	11	12	24
Tilt Right	13	14	24
Tilt Left	15	16	24

CN7

OPERATION BUTTONS	+ TEST LEAD	- TEST LEAD	DC VOLTS
Leg Up	1	2	24
Leg Down	3	4	24
Brake Set	9	10	24
Brake Unlock	11	12	24
Flex	13	14	24
Reflex	15	16	24

Figure 7-20. Connector CN6 or CN7

g. Test Results:

If you do not receive the correct meter readings, the relay box is defective and should be replaced.

NOTE

- Before deciding the relay box is defective, check the wires and pins in the connector blocks to make sure they are not loose or making a bad connection with their mate.

- If the battery power is ON and no table functions have been activated for 3 hours, the power off circuit will interrupt the battery power.

7-10. Main Wire Harness Continuity Tests

If correct meter readings are not received in tests between components, before replacing the components, test the Main Wire Harness to be sure all connectors and wires are making a good connection.

a. CN4 to Batteries Test

1. Disconnect connectors CN4 and the (+) and (-) connectors from the batteries. Leave all other connectors connected.

2. Using an ohmmeter, test for continuity between pin 1 of CN4 and battery (+) connector. Also test between pin 2 of CN4 and battery (-) connector. See figure 7-21.

NOTE

The 15 amp battery protection fuse is in the line between CN4 pin 1 and the battery connector. Test the continuity of the fuse if correct meter reading is not received.





Figure 7-21.

b. CN4 to CN12 Test

1. Disconnect connectors CN4 and CN12. Leave all other connectors connected.

2. Using an ohmmeter, test for continuity between pins 3 and 4 of CN4 and pins 1 and 2 of CN12. See figure 7-22.




CN - 4	CN - 12	OHMS
3	1	0
4	2	0

Figure 7-22.

c. CN4 to Charging Box Test

1. Disconnect connectors CN4, CN11 and CN51. Leave all other connectors connected.

2. Using an ohmmeter, test for continuity between pins 4, 5 and 6 of CN4, pins 1 and 2 of CN11, and pin 4 of CN51. See figure 7-23.



CN - 11	CN - 4	CN - 51	OHMS
1	5	4	0
2	6		0
	4		0

Figure 7-23. CN4, CN11, and CN51

7-11. Solenoids

The solenoids are energized by 24 volt potential that is controlled by the relay box.

The solenoid windings are protected from excessive heat by an internal thermal fuse that will open after approx. 7 minutes of continuous operation. The solenoid must be replaced if the internal thermal fuse has been blown.

The solenoids are mounted directly on either side of the hydraulic mini-valves and push the spool valve in one direction or the other depending upon which solenoid is activated.

a. Solenoid Test

The following tests will check the voltage applied to the solenoids and the resistance of the solenoid coil.

b. Test #1

1. Activate either BATTERY or AC120V operating mode.

2. Disconnect the 2 pin connector from the solenoid in question, all other connectors should be connected. See figure 7-24.

3. Use a DC voltmeter and measure the voltage across the 2 pin connector. Pin 1(+), and pin 2(-). Meter should read approximately 24-28 volts.

NOTE

- The appropriate pendant control button must be pushed during this test. The motor will run when this test is performed, and the brake locking solenoid will be activated by any function other than MOVE.

- If a solenoid does not function when the pendant control button is pushed, the problem could be the pendant control, the relay box, or the solenoid.




Figure 7-24. Solenoid Test

c. Test Results:

If you do not receive the correct voltage, the problem could be in the wires leading down to the connector. The problem could also be in the relay box or the Pendant Control (refer to appropriate section for troubleshooting).

If the correct voltage is obtained, everything is good up to that point and the problem is more than likely the solenoid.

d. Test #2

The solenoid can be checked out using an ohmmeter R x 1 scale.

1. Measure the resistance between the two pin connector in question as shown in figure 7-24. Connector must be disconnected. Polarity of meter leads is not important.

2. The meter should read approximately 16 ohms at room temperature.

3. Measure the resistance between either pin and ground.

4. Meter should read infinity.

e. Test Results:

If the solenoid does not check out with the meter, it is more than likely defective and must be replaced.

NOTE

Whenever there are several components of the same type, a defective unit can also be detected by substituting a known good unit or wire connector. In some cases this may be faster than using a multi-meter.

7-12. Motor/Pump Assembly

The hydraulic pump motor is a 24 volt DC electric motor. The oil pump unit is attached to the bottom of the motor and is a gear type displacement pump with a pumping capacity of .4 liter per min.

The Motor/Pump Assembly is mounted on insulators in the base of the table.

a. Motor/Pump Test

1. Disconnect motor connector CN12. Leave all other connectors connected and activate either BATTERY or AC120V operating mode.

2. Activate any function and use a DC voltmeter to measure across the two pin connector. Pin 1(+) and pin 2(-). See figure 7-25. Meter should read 24-28 volts.




Figure 7-25. Motor Input Voltage

NOTE

If the pump has been activated continuously for 1-1/2 to 2 minutes, the thermal relay will interrupt the power to the pump.

b. Thermal Relay Test

The Thermal Relay is used to interrupt the current flow to the pump motor to protect it from possible damage due to overheating.

1. Turn OFF both BATTERY and AC120V operating modes.

2. Use an ohmmeter to test for continuity between terminals 7 and 8 on the Thermal Relay. See figure 7-26.




Figure 7-26. Thermal Relay

3. The Thermal Relay should reset itself after approximately one minute if it is in the AUTO mode (normal factory setting). If the relay fails to reset itself, check to make sure that the reset button is held IN with the small metal plate. See figure 7-27.




Figure 7-27.

4. The Thermal Relay should activate after 1-1/2 to 2 minutes of continuous pump operation. If necessary, adjust the thermal cut-out time by turning the adjustment screw clockwise to increase the time, counterclockwise to decrease the time. Refer to figure 7-26.

c. Test Results:

If you do not receive the correct meter readings, the problem could be in the wires, connectors, relay box, or main switch (refer to that section for troubleshooting).

If the correct readings are obtained, everything is good up to that point and the problem could be the motor.

d. Motor Resistance Test

The motor can be statically checked for resistance using an ohmmeter. This test is not 100% accurate because you are checking the motor with very low voltage from the meter and without any load.

1. Using an ohmmeter R x 1 scale, measure the resistance between the two pins of CN12. See figure 7-28.

2. The meter should read 1 to 2 ohms at room temperature.

3. Measure the resistance between either pin and ground.

4. Meter should read infinity.




Figure 7-28. Motor Connector CN12

e. Test Results:

If you do not receive the correct meter readings, the motor or wiring is defective.

SECTION VIII ELECTRICAL SYSTEM ADJUSTMENTS

8-1. Relay Box Adjustments - Models 6001N & 6001NB

The Relay Box contains variable resistors for adjusting the operating timers for the BRAKE SET and BRAKE UNLOCK functions. The Relay Box for the battery model tables (6001NB) also has variable resistors for setting the Power Off timer and the battery recharge warning circuit. These timers are set at the factory and usually never need adjustment. If an adjustment is necessary, remove the relay box cover and use the following procedures. See figures 8-1 and 8-2.

a. Brake Release Timer

The Brake Release Timer is set for about 7 seconds and is controlled by the variable resistor VR1 on the relay box circuit board. Turn the adjuster clockwise to increase the operating time. Counterclockwise to decrease the operating time.

b. Brake Set Timer

The Brake Set Timer is set for about 7 seconds and is controlled by the variable resistor VR2 on the relay box circuit board. Turn the adjuster clockwise to increase the operating time. Counterclockwise to decrease the operating time.

c. Battery Low Voltage Indicator

When the battery voltage drops below 23.5 volts, the BATTERY power indicator will begin to "Flash" indicating low battery power. This circuit is controlled by the variable resistor VR3 and should be set at 23.5 volts. Turn the adjuster clockwise to increase the voltage at which the circuit is activated, counterclockwise to decrease.




Figure 8-1. Relay Box Adjustments Model 6001N




Figure 8-2. Relay Box Adjustments Model 6001NB

8-2. Relay Box Adjustments - Model 6001B

The Relay Box contains variable resistors for adjusting the operating timers for the BRAKE UNLOCK, Power Off timer and the battery recharge warning circuit. These timers are set at the factory and usually never need adjustment. If an adjustment is necessary, remove the relay box cover and use the following procedures. See figure 8-3.

a. Brake Release Timer

The Brake Release Timer is set for about 7 seconds and is controlled by the variable resistor VR3

on the relay box circuit board. Turn the adjuster clockwise to increase the operating time. Counterclockwise to decrease the operating time.

b. Battery Low Voltage Indicator

When the battery voltage drops below 23.5 volts, the BATTERY power indicator will begin to "Flash" indicating low battery power. This circuit is controlled by the variable resistor VR1 and should be set at 23.5 volts. Turn the adjuster clockwise to increase the voltage at which the circuit is activated, counterclockwise to decrease.









Figure 8-3. Relay Box Adjustments Model 6001B





Wiring Diagram, Model 6001KB

