SIEMENS

ACUSON X600 ACUSON X700 Diagnostic Ultrasound System System Reference







ACUSON X600, Product Version 1.0 ACUSON X700, Product Version 2.0 Software Version X700 VB20, X600 VA10

©2012-2014 Siemens Medical Solutions USA, Inc.

All Rights Reserved.

September 2014

Printed in the Republic of Korea.

ACUSON, AcuNav, Advanced SieClear, Axius, Cadence, Clarify, DIMAQ, Dynamic TCE, DTI, eSie Touch, Evolve Package, *four*Sight, microCase, MultiHertz, QuickSet, SuppleFlex, Siemens, SieClear, SieScape, SwiftLink, *syngo*, TGO, THI, Velocity Vector Imaging, X600, X700, and 3-Scape are trademarks or registered trademarks of Siemens AG or its subsidiaries and affiliates.

All other product names are trademarks or registered trademarks of their respective companies.

Siemens reserves the right to change system specifications at any time.

Global Business Unit and Legal Manufacturer

Siemens Medical Solutions USA, Inc. Ultrasound 685 East Middlefield Road Mountain View, CA 94043 U.S.A.

Phone: +1-888-826-9702 www.siemens.com/healthcare

CE Declaration

This product is provided with a CE marking in accordance with the regulations stated in Council Directive 93/42/EEC of June 14, 1993 concerning Medical Devices. The CE marking only applies to medical devices that have been put on the market according to the above referenced Council Directive.

Unauthorized changes to this product are not covered by the CE marking and the related Declaration of Conformity.

EU Authorized Representative

Siemens AG Medical Solutions Henkestrasse 127 91052 Erlangen Germany

Siemens Global Headquarters

Siemens AG Wittelsbacherplatz 2 80333 Muenchen Germany

Global Siemens Healthcare Headquarters

Siemens AG Healthcare Sector Henkestrasse 127 91052 Erlangen Germany

Phone: +49 9131 84-0 www.siemens.com/healthcare

Contents

Chapter 1 System Presets

Instructions for using the options in the **Presets** screen to customize the system.

Chapter 2 Documentation Devices

Information on documentation and storage devices, including procedures for storing and retrieving system presets and QuickSets.

Chapter 3 DICOM Connectivity Option

Explanation of the Digital Imaging and Communications in Medicine (DICOM) Connectivity option. This option provides digital image transfer using a DICOM network for both storage and printing.

Chapter 4 Network Export Function

A description of setting up and using the network export function. This function copies patient data to a password-protected shared folder on a destination device (export host) for offline-analysis.

Chapter 5 Wireless Network Selections

A description of how to enable or disable a wireless network adapter connected to the ultrasound system.

Chapter 6 Cardiac References

Chapter 7 Obstetrical References

Note: Not all features and options described in this publication are available to all users. Please check with your Siemens representative to determine the current availability of features and options.

System Reference

ii System Reference

About the User and Reference Manuals

The user and reference manuals contain descriptions for the following ultrasound systems:

- ACUSON X600 diagnostic ultrasound system
- ACUSON X700 diagnostic ultrasound system

Features and options unique to an ultrasound system are identified in Chapter 1 and Appendix A of the Instructions for Use.

The user and reference manuals consist of the following publications.

Publication	Includes		
Instructions for Use	■ Intended Audience		
	 Technical description of the ultrasound system 		
	 Safety and care information for the system and compatible transducers 		
	 Descriptions of all system controls 		
	 Procedures for system setup, examination fundamentals, and the biopsy function 		
	 Acoustic output data 		
Features and Applications Reference*	 Descriptions of image acquisition and optimization, including optional imaging features 		
	 General and exam-specific measurements and calculations 		
	 Data management 		
	 Explanation of the clinical software programs for use on the ultrasound system 		
System Reference*	Description of customizable system settings		
	 Information about DICOM connectivity, network capabilities, and external devices 		
	 Clinical references 		
Electromagnetic Emissions and Immunity: Guidance and Manufacturer's Declaration*	 Information regarding the electromagnetic compatibility (EMC) testing of this system 		

^{*}Languages supported by the user interface include a translation of this publication.

System Reference iii

Conventions

Take a moment to familiarize yourself with these conventions.

Warnings, Cautions, and Notes	 ▲ WARNING: Warnings are intended to alert you to the importance of following the correct operating procedures where risk of injury to the patient or system user exists. ▲ Caution: Cautions are intended to alert you to the importance of following correct operating procedures to prevent the risk of damage to the system. 	
	Note: Notes contain information concerning the proper use of the system and/or correct execution of a procedure.	
Cross-References	Examples:	
	See also: Biohazards, Safety and Care, Chapter 2, Instructions for Use	
	See also: Documentation Devices, Chapter 2, System Reference	
	See also: Alphanumeric Keyboard, p. 26	
Customizable System Settings	System settings available for customization are depicted as shown.	
	Example: Example: Default Settings > Automatic Freeze Response	
Keys and Controls	Keys and controls located on the control panel are identified by uppercase, boldface type.	
	Example:	
	Rotate the 2D control.	
	Keys located on the keyboard are identified by boldface type.	
	Example:	
	Press the Exam key.	
On-screen Objects	On-screen objects such as menu selections, soft key selections, and buttons are identified by boldface type.	
	Example:	
	The system displays the Patient Registration form.	
Selection of On-screen Objects	The SET key on the control panel functions as a point-and-select device (similar to a computer mouse) when used with the trackball.	
	"Select" or "click" describes this action:	
	Roll the trackball to position the pointer (cursor) on an on-screen object and then press the SET key.	
	"Double-click" describes this action:	
	Roll the trackball to position the pointer (cursor) on an on-screen object and then press the SET key twice.	
	"Drag" describes this action:	
	Roll the trackball to position the pointer (cursor) on an on-screen object and then press and hold the SET key. Roll the trackball to reposition the object and then release the SET key.	

iv System Reference

Intended Audience

The intended audience for the user and reference manuals includes the following users.

User	Interaction with Ultrasound Equipment	Expected Experience and Other Characteristics
Sonographer	 Acquires diagnostic views of anatomy, blood flow, and related pathology Performs measurements and analysis of the acquired images Prepares exam data for review and interpretation by a qualified physician 	 Ranges from novices (for example, students) to advanced practitioners with certification in multiple subspecialties Educated in anatomy, physiology, patient care, and identification of pathology in ultrasound images Many sonographers have a Bachelor's degree; some have advanced degrees in related health care subjects
Cardiologist	 Performs invasive and non-invasive ultrasound exams Interprets exam data, including echocardiography exam data Writes and assembles exam findings in a report 	 Medical doctor Expert in diagnostic imaging, including computed tomography (CT), magnetic resonance imaging (MRI), X-ray, ultrasound, and nuclear medicine Advanced training in imaging physics with typically four to six years of post-doctoral training in the field of cardiology
Maternal-fetal Medicine Obstetrician/ Perinatologist Radiologist and Internist	 Performs ultrasound exams Interprets exam data Writes and assembles exam findings in a report Performs ultrasound exams Interprets exam data Writes and assembles exam findings in a report 	 Medical doctor Manages high-risk obstetrical patients for the safe and successful delivery of the fetus Skilled in interpreting ultrasound exam data Medical doctors Expert in diagnostic imaging, including CT, MRI, X-ray, ultrasound, and nuclear medicine Advanced training in imaging physics with typically two to six years of post-doctoral training in the field of radiology
System Administrator and Customer Service Engineer	Configures the ultrasound system for use in a networked environment	 A System Administrator is an individual within your organization who is designated to set up system parameters to connect the ultrasound system or workstation to a picture archiving and communication system (PACS). Customer Service Engineers are Siemens representatives who configure the ultrasound system or workstation during software installation and support troubleshooting activities.

System Reference

vi System Reference

1 System Presets Setting General Preferences.....

Setting General Preferences	3
Using the System Presets	3
Making Screen Selections	4
Presets Screen	5
General 1	6
General 2	7
Customizing the Sequence of Data Entry for the Patient Data F	orm8
Peripheral	9
Customize Keys	10
Customizing the Display of Soft Key Selections	12
Display	13
Exam Configuration	15
User-Defined Exam List	17
Text Annotation	17
Customizing Text Annotations	18
Pictogram List	20
Customizing Pictograms	20
M & R Configuration	22
Customizing the Measurement and Report Preset Settings	23
Summary	32
Summary Page 1 Tab	32
Summary Page 2 Tab	32
Customizing the Summary	33
Service	33
Stress Echo	34
SieScape	34
Contrast Agent Imaging (CAI)	34
Wireless	34
DICOM	34
DIMAQ Utility	35
Clip Capture	36
Network Export	36
Authorization	37
Archive	39
Printer	39

Customizing OB and Early OB Measurements, Calculations, and Reports	40
Item & Reference Selection, Standard OB	
2D-Mode, M-Mode, Doppler, Ratio, and Growth Analysis Tabs	40
EFW / USMA Tab	42
Item & Reference Selection, Early OB	42
Display Item, Standard OB / Early OB	42
Growth Analysis Graphs, OB and Early OB	43
Standard OB / Early OB User-Defined Formulas	44
Standard OB / Early OB User-Defined Tables	46
User-Defined Label, OB and Early OB	48
Customizing Vascular Measurements, Calculations, and Reports	49
Display Item — Cerebrovascular (C-Vascular)	
Display Item — Peripheral Vascular (P-Vascular)	50
Display Item — Venous	50
Customizing Gynecology Measurements, Calculations, and Reports	52
Display Item — Gynecology	
Customizing Cardiac Measurements, Calculations, and Reports	53
Measurement Order — Cardiac	
Heading Tab	
Label Tab	
Display Item — Cardiac	56
User-Defined Label — Cardiac	
Customizing Emergency Medicine Measurements, Calculations, and	
Reports	
Calculation Item — Emergency Medicine	59
Customizing Fetal Echo Measurements, Calculations, and Reports	60
Display Item — Fetal Echo	60

Setting General Preferences

When the ultrasound system is installed at your site, all system settings are factory-defined. You can use the options and settings available in the **system presets** to set up the ultrasound system with your preferences for imaging. System presets define the configuration of the system software whenever you power on the system.

Using the System Presets

You can use the system presets at any time to change the factory (default) settings or modify your own presets.

Note: After powering on the system, you must wait until the system completes the series of self-diagnostic and calibration tests before making any changes to the system presets. These tests last a few minutes, after which the system presets are ready for use.

Siemens recommends that you back up your system presets and QuickSets onto external storage media to prevent accidental loss of your information.

To use the system presets:

- 1. Press the Presets key on the keyboard.
 - The system displays the **Presets** screen, with menu items on the left and selections on the right.
- Roll the trackball to the required menu item on the left of the screen and then press the SET key on the control panel.

The system displays selections for the selected menu item.

To save changes and exit the system presets:

Select the Save button at the bottom of the screen.

To discard changes and exit the system presets, choose a method:

- Select the Cancel button at the bottom of the screen and then select No in the displayed confirmation message.
- Press the Presets key on the keyboard and then select No in the displayed confirmation message.

Making Screen Selections

Use the following techniques to make selections on the right of the **Presets** screen. You can typically roll the trackball to position the trackball pointer on a menu item or setting and then press the **SET** key to complete the selection.

•	Drop-down lists – To open the menu, roll the trackball to position the pointer on the arrow and then press the SET key. To make a selection, roll the trackball to highlight the selection and then press the SET key.	Drop-down list.
•	Spin buttons – To set a higher or lower numeric value, roll the trackball to position the pointer on the up or down arrow and press the SET key until the desired value displays.	Spin button.
•	Check boxes – The option is selected when a checkmark displays inside the box and de-selected when the box is clear. To select or clear the check box, roll the trackball to position the pointer in the box and then press the SET key.	Check box.
•	Buttons – To select a labeled button, roll the trackball to position the pointer on the button or the label and then press the SET key. In some places, only one button can be selected at a time.	Option button.
•	Text entry – Roll the trackball to position the cursor in the field and then press the SET key. Use the keyboard to enter text. When finished, use the Tab key to move to another field or roll the trackball to reposition the cursor and then press the SET key.	Text entry.

1 - 4 System Reference

Presets Screen

The left side of the **Presets** screen lists the following menu items:

Menu Item	Allows you to	
General 1	Enter the name of the hospital or clinic; select a format for the language, date and time, height and weight; select the trackball speed; adjust audio settings; and select preferences for powering on and off the system.	
General 2	Select the registration method (patient data form and data entry requirements); select settings for pictograms and text; enable the system to save images with measurement markers; and designate the storage format for patient data forms, images and reports.	
Peripheral	Specify settings for peripheral devices connected to the ultrasound system, for example, a video recorder or bar code reader.	
Customize Keys	Assign functionality to specific controls on the control panel and the optional footswitch.	
Display	Customize the image screen, for example, enable or disable the screen saver, depth gain compensation curve, cursor in Doppler or M-mode, and patient information.	
Exam Configuration	Modify general settings for the selected exam type.	
User-Defined Exam List	Enable or disable access to each exam type.	
	See Also: For a list of exam types, see Examination Fundamentals, Chapter 4, Instruction for Use.	
Text Annotation	Customize annotation libraries for selected exam types or QuickSets.	
Pictogram List	Customize pictogram libraries for selected exam types or QuickSets.	
M & R Configuration	Select caliper (measurement function) conventions, establish preferences for measurement and reports for each type of exam, and select the number of heart cycles to use when calculating the heart rate.	
Summary	Customize page elements for the Summary report.	
Service	Access password-protected service procedures.	
Stress Echo	Access a new screen. Displays the Maintenance dialog box, from which the system allows you to configure options for the optional Stress Echo feature.	
SieScape	Specify settings for SieScape.	
CAI	Activate the contrast agent imaging (CAI) function and designate the extended clip duration.	
Wireless	Configure wireless network connections.	
DICOM	Configure the ultrasound system and connected devices (such as servers and printers) for DICOM by creating, editing, and activating aliases (DICOM configurations).	
DIMAQ Utility	Specify the display of the right panel.	
Clip Capture	Designate clip capture parameters: capture type, clip length, R-wave delay, and JPEC compression.	
Network Export	Verify selection of an existing setup, select another setup, edit an existing setup, or create a new setup for the host or export host.	
Authorization	Manage accounts and passwords for access to DIMAQ study screens.	
Archive	Configure archive deletion and save options.	
Printer	Install and configure USB printers.	

General 1

Selection	Option(s)	Allows you to
Organization		
Hospital Name	text entry	Enter the name of your hospital or clinic using up to 45 characters. You can modify this entry at any time.
Format		
Language	English	Designates the system language.
	German	
	French	
	Spanish	
	Italian	
	Chinese ¹	
Date Format	Month / Day / Year Day / Month / Year Year / Month / Day	Select the format for the date. The selected format is used in the image screen, the Patient Data form, and the patient reports.
Date & Time Settings		Access a new screen. Enter the current date and time.
Height & Weight	Metric	Select the format for the display of the patient's height and
Format	U.S.	weight used in the Patient Data entry form.
Audio		
Beep on Key Press	on, off	Select this check box to enable the beep to sound when a key is pressed.
Beep after Store Completes	on, off	Select this check box to enable the beep to sound when storage is completed.
Beep Volume	1 through 4, in increments of 1	Set the volume of the beep. Option 1 is the quietest, Option 4 is the loudest.
Line-in Volume	Off, 1 through 25	Adjusts the volume of video playback.
Trackball Behavior		
Trackball Travel	Low	Select the responsiveness of the system to trackball movement.
Speed	Medium High	Low repositions an object a short distance with minimal trackba movement.
	J	Medium repositions an object a moderate distance with minima trackball movement.
		High repositions an object a long distance with minimal trackball movement.
Boot Up		
Active Transducer	LC1	Select a transducer port to be active when you power on the
	LC2	system.
	LC3	
Power Off	Shutdown Confirmation	Select the system response when the partial power on/off switch $({}^{\mbox{$\dot{$}$}})$ is pressed.
	Dialog Power Off	Shutdown Confirmation Dialog — Displays a confirmation dialog box when powering off the system.
		Power Off — Powers off the system directly.
Close Study on System Standby	on, off	(Available when Shutdown Confirmation Dialog is selected for Power Off .)
Otaliaby		<i>,</i>

1 - 6 System Reference

¹ Supported languages are dependent on regional availability.

General 2

Selection	Option(s)	Allows you to
Patient ID		
AutoStore New Patient Form	on, off	Automatically store a screen representation of the completed patient data form to the registered patient's study.
Customize Entry Order		Access a new screen. Customize the order entry sequence in the patient data form.
Common Mode		
Delete Pictogram on Unfreeze	on, off	Select this check box to erase an on-screen pictogram after an image is unfrozen.
Delete Text on Unfreeze	on, off	Select this check box to erase on-screen text annotation after an image is unfrozen.
Pictogram Location	Upper Right	Displays the pictogram at the selected screen location.
	Lower Right	
Font Size	12, 14, 16, 18, 20	Select the point size of the font used for annotations.
Arrow Size	Small (Type1)	Select the size and the type of the directional arrows used for
	Small (Type2)	annotations.
	Small (Type3)	
	Medium (Type1)	
	Medium (Type2)	
	Medium (Type3)	
	Large (Type1)	
	Large (Type2)	
	Large (Type3)	
Patient Registration	Original e-entry	Original uses the standard patient registration form with conventional requirements for data entry and with modified requirements for data entry:
		 Automatically entered year for History fields with OB, Early OB, GYN, EM and Fetal Echo exam types (when month and day are entered).
		 Editable fetal age (Age field for OB, Early OB, EM and Fetal Echo exam types).
		e-entry displays an overlay of patient identification fields on the image screen.
Measurement Result	Small	Select the size of display for the measured results.
Display Size	Medium	
	Large	
Image Store		
Image Store Format with Caliper	on, off	Enable or disable storage of caliper (measurement) information with the image.
Size	Full Screen	Select the storage of the entire screen (including the imaging
	Diagnostic Window Only (1024x768)	parameters, thumbnail and soft keys) or only the image area.

Customizing the Sequence of Data Entry for the Patient Data Form

Note: This selection applies to the original patient data form only. To display an abbreviated patient registration form, use the system presets to select the e-entry form.

During patient registration, pressing the **Tab** key on the keyboard moves the text cursor to the beginning position of the next entry field in the patient data form. You can change the order entry sequence by restricting the **Tab** key to move through only the fields selected in the **Customize Entry Order** screen.

The **Customize Entry Order** screen has two columns: **Selectable Entries** on the left (the factory-default is blank) and **Entry Order** on the right (the factory-default lists all fields on the patient data form). The order of the entries in the **Entry Order** column indicates the order of the cursor in the patient data form when the **Tab** key is pressed.

Although you can customize the movement of the **Tab** key through the fields on the patient data form, the layout of the fields on the form is unchanged.

Note: You can use the trackball and SET key to move to any field on the patient data form.

To use the Customize Entry Order screen:

- Press the Presets key on the keyboard to display the system presets and then select General 2 from the left of the screen.
- Select the Customize Entry Order from the right of the screen.
- To remove a field from the Entry Order column, select the name of the field and click Delete.
- 4. To remove all fields from the Entry Order column, click Delete All.
- To insert a field from the Selectable Entries column, select the name of the field and click Add.
- 6. To change the order of fields in the **Entry Order** column, select the name of the field and click **Move Up** or **Move Down**.
- 7. To restore the factory default settings, select the **Default** button at the bottom of the screen and then select the **Yes** button in the displayed message box to confirm the action.

1 - 8 System Reference

Peripheral

Selection	Option(s)	Allows you to
DVR		
Device Type	TEAC UR-50BD	Select the video recording device.
	None	
Key Function	Record / Pause	Assign functionality to the key set up for use with a video
	Record / Stop	recording device.
Barcode Reader		(Requires a connected barcode reader and your facility's representative barcode sample)
		Map the barcode sample to entry fields on the ultrasound system's patient registration form.
Scan a barcode	(scanned entry)	Display the characters transferred from the scanned barcode sample.
		The position of the cursor is listed beside the barcode characters.
		Note: You can position the cursor in the barcode to determine the starting position (offset) of each entry field.
(check box)	Last Name	Enable or disable the selected entry field for use with the
	First Name	barcode reader.
	Patient ID	
	Performing MD	
	Sonographer	
Offset	(numerical entry)	Enter the starting position of the selected field in the barcode sample.
Length	(numerical entry)	Enter the character length of the selected field.
		Note: All fields support up to 24 characters except the Performing MD field and the Sonographer field (limited to 64 characters).

Customize Keys

Selection	Option(s)	Allows you to
Key Direction		
Depth(+)	CCW	Assign the direction of rotation to the DEPTH control for increasing the depth.
		(CW = Clockwise, CCW = Counterclockwise)
Zoom(+)	CW	Assign the direction of rotation to the ZOOM control fo increasing the magnification factor.
	33	(CW = Clockwise, CCW = Counterclockwise)
Focus(+)	ccw	Assign the direction of rotation to the FOCUS control for decreasing the depth of the focal zone marker (to the near field).
		(CW = Clockwise, CCW = Counterclockwise)
Key Function		
Soft Key	Customize	Access a new screen. Displays the soft key screen, from which the system allows you to customize the display of soft key selections.
Print/Store 1 Key	PC Printer	Assign functionality to the PRINT/STORE1 key.
Print/Store 2 Key	USB B/W	Assign functionality to the PRINT/STORE2 key.
	USB Color	Note: The selections for USB printers (for example,
	Disk Store	PC Printer or Disk Store & USB B/W) are available when you select a USB printer (located in the Printer
	Clip/Volume Store	section of the Printer presets screen).
	DICOM B/W Print	,
	DICOM Color Print	
	Disk Store & PC Printer	
	Disk Store & USB B/W	
	Disk Store & USB Color	
Clip Store Key	Disk Store	Assign functionality to the CLIP STORE key.
	Clip/Volume Store	
Left Pedal	Freeze	Assign functionality to the left or right pedal of the
Right Pedal	Disk Store	optional footswitch.
	Clip/Volume Store	Note: The selections for USB printers (for example, PC Printer or Disk Store & USB B/W) are available
	Rotate 90° Clockwise (TEE)	when you select a USB printer (located in the Printer
	Rotate 90° Counter Clockwise (TEE)	section of the Printer presets screen).
	Caliper	
	Update/View	
	Escape/Timer	
	4B	
	Split	
	TGO Update	
	U/D Flip	
	L/R Flip	
	USB B/W	
	USB Color	

1 - 10 System Reference

Selection	Option(s)	Allows you to
User-Defined 1 Key	4B	Assign functionality to the UD 1, UD 2, and UD 3 key.
User-Defined 2 Key	Split	
User-Defined 3 Key	Sector	
	U / D Flip	
	L / R Flip	
	Full Size	
	Full D	
	Full M	
	Dir Power	
	ECG	
	Exam	
	Report	
	Graph	
	Arrow	
	Clip/Volume Store	
	Biopsy	
	Clarify VE	
	Rotate 90° Clockwise (TEE)	
	Rotate 90° Counter Clockwise (TEE)	
	Text A	
	Text B	
	DVR	
	Transducer	
	Freeze (for UD 3 only)	
	TGO update (for UD 2 only)	
	None	
NEW Key	Not Used	Select the system response when the NEW key is
	Close Study	pressed.
	Close Study and reload	Not Used disables the NEW key.
	boot-up setting	Close Study closes the current study.
		Close Study and reload boot-up setting closes the current study and resets the system with the boot-up setting.
Exchange Key Functionality		
Exchange Functionality of Set and Escape key	on, off	Exchange the functionality of the SET key and ESCAPE key on the control panel.

Customizing the Display of Soft Key Selections

You can rearrange or remove the soft key selections available for the following modes of operation:

- 2D-mode
- Color Flow
- Power
- M-mode
- Doppler
- 3D imaging
- 3D Setup
- 3D/4D

Note: An asterisk (*) indicates there are unsaved changes on a tab.

To customize the display of soft key selections:

- Press the Presets key on the keyboard to display the system presets and then select Customize Keys from the left of the screen.
- Click Customize.

Each mode has a tab for real-time imaging selections (Live [Lv]) and a tab for system freeze selections (Frz). Each tab has multiple "pages" of soft key selections.

- 3. To remove soft key selections from buttons:
 - Select the button representing the soft key selection.
 The system displays a drop-down list of available options below the selected button.
 - b. Select Blank.
- 4. To remove a page of soft key selections, select the << or >> button to access the page and then select the **Delete Page** button.

The system removes the labels from all buttons on the page.

- 5. To remove a tab of soft key selections, select the **Delete All** button.
 - The system removes the labels from all buttons on all pages of the tab.
- 6. To assign a new soft key selection to a button:
 - a. Select the required button representing the soft key selection.
 The system displays a drop-down list of available options below the selected button.
 - b. Select the required label.

1 - 12 System Reference

Display

Selection	Option(s)	Allows you to
Monitor		
Enable Screen Saver	on, off	Select this check box to activate or uncheck to deactivate the screen saver.
Screen Saver Delay	5	Select the time delay (in minutes) before the system activates
	10	the screen saver.
	15	
	20	
Screen Saver Type	Black	Select the background for the screen saver.
	SIEMENS	
Display		
Video Invert	on, off	Select the polarity of the video display for the main image screen. Text is always white against gray or gray against white.
		On (checked) displays a white image area against a black background.
		Off (cleared) displays a black image area against a white background.
DGC		
DGC Invert with Image Invert	on, off	Select this check box to invert the DGC graphic on the image screen when you rotate the image.
DGC Curve Display	Off	Select when the DGC graphic displays on the image screen.
	Always On	Off prevents the DGC from displaying on the image screen.
	Time Out	Always On displays the DGC continuously on the image screen.
		Time Out removes the DGC from the screen three seconds after you adjust the curve. When you adjust the DGC controls again, the curve reappears on-screen.
DGC Control	Max image depth Current image depth	Select the image depth setting.
Thermal Index Display(Neo Head Exam only)	TIS / TIB TIC	Select whether to display TIS / TIB (Soft Tissue Thermal Index / Bone Tissue Thermal Index) or TIC (Cranial Bone Thermal Index) during neonatal head exams.

Selection	Option(s)	Allows you to
Doppler / M-Mode		
Bypass M / D Cursor Display	on, off	Select the system response when the M or D control is pressed. Select this check box to immediately display M-mode or Doppler. De-select the check box to initially display an M-mode or Doppler cursor in the 2D-mode image; the M or D control must then be pressed a second time for M-mode or Doppler to display.
Doppler Search Mode	on, off	Select this check box to activate Doppler Search Mode by pressing the D control, and audibly interrogate vessels with Doppler in 2D-mode before displaying the Doppler spectrum.
Doppler Frequency / Velocity	Frequency Velocity	Display frequency (Hz) or velocity (cm/s) as a unit in the Doppler spectrum.
Patient Banner		
Patient Data	Age	Display the age or the date of birth of the patient on the image
	Date of Birth	screen.
Hide Patient Information	on, off	Display or hide the patient demographic information.

1 - 14 System Reference

Exam Configuration

Selection	Option(s)	Allows you to
Exam	(list of exams)	Select an exam for customization.
Automatic Freeze	Caliper	Select the system response when the FREEZE key is pressed.
Response	Arrow	Cine activates the CINE function. Caliper activates the
	Text	measurement function.
	Cine	Text activates the annotation function. Arrow activates the arrow function.
	Pictogram	arrow function.
Seamless Dual	On	Activate seamless display of dual and split images.
	Off	
Steer Angle Type	FOV-1	Specify the steering angle for the VF10-5 transducer.
(VF10-5 Only)	FOV-2	
2D/M & 2D/Doppler	1/2 2D - 1/2 trace	Specify the image screen layout when two imaging modes are
Display Format	1/3 2D - 2/3 trace	active.
	2/3 2D - 1/3 trace	1/2 2D – 1/2 trace presents 2D-mode on the right side of the upper 1/2, with M-mode or Doppler in the lower 1/2.
	Side by side	1/3 2D – 2/3 trace presents 2D-mode on the right side of the upper 1/3, with M-mode or Doppler in the lower 2/3.
		2/3 2D – 1/3 trace presents 2D-mode on the right side of the upper 2/3, with M-mode sweep or Doppler spectrum in the lower 1/3.
		Side by side presents 2D-mode in the left 40 percent of the screen and either the M-mode sweep or the Doppler spectrum in the right 60 percent of the screen.
Default Doppler Update	2D-Frz / D-Lv	Select display of real-time 2D image during update or select the
Style	2D-Lv / D-Lv	update interval for the 2D image during update.
	D-Lv / 2D-1s	The update interval for D-Lv / 2D-EOS is the end of the sweep.
	D-Lv / 2D-2s	
	D-Lv / 2D-4s	
	D-Lv / 2D-8s	
	D-Lv / 2D-EOS	
Linear Steer Color	On	Select On to automatically invert the color velocity scale when
Invert	Off	you steer the ROI.
Auto Invert of Color	On	Select On to invert the Doppler spectrum and the color bar
and Spectrum	Off	together in 2D-mode with Color / Doppler when the INVERT key is pressed.

Selection	Option(s)	Allows you to
2D-Mode Steer with	On	Select On to allow the 2D-mode display to be steered by
Cursor	Off	moving the Doppler cursor.
Physio Management	Lead Type I	Select the lead type for use with the physiologic function.
	Lead Type II	Lead Type I is the convention for the right arm and the left arm.
		Lead Type II is the convention for the right arm and the left leg.
3 Lead ECG Display	on, off	Select this check box to display the related trace when the selected exam is activated. ECG trace displays from the ECG input.
Indicate R-Wave	on, off	Select this check box to identify R-wave triggers in CINE and also to indicate poor detection of an R-wave.
Aux ECG Display	on, off	Select this check box to display the external ECG trace from the auxiliary input when the selected exam is activated.
Aux Signal Display	on, off	Select this check box to display the external signal from the auxiliary input when the selected exam is activated.
Respiration Display	on, off	Select this check box to display the respiratory trace when the selected exam is activated.
Auto FOV with Color Activation	On	Automatically adjust the 2D-mode field of view (FOV) to the
	Off	color region of interest (ROI).

1 - 16 System Reference

User-Defined Exam List

Note: The currently activated exam is unavailable (dithered). The default exam for each transducer will continue to display in the Exam list when an exam is de-selected in the **User-Defined Exam List** screen

Selection	Option(s)	Allows you to
	Option(s)	
Enable Exam		Customize the list of available exams for some items in the Presets
(list of exams)	on, off	screen.
Text Annotation		
Selection	Option(s)	Allows you to
Exam & QuickSet	(list of exams)	Select an exam type or QuickSet for customization.
Cat Taut A / Taut D	ff	Display the same at a sate way defined asset time that are

Selection	Option(s)	Allows you to
Exam & QuickSet	(list of exams)	Select an exam type or QuickSet for customization.
Set Text A / Text B	on, off	Display the screen to enter user-defined annotations that are assigned to Text A and Text B.
Text Annotation	Anatomy	Display the selected list (library) of annotations.
	Position	
	User Defined	
(text box)		Enter a user-defined annotation or change the selected annotation.
Modify		Replace the selected annotation with the characters displayed in the text box.
Add		Insert the annotation that is displayed in the text box into the displayed list (library).
Delete		Remove the annotation that is displayed in the text box from the displayed list (library).
Move Up		Shift the selected annotation to the next highest position within the list (library).
Move Down		Shift the selected annotation to the next lowest position within the list (library).
Tab Order	General	Display or arrange the position of the selected tab indicator.
	Position	
	Anatomy	
	User Defined	
Auto-Complete	On	When enabled (selected), the system displays a matching phrase
	Off	from the pre-defined text library based on the first few letters you enter using the keyboard.
		Note: You must press the Tab key on the keyboard or double-click SET to accept the displayed phrase.

Customizing Text Annotations

Each exam type has a list of text annotations for anatomical structures and body positions.

You can display a library of annotations for an exam type or QuickSet, use the scroll bar to display additional selections, insert, edit, and remove annotations, change the position of annotations within the library, and reset the annotation library to factory defaults.

To display a library of annotations for an exam type or QuickSet:

 Press the Presets key on the keyboard to display the system presets and then select Text Annotation from the left of the screen.

The system displays the Customize Text Annotation screen.

- 2. Select the exam type or QuickSet from the Exam & QuickSet drop-down list.
- 3. To exit the system presets without saving changes, select the **Cancel** button at the bottom of the screen and then select **No** to confirm the action.

To display additional selections when a scroll bar is displayed:

- Roll the trackball to the up or down arrow on the scroll bar to the right of the selections and press and hold the SET key.
- 2. Roll the trackball until the required selections are displayed and then release the SET key.

To insert an annotation into the displayed library:

1. To specify the location for the new annotation, select an existing annotation within the library.

The system highlights the selected annotation and displays the annotation in the text box.

Use the keyboard to delete the text in the text box and then enter the new annotation into the text box.

Note: You can enter up to 25 characters.

3. Select the Add button.

The system inserts the new annotation below the selected existing annotation within the library.

4. To save changes and exit the system presets, select the **Save** button at the bottom of the screen.

To edit an annotation in the displayed library:

1. Select the annotation within the library.

The system highlights the selected annotation and displays the annotation in the text box.

- Use the keyboard to edit the annotation in the text box.
- 3. Select the Modify button.

The system replaces the selected annotation with your edits.

 To save changes and exit the system presets, select the Save button at the bottom of the screen.

To remove an annotation from the displayed library:

Select the annotation within the library.

The system highlights the selected annotation and displays the annotation in the text box.

- 2. Select the **Delete** button.
- To save changes and exit the system presets, select the Save button at the bottom of the screen.

1 - 18 System Reference

To change the position of an annotation within the displayed library:

- 1. Select the annotation within the library.
 - The system highlights the selected annotation and displays the annotation in the text box.
- To shift the annotation to the next highest position within the library, select the Move Up button.
- To shift the annotation to the next lowest position within the library, select the Move Down button
- To save changes and exit the system presets, select the Save button at the bottom of the screen.

To enter user-defined annotations that are assigned to Text A and Text B:

- 1. Select the Set Text A / Text B check box.
 - The system displays the text box to enter user-defined annotations for Text A.
- 2. Enter the user-defined annotation in the text box and select Add.
- Select Save.
- 4. To enter a user-defined annotation for Text B, select **Text B** from the **Exam & QuickSet** drop-down list and repeat steps 2 and 3.

To select the display of a tab:

Note: You cannot hide the General tab indicator.

- To display an annotation tab indicator, select the check box next to the name of the tab in the Tab Order list.
- To hide an annotation tab indicator, clear the check box next to the name of the tab in the Tab Order list.

To rearrange the order of annotation tabs:

- 1. Select the name of a tab indicator in the **Tab Order** list.
- 2. Click **Move Up** or **Move Down** to position the tab indicator.

To reset annotations for the selected exam type or QuickSet to factory defaults:

 Select the **Default** button at the bottom of the screen and then select the **Yes** button in the displayed message box to confirm the action.

Pictogram List

Selection	Option(s)	Allows you to
Exam & QuickSet	(list of exams)	Select an exam type or QuickSet for customization.
All Pictograms		Display the pictograms available on the system.
Selected		Display the library of pictograms for the selected exam type or QuickSet.
Add		Insert the selected pictogram into the displayed library.
Delete		Remove the selected pictogram from the displayed library.
Move Front		Shift the selected pictogram to the next position within the library.
Move Back		Shift the selected pictogram to the previous position within the library.

Customizing Pictograms

Each exam type has pictograms that can be selected when the exam type is active. The pictograms are stored in libraries that you can edit for each exam type. The first available pictogram in the library displays on the screen when you press the **PICTOGRAM** key on the control panel.

You can display the library of pictograms for an exam type or QuickSet, use the scroll bar to display additional selections, insert and remove pictograms, change the position of pictograms within the library, and reset the pictogram library to factory defaults.

To display the library of pictograms for an exam type or QuickSet:

- 1. Press the **Presets** key on the keyboard to display the system presets and then select **Pictogram List** from the left of the screen.
 - The system displays the Customize Pictogram List screen.
- 2. Select the exam type or QuickSet from the Exam & QuickSet drop-down list.
- To exit the system presets without saving changes, select the Cancel button at the bottom of the screen and then select No to confirm the action.

То	Do This
Insert a pictogram into the library	 Select an existing pictogram from the All Pictogram list and then click Add.
	The system places the new pictogram at the bottom of the Selected list.
Rearrange the pictograms	Select an existing pictogram from the Selected list.
	2. To reposition the pictogram forward in the list, click Move Front .
	3. To reposition the pictogram backward in the list, click Move Back .
Delete a pictogram from the library	 Select an existing pictogram from the Selected list and then click Delete.
	The system places the pictogram in the All Pictogram list.

1 - 20 System Reference

To display additional selections when a scroll bar is displayed:

- 1. Roll the trackball to the up or down arrow on the scroll bar to the right of the selections and press and hold the **SET** key.
- 2. Roll the trackball until the required selections are displayed and then release the SET key.

To insert a pictogram into the displayed library:

- 1. Select the new pictogram from the All Pictograms section of the screen.
- 2. Select the Add button.
 - The system places the new pictogram at the bottom of the list in the **Selected** section of the screen.
- To save changes and exit the system presets, select the Save button at the bottom of the screen.

To remove a pictogram from the displayed library:

- 1. Select the pictogram from the **Selected** section of the screen.
 - The system outlines the selected pictogram.
- 2. Select the Delete button.
- To save changes and exit the system presets, select the Save button at the bottom of the screen.

To change the position of a pictogram within the displayed library:

- 1. Select the pictogram from the Selected section of the screen.
 - The system outlines the selected pictogram.
- 2. To shift the pictogram to the next position within the library, select the **Move Front** button.
- To shift the pictogram to the previous position within the library, select the Move Back button.
- To save changes and exit the system presets, select the Save button at the bottom of the screen.

To reset pictograms within the displayed library to factory defaults:

 Select the **Default** button at the bottom of the screen and then select the **Yes** button in the displayed message box to confirm the action.

M & R Configuration

Selection	Option(s)	Allows you to
Heart Rate Tool		
Number of Heart Cycles for Heart Rate	1, 2, 3, 4, 5	Select the number of heart cycles.
Measurement and Report Preset		
Report Data Auto Store	on, off	Select the check box to automatically store the patient report and measurement data to the DIMAQ integrated workstation when studies are ended.
(Drop-down list)	(list of exams)	Change measurement and report settings for the selected exam type.
Comments Library		(For use with all exam types)
		Enter up to 10 comments for automated inclusion into the Report and Summary.
Recommendations		(For use with all exam types)
Library		Enter up to 10 recommendations for automated inclusion into the Summary.
Anatomy Assessment		(For use with all exam types)
		Define and display descriptive data fields and related descriptions for patient reports.

1 - 22 System Reference

Customizing the Measurement and Report Preset Settings

The Measurement and Report Preset section allows you to customize each exam type.

Measurement Method

(For use with all exam types)

Use this selection to establish a shortcut to a specific measurement method.

The upper section of this screen allows you to select the method activated when the system first enters the measurement function for the specified imaging mode.

The lower section of this screen allows you to select a specific method for automatic activation when a general measurement method is selected in the measurement function. For example, if **Ellipse** is selected in the **Area** field, selecting **Area** from the list of general measurement methods automatically activates the Ellipse method.

To select the Default Measurement Method by Mode:

- For each imaging mode, roll the trackball to the arrow on the right side of the method field and then press the SET key.
 - The system displays a pull-down menu of available measurement methods for this imaging mode.
- 2. Roll the trackball to highlight a measurement method and then press the **SET** key. The highlighted method becomes the default for this imaging mode.

To select the Default Measurement Method:

- For each measurement method category, roll the trackball to the arrow on the right side of the method field and then press the SET key.
 - The system displays a pull-down menu of specific methods.
- 2. Roll the trackball to highlight a measurement method and then press the **SET** key. The highlighted method becomes the default for this method category.

Customize Keys

(For use with all exam types)

You can customize the display of soft key selections for use during the measurement function for the following modes:

- 2D-mode
- M-mode
- Doppler

See also: Customize Keys, p. 1-10

Comments Library for Report

(For use with all exam types)

For exam types with reports, you can enter ten comments for automated inclusion into the report. A maximum of 255 characters is allowed per comment.

Creating a library of comments for a patient report saves you time, particularly for recurring examinations. Rather than entering a phrase in the comment section of a report, you can access pre-defined comments for quick entry by rolling the trackball to the **Comments** button and then pressing the **SET** key.

To enter comments:

- 1. Roll the trackball to one of the comment fields and then press the **SET** key.
- 2. Use the keyboard to type in up to 255 alphanumeric characters.
- 3. Repeat steps 1 and 2 for each required comment.
- Complete comment entry by rolling the trackball to the Save button and then pressing the SET key.

Recommendations Library

(For use with all exam types)

You can access recommendations defined in the system presets for quick entry by clicking **Recommendations** in the Summary.

То	Do This
Enter recommendations into the	1. Position the cursor on one of the recommendation fields.
library	2. Enter the recommendation text (up to 255 characters).
	3. Click Save.

1 - 24 System Reference

General Configuration

(For use with all exam types)

Selection	Option(s)	Allows you to
General Caliper		Change general settings that apply to all exam types.
Caliper Default Position	Center Menu	Assign trackball control to the pointer or measurement marker when the measurement function is initiated.
	Depth	Center displays the first marker in the center of the image screen. A depth value does not display.
		Menu displays the trackball pointer in the Measurement Menu if a label is available. For exam types with no labels, the trackball pointer remains in the center of the image screen when Menu is selected.
		Depth displays the first marker in the center of the image screen, with a dotted line representing the depth from the skin line. A depth value displays in the Measured Results area of the image screen until you anchor the first marker.
Caliper Pattern	х	Specify the shape of the caliper. You can specify one shape at a time for
	+	the entire system. Multiple measurements use the same shape, but are differentiated by number.
Caliper Size	Small	Specify the size of the caliper for use by the entire system. A smaller
	Medium	size may make a larger number of calipers easier to view.
	Large	
Measurement Results	On	Activate or deactivate a background for the Measured Results section of
Background	Off	the image screen.
Measurement Result Display		
2D-Mode	Тор	Displays the Measured Results at the selected screen location in 2D-
	Bottom	Mode.
	Left	
	Right	
Doppler/M-Mode	Тор	Displays the Measured Results at the selected screen location in
	Bottom	Doppler or M-Mode.
	Left	
	Right	

Anatomy Assessment

(For use with all exam types)

То	Do This
Create a user-defined item (descriptive data field)	Note: You can create up to 10 user-defined items for OB and EOB exams and up to 39 user-defined items for other exams.
	1. Select the Item tab.
	2. Enter an item in the User-Defined Item text box.
	3. Click Add.
	The user-defined item displays in the lower Items list.
Delete a user-defined item	1. Select a user-defined item from the lower Items list.
	2. Click Delete .
Create a user-defined selection	1. Select the Selections tab.
corresponding to a selected item	2. Select an item from the Item list.
	3. Enter a selection in the User-Defined Selection text box.
	4. Click Add.
	The user-defined selection displays in the lower Selections list.
Delete a user-defined selection	1. Select a user-defined selection from the lower Selections list.
	2. Click Delete .
Add items or selections to the List Order list	1. Select the Item or the Selections tab.
	2. Select items or selections from the Items or Selections list.
	3. Click Add next to the List Order list.
	The item displays in the List Order list.
	4. Click Save.
	Note: If there are no more spaces in the List Order list, the Add button is disabled. Delete items or selections in the List Order list to add new items or selections.
Delete items or selections from the	1. Select the Item or the Selections tab.
List Order list	2. Select items or selections from the List Order list.
	3. Click Delete next to the List Order list.
	The user-defined items or selections display in the lower Items or Selections list.
	The pre-defined items or selections display on the upper Items or Selections list.
Rearrange items or selections	Select items or selections from the List Order list.
	2. Click Move Up or Move Down to arrange the position of the items or selections.
Restore the factory-defined settings	Click Default at the bottom of the screen.
	The system restores the factory-defined settings and also overwrites the settings that you created.

1 - 26 System Reference

Measurement Order

(Not for use with the following exam types: OB, Early OB, Urology, Orthopedic, and EM)

Use this selection to add and delete labels and to rearrange the order in which labels appear in the Measurement Menu. The **Measurement Order** screen presents two columns of entries: **Selectable Label** on the left and **Measurement Order** on the right. Add labels from left to right or delete labels from right to left. User-defined labels initially appear on the left.

To select an imaging mode:

Note: Not for use with the following exam types: P-Vascular, C-Vascular, Penile.

 Roll the trackball to the down arrow for the Mode drop-down menu, select the required imaging mode and then press the SET key.

To add labels:

- Roll the trackball to a selectable label on the left and then press the SET key.
 The system highlights the label.
- Roll the trackball to the Add button and then press the SET key.
 The label is moved to the bottom of the Measurement Order list on the right.
- 3. Repeat steps 1 and 2 for other labels, as required.

To delete labels:

 Roll the trackball to a label in the **Measurement Order** list on the right and then press the SET key.

The system highlights the label.

- Roll the trackball to the **Delete** button and then press the **SET** key.The label is moved to the bottom of the **Selectable Label** list on the left.
- 3. Repeat steps 1 and 2 for other labels, as required.

To rearrange labels:

 Roll the trackball to one of the labels in the Measurement Order list on the right and then press the SET key.

The system highlights the label.

- 2. Roll the trackball to the **Move Up** or **Move Down** button and then press the **SET** key. The label moves up or down one space in the list.
- 3. Repeat steps 1 and 2 as required to create a restructured Measurement Order list.

To reset labels back to factory default positions:

- 1. Roll the trackball to the **Default** button and then press the **SET** key. The system prompts you to confirm your choice.
- 2. Roll the trackball to the **Yes** button and then press the **SET** key to continue.

Follicle Measurement Method - Gynecology Exam

The gynecology exam **Measurement Order** screen contains an extra field for specifying the Follicle Measurement Method.

To select the Follicle Measurement Method (Gynecology exam):

- Roll the trackball to the arrow on the right of the Follicle Measurement Method field and then press the SET key.
 - The system displays a drop-down menu of available selections.
- 2. Roll the trackball to highlight one of the selections and then press the **SET** key. The highlighted selection becomes the new Follicle Measurement Method.

LV (Left Ventricle) Measurement Method - Fetal Echo Exam

The fetal echo exam **Measurement Order** screen contains an extra field for specifying the LV Measurement Method.

To select the LV Measurement Method (Fetal Echo exam):

- Roll the trackball to the arrow on the right of the LV Measurement Method field and then
 press the SET key.
 - The system displays a drop-down menu of available selections.
- 2. Roll the trackball to highlight one of the selections and then press the **SET** key. The highlighted selection becomes the new LV Measurement Method.

Measurement Label Display - Thyroid Exam

The thyroid exam **Measurement Order** screen contains an extra field for displaying labels for each measurement menu.

Display Item

(Not for use with the following exam types: OB, Early OB, GYN, P-Vascular, C-Vascular, Venous, Fetal Echo, Cardiac, Ped Echo, TEE)

Use this selection to control display of various items on the measurement screen and in the patient report. The **Display Item** screen is unique for each exam type.

Exam Types	Description of Unique Display Item Screen
OB, Early OB	See page 1-42
GYN	See page 1-52
P-vascular	See page 1-50
C-vascular	See page 1-49
Venous	See page 1-50
Fetal Echo	See page 1-60
Cardiac, PedEcho, TEE	See page 1-56

1 - 28 System Reference

Selection	Option(s)	Allows you to	
Measurement Screen			
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.	
Hip Angle Graph (Orthopedic exam only)	on, off	Select this check box to display the sonographic hip angle graph when a Ortho exam measurement has been completed.	
Report			
Performing MD	on, off	Select this check box to include the Performing MD entered in the Patient Data form at the bottom of the report page.	
Referring MD	on, off	Select this check box to include the Referring MD name entered in the Patient Data form at the bottom of the report page.	

User-Defined Label

(Not for use with the following exam types: Urology, Orthopedic, Fetal Echo, Penile, TCD, and EM)

Use this selection to designate special measurement labels.

See also: User-Defined Label, OB and Early OB, p. 1-48

See also: User-Defined Label — Cardiac, p. 1-57

To create a user-defined label:

1. Select a user-defined label number from the drop-down list.

Note: Not available for Doppler with the following exam types: P-Vascular, C-Vascular, GYN, and Renal.

- 2. Enter a label name using the keyboard:
 - For 2D-mode, enter a name in the Label Name text box.
 - For Doppler with GYN and Renal exams, enter a name in the NAME text box.
 - For Doppler with P-Vascular and C-Vascular exam types, enter a label name in the User Defined text box.
- 3. Select a required measurement method from the drop-down list.

Note: Not available for Doppler with the following exam types: P-Vascular, C-Vascular, GYN, and Renal.

4. Repeat steps 1 through 3 for each label.

The system prompts you to save the label.

When all labels have been entered, roll the trackball to the Save button and then press the SET key.

Note: For user-defined labels to appear in the Measurement Menu, you must add them to the Measurement Order list using the **Measurement Order** screen.

To delete a user-defined label:

- Click Delete Current 2D-Mode Label for 2D mode and repeat for each mode.
- For Doppler with P-Vascular, C-Vascular, GYN, and Renal exam types, click Delete Label.

Note: User-defined labels cannot be deleted when they are added to the Measurement Order list.

User-Defined Formula

(For use with the following exam types only: P-Vascular, C-Vascular)

See also: Standard OB / Early OB User-Defined Formulas, p. 1-44

To create a user-defined formula:

- From the Measurement and Report Preset selections for the C-Vascular or P-Vascular exam, roll the trackball to the User-Defined Formula button and then press the SET key. The system displays the User-Defined Formula screen.
- 2. Roll the trackball to the first field and then press the SET key.
- 3. Use the keyboard to enter up to eight characters as the name for the formula.
- 4. Enter the formula in the field below the formula name. Use the keyboard to enter any of the numbers and operators shown in the **Operation** box at the bottom of the screen.
- 5. Roll the trackball to any of the Variable Labels on the right and then press the **SET** key to include the variable in the formula.
- 6. Define constants by first rolling the trackball to the **Value** field to the right of the constant label letter and then pressing the **SET** key.
- 7. Enter a numeric value of up to eight characters, including a decimal point if required and then press the **Enter** key on the keyboard.
- 8. To insert a constant into a formula, roll the trackball to the appropriate letter in the **Label** column and then press the **SET** key.

The system inserts the label letter into the formula.

Note: You can use parentheses, but do not use spaces to separate elements in your formula. Do not delete any of the quote marks entered by the system. You can enter up to 64 characters in the formula field. To conserve space, you can assign a letter value to a constant and enter the letter into your formula instead of the full constant.

For additional formulas, roll the trackball to a different formula tab and then press the SET key. Repeat steps 2 through 8.

1 - 30 System Reference

To delete a user-defined formula:

• Roll the trackball to the **Delete Formula** button and then press the **SET** key.

The system deletes the formula for this tab.

To exit the User-Defined Formula screen:

 To exit and save the formula, roll the trackball to the Save button and then press the SET key.

The system informs you if there is a syntax or other error in the formula. Resolve the problem and exit again.

2. To exit and not save the formula, roll the trackball to the **Previous** button and then press the **SET** key.

The system queries you to save changes by selecting $\bf Yes$ or discard changes by selecting $\bf No$.

Report Tab

(For use with the following exam types only: GYN, EM)

Use this selection to add and delete tabs and to rearrange the order in which tabs display in the measurement report for the selected exam type.

То	Do This		
Add tabs to a report	Select a tab from the Selectable Report Tab Order list.		
	2. Click Add.		
	The tab is relocated to the bottom of the Report Tab Order list.		
Delete tabs from a report	Note: You cannot delete the last tab in the Report Tab Order section.		
	1. Select a tab in the Report Tab Order list.		
	2. Click Delete .		
	The tab is relocated to the bottom of the Selectable Report Tab Order list.		
Rearrange tabs on a report	Select a tab in the Report Tab Order list.		
	2. Click Move Up or Move Down.		
	The selection moves up or down one position in the list.		

Summary

Note: Display Items for Summary and Signature section applies only when a new study is opened.

Summary Page 1 Tab

Selection	Option(s)	Allows you to
Site Information		
Logo	on, off	Insert an image in the Letter Header section.
Load		Select an image from the USB-compatible device.
Delete		Delete the selected image.
Text 1	(text entry)	Enter text to display in the Letter Header section.
Text 2	(text entry)	Enter text to display in the Letter Header section.
Text 3	(text entry)	Enter text to display in the Letter Header section.
Font		Access a dialog box to customize the display of text (for example, type, style, or size).
Display Items for Summary		
Report Title	On	Enable or disable the Report Title section on the Summary .
	Off	
Graphs	On	Enable or disable the Graphs section on the Summary .
	Off	(Displays only in exam types that include Graphs .)
Image	On	Enable or disable the Images section on the Summary .
	Off	
Summary	On	Enable or disable the Summary section on the Summary .
	Off	
Recommendations	On	Enable or disable the Recommendations section on the
	Off	Summary.
Signature	On	Enable or disable the Signature section on the Summary .
	Off	

Summary Page 2 Tab

Selection	Option(s)	Allows you to	
Section Heading		Enter a user-defined title for each section.	
Signature	Enter the names of the people who sign the Summary.		
Add		Inserts the defined name into the list.	
Delete		- Remove the selected name from the list.	
Reference Values			
Display Adult Cardiac	On	Enable or disable the display of cardiac reference values for each	
Reference Values	Off	measured label on the Summary .	

1 - 32 System Reference

Customizing the Summary

To display the settings for site information and display items:

Select the Summary Page 1 tab.

То	Do This	
Insert an image for inclusion on the	1. Select Load from the Logo section.	
summary	The system displays a list of compatible images located in the root directory of the inserted USB-compatible storage device.	
	2. Select an image.	
	The system displays the image in the Logo section.	
Delete the image	 Select Delete from the Logo section. 	
Display customized text in the summary header	 Use the keyboard to enter text in the text box. 	
Modify the font type, style, or size	1. Select the Font button.	
	2. Select the required format and then select OK .	

To display the settings for section headings and signatures:

Select the Summary Page 2 tab.

То	Do This
Change title of each item in the summary	 Delete the existing text and enter the new titles (up to 48 characters).
Add a name to the signature section in	1. Enter text in the Signature section (up to 32 characters).
the summary	2. Click Add.
Select a name to display in the signature section	Select a name from the drop-down list in the Signature section.
Delete a defined name	Click Delete.
Display adult cardiac reference values on the Summary	■ Select On.

Service

This selection provides the system serial number and software version number, along with password-protected service protocols. The service function allows service personnel to confirm the correct operation of the system. Exiting the Service function returns the system to imaging.

Note: Text in the Siemens Service Software screen is displayed in English only.

Note: When you select **Restore Factory Defaults** from the **Siemens Service Software** screen, the system restores the initial factory default settings for all values except Language and Video Format.

The **Stress Echo** menu item in the system presets displays the **Maintenance** dialog box, which allows you to configure options for the optional Stress Echo feature. Options determine system behavior during acquisition, appearance of loops in the Stress Echo screen, placement of WMS (wall-motion scoring) graphics relative to the loops they represent, type of line used for creating traces, lengths of systolic duration for specific heart rates, and available protocols.

Exiting (quitting) the Stress Echo presets screen returns the system to imaging.

The Stress Echo chapter describes the setup options in detail.

See also: Stress Echo, Chapter A9, Features and Applications Reference

SieScape

Selection	Option(s)	Allows you to
SieScape Scale	On	Automatically display a ruler along a frozen SieScape image.
	Off	
SieScape Size	Best Fit, 1, 2, 3, Full Size	Determine the scale of the SieScape image when frozen.
		Best Fit automatically scales the image to fit the window, based on the selected rotation. Best Fit is the default image size.
		1–3 incrementally scales the image size between Best Fit and Full Size .
		Full Size displays the full (actual) size of the image in the image area.

Contrast Agent Imaging (CAI)

Selection	Option(s)	Allows you to
CAI Mode	On	Activate contrast agent imaging.
	Off	
Extended Clip	5min (20fps)	Specify the duration of clip capture during contrast agent
Duration	6min (15fps)	imaging.
	7min (15fps)	
	8min (10fps)	
	9min (10fps)	
	10min (10fps)	
	15min (6fps)	
	20min (5fps)	

Wireless

You can configure the ultrasound system to connect to a wireless network.

The chapter about the wireless network describes the setup options in detail.

See also: Wireless Network Selections, Chapter 5, System Reference

DICOM

You can configure the ultrasound system and connected devices (such as servers and printers) for DICOM by creating, editing, and activating aliases (DICOM configurations).

The DICOM chapter describes the setup options in detail.

See also: DICOM Connectivity Option, Chapter 3, System Reference

1 - 34 System Reference

DIMAQ Utility

See also: Patient Data Management, Chapter C1, Features and Applications Reference

Selection	Option(s)	Description
Thumbnails		
Columns	1, 2, 3, 4	Selects the number of columns displayed in the Thumbnail screen.
Rows	4 through 12	Selects the number of rows displayed in the Thumbnail screen.
Printer	None	Selects the type of printer or storage device.
	DICOM Print, BW	Note: The PC Printer, USB BW Printer, or USB Color Printer
	DICOM Print, Color	options are available when a corresponding printer is assigned u
	PC Printer	the Printer item on the Presets screen.
	USB BW Printer	
	USB Color Printer	
Active Panel	Thumbnails	Display or arrange the position of the selected tabs.
	PatientInfo	
	Results	

To select the display of a tab:

- To display a panel tab, select the check box next to the name of the tab in the Active Panel list.
- To hide a panel tab, clear the check box next to the name of the tab in the Active Panel list.

To rearrange the order of annotation tabs:

- 1. Select the name of a panel tab in the Active Panel list.
- 2. Click Move Up or Move Down to position the tab.

Clip Capture

Selection	Option(s)	Description
Compression	Low	Select level of image compression and file size.
	Medium	
	High	
Trigger Type	Time Capture	Select clip capture over a period of seconds or heart beat
	Beat Capture	cycles.
	R-Wave Only Capture	
Chronology	Prospective	Retrospective selects a clip of previous images. Prospective
	Retrospective	selects a clip of succeeding images.
Time Trigger	1, 2, 3, 4, 8*, 60*, 120*, (user-defined)*	(Available when Time Capture is selected for Trigger Type .) Specify the duration of each clip in seconds.
	5-10, 15, 20	(Available when Time Capture is selected for Trigger Type .) Specify the duration of each clip in minutes.
Beat Trigger	1, 2, 3, 4, 5*, 6*, 7*, 8*, 9*, 10*, 15*, 20, (user-defined)*	(Available when Beat Capture or R-Wave Only Capture is selected for Trigger Type .) Specify the duration of each clip in heart beat cycles.
R-Wave Delay	0 to 480 in steps of 30 msec	(Available when Beat Capture or R-Wave Only Capture is selected for Trigger Type .) Set the capture point based on a delay beyond the R-Wave.
Acquisition Rate	normal	Defines the frame rate of the acquisition.
	high	

^{*} Available when **Prospective** is selected for **Chronology**.

Network Export

You can verify selection of an existing setup, select another setup, edit an existing setup, or create a new setup for the host or export host using the system presets on the ultrasound system.

The Network Export Function chapter describes the setup options in detail.

See also: Network Export Function, Chapter 4, System Reference

1 - 36 System Reference

Authorization

When you access the **Authorization** screen for the first time, the system prompts you to set up the administrator account.

Note: To change these selections, you must log in with an administrator account, unless otherwise noted.

Selection	Option(s)	Description
Change Password		
Change		Displays a dialog box for changing your current password.
		Note: This selection is available for all user accounts.
Administration		
Password		Displays a login dialog box for an administrator.
Accounts		
(user defined entries)		Displays the defined user accounts when you log in to this screen as an administrator. You can change the settings for the selected user account.
Administrator	on, off	When enabled (selected), assigns administrator privileges to the selected user account.
Disabled	on, off	When enabled (selected), disables the selected user account.
		Note: Use this selection to reactivate a disabled user account.
Reset		Displays a dialog box to reset the password for the selected user account.
Delete		Deletes the selected user account.
New		Displays a dialog box to create a new user account.
CD / DVD		
Import		Retrieves user accounts and passwords from disk media.
Export		Saves user accounts and passwords to disk media.

Selection	Option(s)	Description
Authorization Policy		
Login Required	on, off	When enabled (selected), requires a user account and password to access the DIMAQ integrated workstation. Selecting this option allows you to configure the Authorization Policy section.
		When disabled (cleared) allows all users access to the DIMAQ integrated workstation without requiring a password.
Retry Limits Retry Period	Attempts Seconds	When enabled (selected), causes the user account to be disabled if login attempts exceed the specified limit. An administrator must reactivate the user account.
		1 to 100 attempts in increments of 1
		1 to 5 seconds in increments of 1 second
		Note: The retry limit does not apply to administrator accounts.
Autologout (Screen Saver)	on, off	When enabled (selected), automatically logs out after the user account is inactive for the specified interval of time.
Password Expire	Days	When enabled (selected), requires users to change passwords after the specified expiration period.
		1 to 1,000 days in increments of 1 day
Password Policy	Minimum Characters Lowercase Characters	When selected (enabled), requires new passwords to conform to specified password security restrictions.
	Special Characters	Specifies the minimum number of characters a password must contain.
	Uppercase Characters Numeric Characters	• 0 to 64 characters in increments of 1
Login Screen Message		
Change		Allows you to use the keyboard to customize the login message for the DIMAQ integrated workstation.
		Allows you to use the keyboard to customize the log

1 - 38 System Reference

Archive

Selection	Option(s)	Description
General		
Study Archive History Deletion Policy	Always Delete Study Archive History When Study is Deleted	Select how the study archive is maintained after the study is deleted.
	Allow Delete Study Archive History after Study is Deleted	
	No Delete of Study Archive History	
Show Deleted Studies in Study Screen	on, off	Select this check box to display the studies deleted from the system in the DIMAQ integrated workstation's Study screen.
DVD		
Burn Showcase to DICOM DVD	on, off	Enable or disable automatic storage of the DICOM viewer software program with DICOM-formatted data archived to disk media.

Printer

Selection	Option(s)	Description
Printer		
Install		Installs a USB printer.
Status		Shows the status of the most recently assigned printer.
PC Printer	(drop-down list)	Lists the installed USB printers.
USB BW Printer	(drop-down list)	Lists the installed USB printers.
USB Color Printer	(drop-down list)	Lists the installed USB printers.

Note: To ensure images print correctly, select the name of the USB printer corresponding to each installed printer from the drop-down list.

Customizing OB and Early OB Measurements, Calculations, and Reports

Measurement and Report Preset	Description
Item & Reference Selection, Standard OB	See page 1-40
Item & Reference Selection, Early OB	See page 1-42
Display Item, Standard OB / Early OB	See page 1-42
Growth Analysis Graphs, OB and Early OB	See page 1-43
Standard OB / Early OB User-Defined Formulas: EFW Formula, MA Data, GA Data, Ratio Formula	See page 1-44
Standard OB / Early OB User-Defined Tables: MA Data and GA Data	See page 1-46
User-Defined Label	See page 1-48
Measurement Method	See page 1-23
Customize Keys	See page 1-23
General Configuration	See page 1-25
Comments Library for Report	See page 1-24
Recommendations Library	See page 1-24
Anatomy Assessment	See page 1-26

Item & Reference Selection, Standard OB

2D-Mode, M-Mode, Doppler, Ratio, and Growth Analysis Tabs

This selection allows you to edit the Measurement Item list for 2D-mode, M-mode, Doppler, ratios, and Growth Analysis.

To add or delete measurement items:

- To add a measurement item, roll the trackball to an item in the Selectable Label list and then press the SET key.
- 2. Roll the trackball to the \boldsymbol{Add} button and then press the \boldsymbol{SET} key.
 - The item is placed at the end of the **Measurement Item** list.
- 3. To delete a measurement item, roll the trackball to an item in the **Measurement Item** list and then press the **SET** key.
- 4. Roll the trackball to the **Delete** button and then press the **SET** key.
 - The item is placed at the end of the **Selectable Label** list. Any author assignment to the item is retained.

1 - 40 System Reference

To assign an author to a measurement item:

Note: For 2D-mode, M-mode, ratio, and Growth Analysis only.

- 1. Roll the trackball to the **Author** field to the right of the **Measurement Item** and then press the **SET** key. If the field is blank, no selections are available.
- 2. Roll the trackball to highlight an author and then press the **SET** key. The author is now assigned to the measurement item.

To add all selectable labels assigned to the same author:

Note: For 2D-mode, ratio and Growth Analysis only.

- Under Same Author Label All Selection, roll the trackball to the unlabeled text box and then press the SET key.
- Roll the trackball to highlight an author and then press the SET key.
- Roll the trackball to the Add button and then press the SET key.
 All selectable labels assigned to this author are added to the Measurement Item list.

To move between pages of measurement items:

Note: For 2D-mode only.

- Roll the trackball to the Next button and then press the SET key to access a higher page number.
- Roll the trackball to the Prev button and then press the SET key to access a lower page number.

To select display of single or averaged measurements:

Note: This task cannot be performed with the Ratio and Growth Analysis tab.

- For each measurement item, roll the trackball to the Average button (to display an average of all measurements) or the Direct button (to display the last measurement) and then press the SET key.
- To change all measurement items on the same page, roll the trackball to the Average or Direct button in the Same Parameter Selection All Label section and then press the SET key.
- 3. Access each page of Measurement Items and repeat step 1 or 2.

To reset the Measurement Item list:

Roll the trackball to the **Default** button and then press the **SET** key. Select **Yes** in the displayed confirmation message.

All measurement items and author assignments are returned to factory default settings.

EFW / USMA Tab

Use this tab to select preferred authors for two EFW formulas. Both formulas display in the worksheet and the report. The EFW1 formula displays in the Measured Results when the required measurements have been made. You can also select an average USMA to be returned as measurements are made or specify that one of Hadlock's eleven regression equations be used.

For EFW1, EFW2, and USMA selections, the required measurements are listed in the associated Based Label box.

To make an EFW or USMA selection:

- Roll the trackball to the appropriate Author field and then press the SET key.
 The system displays a pull-down menu of available authors or equations.
- 2. Roll the trackball to highlight an author or equation and then press the SET key.

Item & Reference Selection, Early OB

The Item & Reference Selections for Early OB parallel those for Standard OB. The **Ratio** tab has no system-defined ratios, but shares five user-defined ratio labels with Standard OB. The **EFW / USMA** tab is the same as for Standard OB.

Display Item, Standard OB / Early OB

The Standard OB / Early OB **Display Item** screen allows you to designate items to include on the measurement screen and in the worksheet and patient report.

Selection	Option(s)	Allows you to
Measurement Screen		
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.
Vertical Display of Doppler Measurement Results	Systole Diastole S / D RI PI	Select each check box to display the selection as a permanent, labeled item in the Measured Results for Doppler. De-select the check box to not display the selection in the Measured Results.
Report / Worksheet		
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.
Display of Doppler Measurement Results	Systole Diastole S / D RI PI	Select each check box to display the selection as an item in the Doppler section of the report. De-select the check box to not display the selection in the Doppler section of the report.
Performing MD	on, off	Select this check box to include at the bottom of the report page the Performing MD entered in the patient data form.
Referring MD	on, off	Select this check box to include at the bottom of the report page the Referring MD name entered in the patient data form.

1 - 42 System Reference

Selection	Option(s)	Allows you to
HC / AC Measurement		
HC with BPD / OFD Measurement	on, off	Automatically derive values for BPD and OFD from the HC Measurement.
AC with ATD / ASD Measurement	on, off	Automatically derive values for ATD and ASD from the AC Measurement.
Display SD / Growth Percentile		
Display SD / Growth	ON	Enable the display of a standard deviation for each measurement:
Percentile	OFF	ON — Displays the standard deviation (SD).
		OFF — Displays the gestational age instead of the SD.
Notice of estimated age	OFF	Specify the upper limit of the range for the standard deviation (SD).
	1.5SD	
	2.0SD	
	2.5SD	
	3.0SD	
Auto OB		
European Auto OB		
BPD Outer to Outer	on, off	When selected (checked), enables BPD outer-to-outer measureme

Growth Analysis Graphs, OB and Early OB

Use this selection to set up growth curves for OB and Early OB exams.

Selection	Option(s)	Allows you to
Link Files	Manual	Link files in the measurement report manually or automatically.
	Automatic	
Customize Growth Analysis Graphs		
Graph Format	Single Quad	Select Single to display one graph to a patient report page. Select Quad to display four graphs to a page. With either option, each graph displays the growth curve for a different, user-selectable growth parameter according to a user-selectable reference (author).
Graph Display	Current Previous	Select Current to display measurement values from the current exam only. Select Previous to display values from prior OB exams. Previous requires that the exams are available on the hard drive or CD/DVD and are linked to the current study. Select both check boxes to plot current measured results with previous measurements for a parameter on a single graph.
Graph Grid	on, off	Display vertical and horizontal lines on the graph.
Display All Measured Label	on, off	Select this check box to display all measurement values from the current exam on the Obstetrical Growth Curve Graph page of the patient report when Single is selected. De-select this check box to display only the selected measurement value.

Standard OB / Early OB User-Defined Formulas

Access a Standard OB / Early OB formula with one of the following selections from the Standard OB or Early OB Measurement and Report screen:

- User-Defined EFW Formula
- User-Defined Menstrual Age

The following procedures abbreviate menstrual age as "MA."

User-Defined Growth Analysis

The following procedures abbreviate growth analysis as "GA."

User-Defined Ratio Formula

To access a formula screen:

- 1. Roll the trackball to any of these choices and then press the SET key.
- If the system displays a confirmation window, roll the trackball to the OK button and then press the SET key.
- For MA Data and GA Data, roll the trackball to the Formula button under Data Type and then press the SET key.

The resulting formula screens are very similar. Basic formula-building rules apply to EFW, Ratio, MA Data, and GA Data formulas. Use the following procedure for all four formula types.

To create a user-defined formula:

- 1. Roll the trackball to the drop-down box at the upper left corner and then press the **SET** key. The system displays a list of numbered User-Defined formulas.
- Roll the trackball to highlight one of the User-Defined formula numbers and then press the SET key.
- In the MA Data and GA Data screens, roll the trackball to the Known Variable Label field and then press the SET key. In the Ratio Formula screen, roll the trackball to the Label Name field and then press the SET key.

The system displays a list of labels.

- 4. For these three screens, roll the trackball to highlight a label and then press the SET key.
- For all screens, roll the trackball to the Reference (Author) field and then press the SET key.
- Roll the trackball to highlight an author or use the keyboard to enter the name of an author and then press the SET key.
- For all screens, roll the trackball to the first field in the Range section and then press the SET key.

Note: The **Range** section is not available for the MA Data screen when you select the Formula button under Data Type.

1 - 44 System Reference

- 8. For the GA Data screen, enter the lower limit for the measurement range in millimeters and then use the trackball and **SET** key to move the cursor to enter millimeters for the upper limit
- 9. For all screens, use the trackball and **SET** key to advance to the date area.
- 10. Using the trackball and SET key between boxes, enter the week and day for the lower limit for the age range in the boxes at the left and the week and day for the upper limit in the boxes at the right.
- 11. For a Ratio formula screen, enter the minimum and maximum values for the ratio between the parentheses.
- In the GA Data formula screen, roll the trackball to the SD Type field and then press the SET key.

A list of standard deviation types displays.

- 13. Roll the trackball to highlight one of the SD types and then press the SET key.
- 14. In the Result Unit section of the MA Data formula screen, roll the trackball to the **Days** button for a standard deviations formula or the **Weeks** button for a standard formula and then press the **SET** key.
- 15. For MA Data, GA Data, and EFW formula screens, roll the trackball to the upper right corner to select a conventional formula or a standard deviation limits formula.
- 16. Enter your formula in the field to the right of the equals sign (=). Use the keyboard to enter numbers and any of the operators listed in the **Operation** box at the bottom of the screen. Use the trackball and the **SET** key to select constants (see below) and variables (or values). Example: "A"*"LOG"("BPD") + "COS"("ATD") 1.8327

Note: You can use parentheses, but do not use spaces to separate elements in your formula. Do not delete any of the quote marks entered by the system. You can enter up to 64 characters in this field. To conserve space, you can assign a letter value to a constant and enter the letter into your formula instead of the full constant.

To define a constant for a user-defined formula:

Constant	
Label	Value
Α	1.118303
В	K

 Roll the trackball to the Value column parallel with the label letter to which you want to assign the value and then press the SET key.

The system displays an entry field next to the label letter.

- 2. Enter a numeric value of up to 60 characters, including a decimal point if required and then press the **Enter** key on the keyboard.
- To insert a constant into a formula, roll the trackball to position the pointer on the appropriate letter in the Label column and then press the SET key.

The system inserts the label letter into the formula.

To delete a user-defined formula:

- Roll the trackball to highlight one of the User-Defined numbers in the upper left of the screen.
- 2. Roll the trackball to the **Delete Current Reference** button and then press the **SET** key.

To exit a user-defined formula screen:

 To exit and save the formula, roll the trackball to the Save button and then press the SET key.

The system informs you if there is a syntax or other error in the formula. If necessary, resolve the problem and exit again.

To exit and not save the formula, roll the trackball to the **Previous** button and then press the **SET** key.

The system queries you to save changes by selecting $\bf Yes$ or discard changes by selecting $\bf No$.

Standard OB / Early OB User-Defined Tables

Access a Standard OB / Early OB table with one of the following selections from the Standard OB or Early OB Measurement and Report screen:

User-Defined Menstrual Age

The following procedures abbreviate menstrual age as "MA."

User-Defined Growth Analysis

The following procedures abbreviate growth analysis as "GA."

To access a table screen:

- 1. Roll the trackball to one of these choices and then press the SET key.
- If the system displays a confirmation window, roll the trackball to the OK button and then press the SET key.
- 3. Roll the trackball to the Table button under Data Type and then press the SET key.

The resulting table screens are very similar for MA Data and GA Data. Basic table-building rules apply to both types. Use the following procedure for both table types.

To create a user-defined table:

- 1. Roll the trackball to the drop-down box at the upper left corner and then press the **SET** key. The system displays a list of numbered User-Defined tables.
- Roll the trackball to highlight one of the User-Defined table numbers and then press the SET key.
- Roll the trackball to the Known Variable Label field and then press the SET key.
 The system displays a list of labels.

1 - 46 System Reference

- 4. Roll the trackball to highlight a label and then press the **SET** key.
- 5. Roll the trackball to the **Reference (Author)** field and then press the **SET** key.
- 6. Roll the trackball to highlight an author or use the keyboard to enter the name of an author and then press the **SET** key.
- 7. Roll the trackball to the first field in the Range section and then press the SET key.
- 8. Enter the lower limit for the measurement range in millimeters and then use the trackball and **SET** key to move the cursor and enter the upper limit.
- 9. Use the trackball and **SET** key to advance to the date area.
- 10. Using the trackball and SET key to move between boxes, enter the week and day for the lower limit for the age range in the boxes at the left and the week and day for the upper limit in the boxes at the right.
- In the GA Data table screen, roll the trackball to the SD Type field and then press the SET key.
 - A list of standard deviation types displays.
- 12. Roll the trackball to highlight one of the SD types and then press the SET key.
- 13. In the MA Data table screen, your result units of weeks and days are built into the table, so leave the default selection for the **Result Unit** field.
- 14. Create your table in the box. Use the trackball and **SET** key to move to each new field. Create additional lines by using the scroll bar.

The first line should contain the lower limit for the variable value and the week and day for the lower limit of the date range. The last line should contain the upper limits. The table must contain an entry for every variable value between the upper and lower limits in order for the system to display a measured value in the worksheet and the patient report. For example, if you specify a range from 10.0 to 11.0, you must create a line entry for 10.0, 10.1, 10.2...11.0. If you only create entries for 10.0, 10.2, 10.4...11.0, a measured value of 10.3 will not display.

Note: Measurements corresponding to table values that are outside the range will not be recognized. A measurement that is within the range but less than the lowest table value will only provide an MA or GA value equivalent to the lowest value. A measurement that is within the range but greater than the highest table value will only provide an MA or GA value equivalent to the highest value.

- 15. In the **Value** field, enter the size in mm that indicates a specific age.
- 16. In the Weeks and Days field, enter the age.
- 17. For MA tables, enter a number in the **SD Limits** field. The system converts the number to days for you, such as +/- 2 d.
 - For GA tables, enter lower and upper limits for the value in the **Lo Limit** and **Up Limit** fields.
- 18. To clear contents of a cell in the table, position the cursor in the cell and then select the **Clear Cell** button.

- 19. To clear contents of an entire line in the table, position the cursor in the line and then select the **Clear Line** button.
- 20. To undo the most recent change in the table, select the **Undo** button.

To delete a user-defined table:

- Roll the trackball to highlight one of the user-defined numbers in the upper left of the screen.
- 2. Roll the trackball to the **Delete Current Reference** button and then press the **SET** key.

To exit a user-defined table screen:

- To exit and save the table, roll the trackball to the Save button and then press the SET key.
 - The system informs you if there is an error in the table. Resolve the problem and exit again.
- To exit and not save the table, roll the trackball to the **Previous** button and then press the SET key.
 - The system queries you to save changes by selecting \mathbf{Yes} or discard changes by selecting \mathbf{No} .

User-Defined Label, OB and Early OB

The OB and Early OB exams share five user-defined labels for 2D-mode and another five user-defined labels for Doppler. Access a user-defined label by selecting **User-Defined Label** from the **Standard OB** or **Early OB Measurement and Report** screen.

To create a user-defined label:

- Roll the trackball to the drop-down menu at the upper left corner of the 2D-mode or Doppler section on the **User Defined Label** screen and then press the **SET** key.
 A list of five user-defined numbers displays.
- 2. Roll the trackball to highlight one of the user-defined numbers and then press the SET key.
- 3. Roll the trackball to the **Label Name** field and then press the **SET** key.
- 4. Use the keyboard to type in a label name of up to eight characters.
- For 2D-mode labels, roll the trackball to the Measurement Method field and then press the SET key.
 - A list of measurement methods displays.
- 6. Roll the trackball to highlight a method and then press the **SET** key. The system assigns the appropriate unit of measure for the method.
- 7. For additional 2D-mode labels, repeat steps 2 through 6.
- 8. For Doppler labels, use steps 2 through 4 as required.

To delete a user-defined label:

- Roll the trackball to the drop-down menu at the upper left corner of the 2D-mode or Doppler section on the **User Defined Label** screen and then press the **SET** key.
 A list of five user-defined numbers displays.
- 2. Roll the trackball to highlight one of the user-defined numbers and then press the SET key.
- Roll the trackball to the Delete Current 2D-Mode Label or the Delete Current Doppler Label button and then press the SET key.

1 - 48 System Reference

Customizing Vascular Measurements, Calculations, and Reports

Measurement and Report Preset	Description
Display Item, C-Vascular	See page 1-49
Display Item, P-Vascular	See page 1-50
Display Item, Venous	See page 1-50
Measurement Method	See page 1-23
Customize Keys	See page 1-23
Measurement Order	See page 1-27
User-Defined Label	See page 1-29
General Configuration	See page 1-25
Comments Library for Report	See page 1-24
Recommendations Library	See page 1-24
Anatomy Assessment	See page 1-26

Display Item — Cerebrovascular (C-Vascular)

Selection	Option(s)	Allows you to
Measurement Screen		
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.
Vertical Display of Doppler Measurement Results	Systole Diastole S / D RI PI	Select each check box to display the selection as a permanent, labeled item in the Measured Results for Doppler. De-select the check box to not display the selection in the Measured Results.
Report		
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.
Display of Measurement Results	%Stenosis Systole Diastole S / D RI PI	Select each check box to display the selection as an item in the Doppler section of the report. De-select a check box to not display a selection in the Doppler section of the report.
Calculation Label Display	ICA / CCA(S) ICA / CCA(D)	Specify calculated ratios to display in the report.
Performing MD	on, off	Select this check box to include at the bottom of the report page the Performing MD entered in the Patient Data form.
Referring MD	on, off	Select this check box to include at the bottom of the report page the Referring MD name entered in the Patient Data form.

Display Item — Peripheral Vascular (P-Vascular)

Selection	Option(s)	Allows you to
Measurement Screen		
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.
Vertical Display of	Peak Systole	Select each check box to display the selection as a permanent,
Doppler Measurement Results	RI	labeled item in the Measured Results for Doppler. De-select the check box to not display the selection in the Measured Results.
Results	PI	check box to not display the selection in the Measured Results.
Report		
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.
Display of	Peak Systole	Select each check box to display the selection as an item in the
Measurement Results	RI	Doppler section of the report. De-select a check box to not display
	PI	a selection in the Doppler section of the report.
Performing MD	on, off	Select this check box to include at the bottom of the report page the Performing MD entered in the patient data form.
Referring MD	on, off	Select this check box to include at the bottom of the report page the Referring MD name entered in the Patient Data form.

Display Item — Venous

The **Display Item** screen for the Venous exam presents two columns of entries: **Selectable Label** on the left and **Report Label Order** on the right. Add labels from left to right, or delete labels from right to left.

To add labels:

- 1. Roll the trackball to a selectable label on the left and then press the **SET** key. The system highlights the label.
- Roll the trackball to the Add button and then press the SET key.
 The system moves the label to the bottom of the Report Label Order list on the right.

To delete labels:

 Roll the trackball to a label in the Report Label Order list on the right and then press the SET key.

The system highlights the label.

2. Roll the trackball to the **Delete** button and then press the **SET** key.

The system moves the label to the bottom of the **Selectable Label** list on the left.

1 - 50 System Reference

To rearrange labels:

- Roll the trackball to one of the labels in the Report Label Order list on the right and then
 press the SET key.
 - The system highlights the label.
- 2. Roll the trackball to the **Move Up** or **Move Down** button and then press the **SET** key. The system moves the label up or down one space in the list.
- 3. Repeat steps 1 and 2 as required to create a restructured Report Label Order list.

To reset labels back to factory default positions:

- Roll the trackball to the **Default** button and then press the **SET** key.
 The system prompts you to confirm your choice.
- 2. Roll the trackball to the **OK** button and then press the **SET** key to continue.

The **Display Item** screen for the Venous exam also provides the following selections:

Selection	Option(s)	Allows you to
Performing MD	on, off	Select this check box to include at the bottom of the report page the Performing MD entered in the Patient Data form.
Referring MD	on, off	Select this check box to include at the bottom of the report page the Referring MD name entered in the Patient Data form.

Customizing Gynecology Measurements, Calculations, and Reports

Measurement and Report Preset	Description
Display Item	See page 1-52
Report Tab	See page 1-31
Measurement Method	See page 1-23
Customize Keys	See page 1-23
Measurement Order	See page 1-27
User-Defined Label	See page 1-29
General Configuration	See page 1-25
Comments Library for Report	See page 1-24
Recommendations Library	See page 1-24
Anatomy Assessment	See page 1-26

Display Item — Gynecology

The Gynecology **Display Item** allows you to designate items to include on the measurement screen and in the patient report.

Selection	Option(s)	Allows you to		
Measurement Screen				
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.		
Vertical Display of	Systole	Select each check box to display the selection as a permanent,		
Doppler Measurement Results	Diastole	labeled item in the Measured Results for Doppler. De-select the check box to not display the selection in the Measured Results.		
Results	S/D	box to not display the selection in the Measured Results.		
	RI			
	PI			
Report				
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurement values in the Measured Results. De-select the check box to display all labels on the Measurement Menu in the Measured Results.		
Display of Doppler	Systole	Select each check box to display the selection as an item in the		
Measurement Results	Diastole	Doppler section of the report. De-select a check box to not display a selection in the Doppler section of the report.		
	S/D	Selection in the Doppler Section of the report.		
	RI			
	PI			
Performing MD	on, off	Select this check box to include at the bottom of the report page the Performing MD entered in the Patient Data form.		
Referring MD	on, off	Select this check box to include at the bottom of the report page the Referring MD name entered in the Patient Data form.		

1 - 52 System Reference

Customizing Cardiac Measurements, Calculations, and Reports

All customization for Cardiac exams is also available for Ped Echo exams. The customized settings for the Ped Echo exam are independent of the Cardiac exam.

Note: When you customize measurements and calculations for use with the Cardiac exam, the customization also applies to the TEE exam.

Measurement and Report Preset	Description
Measurement Method	See page 1-23
Customize Keys	See page 1-23
General Configuration	See page 1-25
Measurement Order	See page 1-27
Display Item	See page 1-56
User-Defined Label	See page 1-57
Comments Library for Report	See page 1-24
Recommendations Library	See page 1-24
Anatomy Assessment	See page 1-26

Measurement Order — Cardiac

Use the **Heading** tab to select and reorder headings (measurement types).

Note: Only the measurement types in the **Measurement Order** list on the **Heading** tab display on the **Display Item** screen.

Use the **Label** tab to further customize the contents (available labels) for each heading.

Heading Tab

Note: Only the Measurement types in the **Measurement Order** list on the **Heading** tab display in the **Heading** field on the **Label** tab.

То	Do This		
Add a heading	Select the required imaging mode from the Mode drop-down list.		
	2. Select a measurement type from the Selectable Heading list.		
	3. Click Add.		
	The selection is relocated to the bottom of the Measurement Order list.		
Delete a heading	Select the required imaging mode from the Mode drop-down list,		
	2. Select a measurement type from the Measurement Order list.		
	3. Click Delete .		
	The selection is relocated to the bottom of the Selectable Heading list.		
Rearrange headings	Select the required imaging mode from the Mode drop-down list.		
	2. Select a measurement type from the Measurement Order list.		
	3. Click Move Up or Move Down.		
	The selection moves up or down one position in the list.		

Label Tab

The **Label** tab allows you to customize measurement order for guided and non-guided Cardiac measurements.

Customizing Guided Measurements

The Cubed, Teichholz, and Gibson selections are guided measurements for assessing left ventricular function.

The guided measurements present workflow patterns. Each pattern dictates a sequence of measurements. Select a pattern that best matches your workflow. Pattern 1 for each of the three guided measurement types includes all measurement labels. These measurements appear in the **Measurement Order** column on the right. Other patterns present the same sequence but with fewer measurements. Measurements not included in a pattern are listed in the **Selectable Label** column on the left. Measurements cannot be added, deleted, or rearranged for patterns.

To select a pattern for a Cardiac guided measurement type:

Note: Only the measurement types in the **Measurement Order** list on the **Heading** tab display in the **Heading** field on the **Label** tab.

- 1. Select the Label tab.
- Select a measurement type from the Heading field.
 - Cubed(2D)
 - Teichholz(2D)
 - Gibson(2D)
 - LV/Cubed(M)
 - LV/Teich(M)
 - LV/Gibson(M)
- 3. Select a sequence of measurements (pattern) from the **Pattern** field.

The **Measurement Order** column displays the required measurement labels and the order of display for the selected pattern.

4. Click Save.

1 - 54 System Reference

Customizing Non-Guided Measurements

Note: Only the measurement types in the Measurement Order list on the Heading tab display in the Heading field on the Label tab.

То	Do This
Add a label	1. Select the Label tab.
	2. Select a measurement type from the Heading drop-down list.
	3. Select a label from the Selectable Label list.
	4. Click Add.
	The label is relocated to the bottom of the Measurement Order list.
Delete a label	1. Select the Label tab.
	2. Select a measurement type from the Heading drop-down list.
	3. Select a label from the Measurement Order list.
	4. Click Add.
	The label is relocated to the bottom of the Selectable Label list.
Rearrange labels	1. Select the Label tab.
	2. Select a measurement type from the Heading drop-down list.
	3. Select a label from the Measurement Order list.
	4. Click Move Up or Move Down.
	The label moves up or down one position in the list.

Display Item — Cardiac

All customization for Cardiac exams is also available for Ped Echo exams. The customized settings for the Ped Echo exam are independent of the Cardiac exam.

Note: When you customize measurements and calculations for use with the Cardiac exam, the customization also applies to the TEE exam.

The Cardiac **Display Item** allows you to designate items to include on the measurement screen and in the patient report.

Selection	Option(s)	Allows you to		
General				
Default Measurement Title	2D-Mode M-Mode	Select which measu mode is entered.	rement type will be activ	ve when an imaging
	Doppler	,	surement types in the N display on the Display	leasurement Order list Item screen.
		2D-Mode measurement types: None Simpson BP Simpson SP Mod Simpson Single Plane Bi-Plane Bi-Plane Bullet Cubed(2D) Teichholz(2D) Gibson(2D) Mitral Valve AV / LA Aortic Valve Pulmonary Valve RV LV PISA(MR) PISA(MR) PISA(MS) LV Mass T-E LV Mass A-L LA Vol (A-L) LA Vol (Simp) RA Vol (A-L) RA Vol (Simp) RA Vol (Simp)	M-Mode measurement types: None LV / Cubed(M) LV / Teich(M) LV / Gibson(M) Mitral Valve(M) RV / LA(M) RV(M)	Doppler measurement types None Mitral Valve Aortic Valve Tricuspid Valve Pulmonary Vein AR TR PR MR PISA(MR) PISA(MS) DTI Qp/Qs Tei Index
Data Averaging	Direct Average	Specify whether to display the last measurement or an average of the measurements.		
HR Measurement	ECG	Select the method for	or measuring heart rate.	
Method	Doppler / M-mode			

1 - 56 System Reference

Selection	Option(s)	Allows you to	
Display of	Measurement Type	Activate either the last-used measurement type or the system-defaul	
Measurement Labels	Last Used	measurement type when you exit and then re-enter the measurement function during a Cardiac, Ped Echo, or TEE exam.	
Display AOLA			
AOd/LAs	on, off	Enable display of the label.	
LAs/AOd	on, off	Enable display of the label.	
Default RAP	0mmHg	Select the default value for the Right Atrial Pressure (RAP) in the	
	5mmHg	Measurement Menu.	
	10mmHg	You can change the value when the Cardiac measurement function	
	15mmHg	is active.	
	20mmHg		
	25mmHg		
Report			
Performing MD	on, off	Select this check box to include at the bottom of the report page the Performing MD entered in the Patient Data form.	
Referring MD	on, off	Select this check box to include at the bottom of the report page the Referring MD name entered in the Patient Data form.	

User-Defined Label — Cardiac

Note: You can also customize the measurements and calculations for use with the **Ped Echo** exam. The customization of the **Ped Echo** exam is independent of the customization of the **Cardiac** exam.

The Cardiac User-Defined Label item allows you to create up to two measurement types to include on the measurement screen and in the patient report. Each measurement type can have up to six mode-specific measurement labels (up to two labels per imaging mode: 2D-Mode, M-Mode, and Doppler).

Selection	Option(s)	Allows you to
User-Defined1,		
User-Defined2		
Heading Name		Enter up to eight characters to name the user-defined measurement type.
Label		
2D-Mode 1	Distance	Enter up to three characters to name a 2D-mode measurement label
2D-Mode 2	Area	and select the default measurement method.
	Disk	
M-Mode 1	Distance	Enter up to three characters to name an M-mode measurement label
M-Mode 2	Time	and select the default measurement method.
	Slope	
Doppler 1	Velocity	Enter up to three characters to name a Doppler measurement label
Doppler 2	Time	and select the default measurement method.
	RI	
	Acceleration	
	PI Trace	
	VTI	

To access the User-Defined Label screen for Cardiac exams:

- Press the Presets key on the keyboard to display the Presets screen and then select M & R Configuration on the left of the screen.
- Select Cardiac from the drop-down menu in the Measurement and Report section of the screen.
- Select the User-Defined Label button.

The system displays the User-Defined Label screen for Cardiac exams.

To create a user-defined Cardiac measurement type:

- 1. Access the **User-Defined Label** screen for Cardiac exams.
- 2. Select the User-Defined 1 tab or the User-Defined 2 tab.
- Roll the trackball to the **Heading Name** field and then press the **SET** key on the control panel.
- 4. Use the keyboard to enter up to eight characters to name the Cardiac measurement type.
- 5. For each measurement label:
 - a. In the Label section, roll the trackball to a blank name field for the required imaging mode and then press the SET key on the control panel.
 - b. Use the keyboard to enter up to three characters to name the measurement label.
 - c. Roll the trackball to the drop-down menu located to the right of the name, press the SET key to list the mode-specific measurement methods and then use the trackball and SET key to select a measurement method.
- Roll the trackball to the Save button at the bottom of the screen and then press the SET key on the control panel.

The system saves the user-defined measurement type.

7. To exit the user-defined label screen, select the **Previous** button.

To delete a user-defined Cardiac measurement type:

- 1. Access the User-Defined Label screen for Cardiac exams.
- 2. Select the User-Defined 1 tab or the User-Defined 2 tab.
- Roll the trackball to the **Delete Label** button and then press the **SET** key on the control panel.

The system clears all fields.

Roll the trackball to the Save button at the bottom of the screen and then press the SET key.

The system deletes the user-defined measurement type.

5. To exit the user-defined label screen, select the **Previous** button.

1 - 58 System Reference

To delete a measurement label within a user-defined Cardiac measurement type:

- 1. Access the User-Defined Label screen for Cardiac exams.
- 2. Select the User-Defined 1 tab or the User-Defined 2 tab.
- Roll the trackball to the name of the measurement label and then press the SET key on the control panel.
- 4. Use the backspace key to remove the name of the measurement label.
- 5. Roll the trackball to the **Save** button at the bottom of the screen and then press the **SET** key.

The system deletes the measurement label.

6. To exit the user-defined label screen, select the **Previous** button.

Customizing Emergency Medicine Measurements, Calculations, and Reports

Measurement and Report Preset	Description
Measurement Method	See page 1-23
Customize Keys	See page 1-23
General Configuration	See page 1-25
Report Tab	See page 1-31
Calculation Item	See page 1-59
Display Item	See page 1-28
Comments Library for Report	See page 1-24
Recommendations Library	See page 1-24
Anatomy Assessment	See page 1-26

Calculation Item — Emergency Medicine

Use this selection to select a reference author for OB measurement labels and one or two planes for measuring bladder volume.

Option(s)	Allows you to		
BPD	(Listing of measurement labels for assignment of a reference		
CRL	[author].)		
GS			
(Drop-down menu of authors)	Assign a reference [author] to the corresponding measurement label.		
on, off	Use measurements from the transverse plane.		
on, off	Use measurements from the sagittal plane.		
	BPD CRL GS (Drop-down menu of authors) on, off		

To assign an OB reference author:

For each measurement label, roll the trackball to the arrow in the Author field and then
press the SET key.

The system displays a pull-down menu of reference authors for the measurement label.

2. Roll the trackball to highlight an author and then press the **SET** key.

The system uses the selected reference author to determine an estimated menstrual age for measured results.

To reset labels back to factory default positions:

- 1. Roll the trackball to the **Default** button and then press the **SET** key. The system prompts you to confirm your choice.
- 2. Roll the trackball to the **OK** button and then press the **SET** key to continue.

To select planes for the Bladder Volume calculation:

Roll the trackball to select one or both plane selections and then press the SET key.

Customizing Fetal Echo Measurements, Calculations, and Reports

Measurement and Report Preset	Description
Measurement Method	See page 1-23
Customize Keys	See page 1-23
General Configuration	See page 1-25
Display Item	See page 1-60
Measurement Order	See page 1-27
Comments Library for Report	See page 1-24
Recommendations Library	See page 1-24
Anatomy Assessment	See page 1-26

Display Item — Fetal Echo

Use this selection to control display of various items on the measurement screen and in the patient report. Also the **Display Item** screen for the Fetal Echo exam presents two columns of entries: **Selectable Label** on the left and **Report Label Order** on the right. Add labels from left to right, or delete labels from right to left.

Selection	Option(s)	Allows you to	
Measurement Screen			
Abbreviated Display of Results	on, off	Select this check box to display only labels with assigned measurer values in the Measured Results. De-select the check box to display labels on the Measurement Menu in the Measured Results.	
Report			
Performing MD	on, off	Select this check box to include the Performing MD entered in the Patient Data form at the bottom of the report page.	
Referring MD	on, off	Select this check box to include the Referring MD name entered in the Patient Data form at the bottom of the report page.	

1 - 60 System Reference

To add labels:

- 1. Roll the trackball to a selectable label on the left and then press the **SET** key. The system highlights the label.
- Roll the trackball to the Add button and then press the SET key.
 The system moves the label to the bottom of the Report Label Order list on the right.

To delete labels:

 Roll the trackball to a label in the Report Label Order list on the right and then press the SET key.

The system highlights the label.

Roll the trackball to the **Delete** button and then press the **SET** key.The system moves the label to the bottom of the **Selectable Label** list on the left.

To rearrange labels:

Roll the trackball to one of the labels in the Report Label Order list on the right and then
press the SET key.

The system highlights the label.

- 2. Roll the trackball to the **Move Up** or **Move Down** button and then press the **SET** key. The system moves the label up or down one space in the list.
- 3. Repeat steps 1 and 2 as required to create a restructured Report Label Order list.

To reset labels back to factory default positions:

- 1. Roll the trackball to the **Default** button and then press the **SET** key. The system prompts you to confirm your choice.
- 2. Roll the trackball to the **OK** button and then press the **SET** key to continue.

1 System Presets

1 - 62 System Reference

2 Documentation Devices

Documentation and Storage Devices	3
Using the CD/DVD Drive	3
Storing and Retrieving System Presets and QuickSets	4
File Type Descriptions	
Printers	7
Report Printers	7
Manufacturers of Medically-Approved Isolation Transformers	
Mitigating the Risk of Connecting a Report Printer	9
Patient Environment	9
Connecting and Installing Report Printers	10
Video Recorders	13
Video Communication Setup	13

2 Documentation Devices

2 - 2 System Reference

Documentation and Storage Devices

Controls and keys located on the ultrasound system are used to transfer images and patient reports to a documentation device or a disk drive.

- Documentation devices include a black and white printer, a color (video) printer, and a video recorder.
- Storage devices include a CD/DVD drive.

Using the CD/DVD Drive

To insert a disk into the CD/DVD drive on the ultrasound system:

- 1. Press the Patient Browser key on the keyboard to display the Study screen.
- If the system displays the Image screen, then select the Study Screen button to display the Study screen.
- 3. Select the **Eject** button in the **Export/Import** section of the Study screen. The system ejects the CD/DVD tray.
- 4. Place the disk onto the CD/DVD tray.
- 5. Select the **Load** button in the **Export/Import** section of the Study screen.

The system closes the CD/DVD tray and reads the disk.

Note: If the CD/DVD **Status** displays **Unknown**, select **Load** again and wait until the status displays **Ready**.

To eject an inserted CD/DVD:

- 1. Press the Patient Browser key on the keyboard to display the Study screen.
- If the system displays the Image screen, then select the Study Screen button to display the Study screen.
- 3. Select the **Eject** button in the **Export/Import** section of the Study screen.

The system ejects the CD/DVD tray.

- 4. Remove the disk from the CD/DVD tray.
- 5. Select the Load button in the Export/Import section of the Study screen.

The system closes the CD/DVD tray.

Storing and Retrieving System Presets and QuickSets

You can save user-defined QuickSets and system presets to a CD/DVD or a USB memory device and then retrieve the files as needed.

See also: File Type Descriptions, p. 2-6

Note: Text in the Siemens Service Software screen is displayed in English only.

To display the Backup/Restore screen:

- 1. Press the **Presets** key on the keyboard to display the **Presets** screen.
- 2. Select Service on the left of the screen.
- 3. Select the **Service** button to display the **Siemens Service Software** screen.
- Delete none from the Password box and then select OK to display the user-configurable options.
- 5. Select Backup & Restore.

The system displays the Backup/Restore screen.

To save system presets and/or QuickSets to a CD/DVD or a USB memory device:

- Insert a blank disk to the CD/DVD drive or connect the USB memory device to the USB port.
- Select Backup from the Select drop-down list.
 - The system displays the QuickSet Utility dialog box.
- 3. Select the check box for each required QuickSet and then select Next.
 - The system displays the Backup dialog box.
- 4. Select **CD/DVD** or **USB** to backup the user-defined data. If **USB** is selected, you can select the appropriate USB drive from the drop-down list.
- Select the check box for each required file type and then select **Backup** in the Backup dialog box.

 $\textbf{Note:} \ \textbf{If a disk is absent, the system displays a message requesting insertion of a disk.}$

The system displays a completion message when the process is complete.

- 6. Select OK.
- 7. To redisplay the image screen:
 - a. Select Home on the Backup/Restore screen.
 - b. Select Exit on the Siemens Service Software screen to display the Presets screen.
 - c. Select Cancel.

2 - 4 System Reference

To retrieve system presets and/or QuickSets from a CD/DVD or a USB memory device:

Note: When you retrieve system presets, the system overwrites the related settings in the system presets. When you retrieve a QuickSet, the system overwrites any existing QuickSet that has the same name.

- 1. Insert the disk or connect the USB memory device that contains the backup data.
- 2. Display the Backup/Restore screen.
- 3. Select Restore.

The system displays a message requesting confirmation that the backup disk is inserted.

- 4. Select **OK** to display the Restore dialog box.
- Select CD/DVD or USB to restore user-defined data. You can select the appropriate USB drive from the drop-down list.
- Select the check box for each required file type and then select **Restore** to begin the restore process.
- 7. Select **OK** when the completion message displays.

The system displays the QuickSet Utility dialog box.

- 8. To delete all QuickSets stored on the system and add new QuickSets:
 - a. Select the Clean QuickSet(s) on System check box in the Options section.
 - b. Select the required QuickSets in the QuickSets Removable Media section.
 - c. Select the **Restore** button.

The system deletes all QuickSets stored on the system and restores the selected QuickSet(s) from the disk media.

- 9. To add selected QuickSets to the system without deleting existing QuickSets:
 - a. Select the required QuickSets in the QuickSets Removable Media section.
 - b. Select the Restore button.

The restored QuickSets display in the QuickSets - System section.

10. To exit the QuickSet Utility dialog box, select Close.

The system displays a message that power must be cycled to the system for completion of the operation.

11. Select **OK** to restart the ultrasound system.

File Type Descriptions

Each file type saves a specific set of system settings.

Note: The listed file types correspond to the information stored on the system or inserted CD/DVD. For example, the **Service Image** file type is listed in the **Backup** dialog box only when service images are stored on the system.

File Type	Settings Saved
M&R User Defined	Settings from the Measurement & Report menu item in the system presets.
Quickset	All QuickSets stored on the ultrasound system's hard disk and the default setting (exam type or QuickSet) specified for each transducer.
Service Image	Service images from the Service menu item in the system presets.
Service Log	Service logs from the Service menu item in the system presets.
Service Test Report	Service test reports from the Service menu item in the system presets.
System Preset	Settings from the system presets (excludes Service information and settings accessed through Measurement & Report).
License Info	Licenses for software-based options.
User Defined Map	Settings from the Modify Map screen.

2 - 6 System Reference

Printers

You can print images from a current examination, a patient report, CINE data, or an image retrieved from a disk.

Note: Refer to the manufacturer's user manual for proper handling and operating instructions of the printer installed on your ultrasound system.

Report Printers



▲ WARNING: Accessory equipment connected to the analog and digital interfaces must be certified according to the respective EN and IEC standards (e.g., EN 60950 and IEC 60950 for data processing equipment and EN 60601-1 and IEC 60601-1 for medical equipment). Furthermore, all configurations shall comply with the system standard EN 60601-1-1 and IEC 60601-1-1. Anyone who connects additional equipment to the signal input or signal output ports configures a medical system and is therefore responsible that the system complies with the requirements of the system standard EN 60601-1-1 and IEC 60601-1-1. Siemens can only guarantee the performance and safety of the devices listed in the Instructions for Use. If in doubt, consult the Siemens service department or your local Siemens representative.



⚠ WARNING: Equipment connected to the ultrasound system and in the patient environment must be powered from a medically-isolated power source or must be a medically-isolated device. Equipment powered from a non-isolated source can result in chassis leakage currents exceeding safe levels. Chassis leakage current created by an accessory or device connected to a non-isolated outlet may add to the chassis leakage current of the ultrasound system.



▲ WARNING: Non-medical grade report printers cannot be used within a patient environment.



⚠ **WARNING**: During use of a non-medical grade report printer or when a non-medical grade report printer is connected to the ultrasound system, the ultrasound system cannot in any way be in contact with a patient.

Relevant standards for some non-medical electrical equipment may have limits for enclosure leakage currents higher than required by medical standards. These higher standards are acceptable only outside the patient environment. It is essential to reduce enclosure leakage currents when non-medical electrical equipment is to be used within the patient environment. Measures for reducing leakage current include use of a medically-approved isolation transformer.

See also: Technical Description, Appendix A, Instructions for Use

The ultrasound system has printer drivers compatible with non-medical grade report printers. Siemens does not guarantee the performance and safety of any non-medical grade report printer. Non-medical grade report printers do not fulfill the following safety requirements:

- EN 60601-1-1 and IEC 60601-1-1 (Medical Electrical Equipment, Part 1: General Requirements for Safety).
- EN 60601-1-2 and IEC 60601-1-2 (Electromagnetic Compatibility of Medical Devices).

If a non-medical grade report printer is to be used with the ultrasound system, then you must ensure mitigation is provided to meet all safety requirements. It is the responsibility of the user to ensure that the ultrasound system in combination with the non-medical grade report printer complies with safety requirements.

- Always use a medically-approved isolation transformer with a non-medical grade report printer.
- Mitigate risk with regard to the Electromagnetic Compatibility of Medical Devices requirement. A non-medical grade device must be designed, manufactured, and certified to meet the same EMC (electromagnetic compatibility) requirements as the ultrasound system, or other means must ensure that the overall EMC requirements are met.

Manufacturers of Medically-Approved Isolation Transformers

Manufacturer	Web Site
Tripp Lite	www.tripplite.com
Toroid Corporation of Maryland	www.toroid.com
Dale Technology Inc.	www.daletech.com

2 - 8 System Reference

Mitigating the Risk of Connecting a Report Printer

To fulfill EN 60601-1-1 and IEC 60601-1-1 (Medical Electrical Equipment, Part 1: General Requirements for Safety) requirements for non-medical peripheral equipment:

- The non-medical peripheral equipment must be approved according to any other EN or IEC standard (EN XXXXX or IEC XXXXX, e.g., equipment complying with EN 60348 and IEC 60348, EN 60950 and IEC 60950, etc.).
- The connection of non-medical peripheral equipment to your ultrasound system must adhere to the following conditions:
 - Connect the ultrasound system to an AC power outlet within a medically used room
 within the patient environment. A patient environment is defined as an area in which
 medical examination, monitoring, or treatment of the patient takes place. The patient
 environment is located 1.5 meters (1.8 meters [6 feet] in Canada and the U.S.A.)
 around the patient location.
 - Connect the peripheral equipment AC power cable to a medically approved isolation transformer.
 - Connect the medically approved isolation transformer to a main AC outlet either inside
 or outside the patient environment. The peripheral device and medically approved
 isolation transformer combination can be either (a) within the same room as the
 ultrasound system, or (b) in a non-medically used room.

For additional information and other possible combinations, please refer to the Medical Electrical Equipment Standard EN 60601-1-1 or IEC 60601-1-1, Annex BBB.7, Scenario 3c.

Note: The above information is based on current EN 60601-1-1 and IEC 60601-1-1 standards, dated 2000-12. If your country's regulatory standards for medical equipment do not correspond to EN 60601-1 and IEC 60601-1, as well as EN 60601-1-1 and IEC 60601-1-1, your local requirements may differ.

Patient Environment

See also: Connecting Peripheral Equipment, System Setup, Chapter 3, Instructions for Use

Connecting and Installing Report Printers

Report printers are either directly connected to the ultrasound system (PC printer or USB printer) or linked through a network path to the ultrasound system (network printer).

You must observe all safety precautions for connecting a non-medical device to the ultrasound system.

Note: The **SET** key on the control panel functions as a point-and-select device (similar to a computer mouse) when used with the trackball. To select an on-screen object such as a button or a check box, roll the trackball to position the pointer (cursor) on the object and then press the **SET** key on the control panel.

Prerequisites:

- For PC printers:
 - Insert the disk media with the printer driver into the ultrasound system.
 - Disconnect the PC printer from the ultrasound system
- For network printers, ensure you have the network path or URL.

To install a printer driver:

- 1. Insert the disk media with the printer driver.
- 2. Press the **Presets** key on the keyboard and then select **Printer** on the left of the screen.
- Click Install and then click Next when the system displays the screen for installing the print driver.
- 4. Select Install a Printer driver and then click Next.

The system displays a list of device drivers on the disk media.

5. Select the required printer device driver and then click Next.

The system begins installing the printer device driver.

Note: If the system displays a message, click OK.

- 6. Click Next when the system displays the completion message.
- For PC printers only: Connect the USB cable from the printer to a USB port on the ultrasound system.

Note: The system may display a message box depending on the printer manufacturer. If a message is displayed, follow the instructions in the message box.

- 8. Click **Next** to complete the installation.
- 9. Click **Close** when the system displays the completion message.

The system displays a message to restart the system.

10. Click Yes.

2 - 10 System Reference

To add a network printer:

- 1. Press the **Presets** key on the keyboard and then select **Printer** on the left of the screen.
- 2. Click Install.

The system displays the screen for installing the printer driver.

3. Select Connect to a network printer and then click Next.

The system automatically detects the available printers.

4. Select the required network printer and then click **Next**.

If the required printer is not detected, click The printer that I want isn't listed.

- 5. Follow the instructions on the screen.
- 6. Click **Close** when the installation is completed.

The system displays the message to restart the system.

7. Click Yes.

Confirming Installation

To confirm installation, select a printer and then print a report.

Selecting the PC Printer or USB Printer

Use the system presets to select a PC printer or a USB printer as the system's report printing device.

■ Printer

To select the PC printer or USB printer:

- 1. Press the **Presets** key on the keyboard and then select **Printer** on the left of the screen.
- 2. Select the required printer from the drop-down list for PC Printer or USB Printer.
- Click Save.

The system displays the active image screen.

Testing the PC Printer or USB Printer Installation

Test the installation of the printer by printing a report.

Note: You can perform this test without actual data in a report.

To test the PC printer or USB printer installation:

1. Press the **EXAM** key on the control panel.

The system displays a list of exams and QuickSets.

- 2. Select an exam type with support for a patient report, such as C-Vascular.
- 3. Press the **Report** key on the keyboard.
- 4. Click **Send Report** on the lower right of the screen.

The system sends the report to the selected printer and changes the **Send Report** button to **Cancel**.

- a. To interrupt immediately, click Cancel.
- b. To stop after the current page, press the **ESCAPE** key.

2 - 12 System Reference

Video Recorders

Note: Please refer to the manufacturer's user manual for instructions on operating your video recorder.

Note: While the ultrasound system is designed to provide the highest quality of images to a documentation or storage device, image quality during playback is dependent on the video recorder and video media being used.

Video Communication Setup

Connect the video recorder cables to the DVI ports on the Input/Output panel of the ultrasound system.

To designate which video input port is connected to the video recorder cables:

- 1. Press the **Presets** key on the keyboard to access the system presets.
- 2. Select **Peripheral** on the left of the screen.
- 3. Select a recording device for **Device Type**.
- 4. Select the **Save** button to store the new settings and exit the system presets.

2 Documentation Devices

2 - 14 System Reference

3 DICOM Connectivity Option

About DICOM	3
Current and Previous Studies	3
Screens	4
DICOM Storing and Printing	5
Storing Studies	5
DICOM Structured Reporting	5
DICOM Setup	6
Creating and Editing Aliases	7
Activating Aliases	8
Deleting Aliases	8
Field Descriptions for DICOM Configuration Screens	9
Local Host Setup Screen	9
DICOM Storage Server Setup Screen	. 10
Worklist Server Setup Screen	. 12
DICOM Modality Performed Procedure Steps (MPPS) Server Setup Screen	13
DICOM Printer Setup Screen	
Query/Retrieve Screen	
DICOM Storing and Printing	. 17
Configuring Clip Options for DICOM	. 17
Configuring the System for In-Progress Store	. 17
Storing Images to DICOM Storage Servers	. 18
Printing Images to DICOM Printers	. 19
Arranging Printer Layout Pages	. 21
Queue Status Indicators	. 22

3 DICOM Connectivity Option

3 - 2 System Reference

About DICOM

Note: Before using the DICOM Connectivity option, familiarize yourself with the functionality of the DIMAQ Study and Image screens.

The DICOM (Digital Imaging and Communications in Medicine) Connectivity option works in conjunction with the DIMAQ integrated workstation to provide digital image transfer using a DICOM network for both storage and printing. With the option installed, the ultrasound system is a DICOM Storage Class User and DICOM Print Class User.

Current and Previous Studies

This chapter describes studies as *current* or *previous*. The ultrasound system supports only one registered patient at a time. When you register a patient, you initiate a current study. This study remains current until you create a new study by:

- Registering a new patient after pressing the New Patient key
- Re-registering the current patient by clicking New on the Study screen

You can also end a current study without creating a new study by:

- Clicking Close Study on the Image screen or Close on the Study screen
- Shutting down the ultrasound system
- Pressing New on the keyboard

Use the system presets to assign functionality to the New key.

E Customize Keys > NEW Key

When you end a current study using any of these methods, the study becomes a previous study. A previous study remains linked to its original patient data and can be accessed from the Study screen. Original patient data cannot be changed in a previous study.

Screens

The following screens are used with DICOM and are accessed by pressing the **Patient Browser** key on the keyboard:

- Image screen displays images for the currently selected study. When the DICOM option is installed, includes selections for sending images to DICOM printers.
 - **Note:** In this chapter, the term "Image screen" refers to a screen within the DIMAQ feature. In other chapters of user and reference manuals, the use of "image screen" refers to a typical live image screen that displays real-time images as they are acquired.
- Study screen lists studies that are saved on the selected disk (Local Disk, CD/DVD, or Removable Disk). When the DICOM option is installed, includes selections for sending studies to DICOM printers and storage servers.
- DICOM screen displays tabs for pages that list current DICOM activity:
 - DICOM BW Printer Layout displays black and white images assembled according to a selected format for the DICOM Print Queue.
 - DICOM Color Printer Layout displays color images assembled according to a selected format for the DICOM Print Queue.
 - DICOM Print Queue lists images sent to the DICOM printer.
 - DICOM Store Queue lists images sent to the DICOM storage server.
 - Retrieve Queue lists studies retrieved from the Query/Retrieve server.
- Worklist screen displays studies stored on the worklist server for automatic entry of data on the Patient Data form.
- Procedure screen displays the Choose Procedure screen for selection of another procedure for the currently registered patient.
- Live screen displays the real-time imaging screen.

3 - 4 System Reference

DICOM Storing and Printing

You can send images from current or previous studies to the **DICOM Store Queue** using one of the following methods:

- Send all images for a previous study directly from the Study screen.
- If the Autostore to DICOM setting is selected in the system presets, the system sends all images on the Image screen when a current study is closed.

You can print from current or previous studies to a DICOM printer using one the following methods:

- Assemble individual images on a printer layout page in a current or previous study.
- Print single or multiple pages of images from a printer layout page in a current or previous study.
- Send all images from a previous study directly to a printer queue from the Study screen.
- Using the following settings in the system presets, the ultrasound systems prints images when certain conditions are met:
 - If the Print When Page Is Full setting is selected, a page is sent to the printer queue
 as soon as the last image required by the page layout is added. An incomplete page is
 automatically sent to the printer queue when you close a current study or select
 another study.
 - If the Print At End Of Exam setting is selected, you can assemble multiple pages prior to printing, and all pages are automatically sent to the printer queue when you close a current study or select another study.

Storing Studies

The Study screen lists all current and previous studies stored on the selected device in the **Archive Source** drop-down list: **Local Disk**, **CD/DVD**, or **Removable Disk**.

You can access images from a previous study without closing the current study.

DICOM Structured Reporting

Note: DICOM structured reports are available only for Obstetrics, Gynecology, Cardiac, and Vascular exams.

The ultrasound system automatically generates a DICOM structured report (SR) for the current examination and stores the SR to the study on the system's hard disk.

Note: DICOM structured reports are not listed in the DIMAQ Image screen; you must send the SR to a DICOM device to view the report.

Use the system presets to send DICOM structured reports to DICOM devices.

■ DICOM

DICOM Setup

Prerequisite: A working knowledge of Windows networking principles is necessary and beneficial for completing DICOM configuration.

Use the system presets to set up DICOM.

■ DICOM

Note: DICOM configuration is disabled during a patient examination. If a patient is registered, close the study before performing DICOM configuration.

DICOM Setup requires the following information for each configured device, for example, a storage server, worklist server, or documentation device:

- Ultrasound system host name, alias, Application Entity (AE) title, Internet Protocol (IP) address, subnet mask, and default gateway
- Media type and duplex mode required for connection to the host (ultrasound system)
- Alias, AE title, IP address, and port number for each DICOM device

You must check the storage server for compatibility with the ultrasound system settings.

To begin DICOM Setup, connect a network cable to the Ethernet port on the input/output panel of the ultrasound system.

Use the tabs on the DICOM setup screen to configure the following devices.

Tab	Description	
Local Host	Local network settings for the ultrasound system.	
Storage Server	Configuration settings for the devices where patient information is stored. You can activate up to three storage servers and specify when images are saved to the server(s).	
Worklist Server	Configuration settings for information system servers, for example, a hospital information system (HIS). You can configure the system to perform a search of procedures on the active worklist server.	
MPPS Server	Configuration settings for the Modality Performed Procedure Step (MPPS) server that works with the worklist server to provide updates to exam status.	
BW Printer	Configuration settings for documentation devices. For example, you can specify when pages ar	
Color Printer	printed and the print format.	
Query/Retrieve	Configuration settings for the information server used to query and retrieve patient data.	

3 - 6 System Reference

Creating and Editing Aliases

You can create and edit aliases (DICOM configurations) for the host (ultrasound system) and other devices, for example, servers and printers.

To create or edit an alias:

- 1. Press **Presets** on the keyboard and then select **DICOM** on the left of the screen.
- 2. Select the tab for the required alias, for example, **Storage Server** or **Worklist Server**.
- 3. To edit an existing alias, select the alias from the server list and then click **Edit**. The system enables the current DICOM configuration settings for the selected alias.
- 4. To create a new alias, click New.
 - The system enables the DICOM configuration settings to define a new alias.
- 5. Enter the required settings and then click Apply.
 - See also: Field Descriptions for DICOM Configuration Screens, p. 3-9
- 6. Confirm a successful connection and valid configuration information for devices connected to the ultrasound system:
 - To verify the connection, click Ping.
 - To verify the connection and configuration information, click Echo.
- To save all configuration changes and exit the system presets, click Save.
 If you changed any host configuration information, the system prompts you to restart the ultrasound system.
- 8. To cancel all configuration changes and exit the system presets, click **Cancel**.

Activating Aliases

You can activate existing aliases (DICOM configurations) for the host (ultrasound system) and other devices, for example, servers and printers.

To activate an existing alias:

- 1. Press Presets on the keyboard and then select DICOM on the left of the screen.
- Select the tab for the required alias, for example, to activate a worklist server alias, select the Worklist Server tab.
- 3. Select the alias from the server list.
- 4. To activate the alias and exit the system presets, click **Apply** and then click **Save**.

Deleting Aliases

You can delete aliases (DICOM configurations) for the host (ultrasound system) and other devices, for example, servers and printers.

To delete an alias:

- 1. Press Presets on the keyboard and then select DICOM on the left of the screen.
- 2. Select the tab for the required alias, for example, to delete a storage server alias, select the **Storage Server** tab.
- 3. Select the alias from the server list and then click **Delete**.
- 4. To save changes and exit the system presets, click **Save**.

3 - 8 System Reference

Field Descriptions for DICOM Configuration Screens

Note: Obtain the required configuration information from your network administrator.

Local Host Setup Screen

Field	Settings
Local Host	Displays the name of the configured local host system.
Show network status	When enabled (checked), the Network section on the Study screen indicates the status of the network connection.
Alias	Text entry to identify the configured device.
AE Title	Text entry for the application entity title.
Host Name	Text entry for the local host name.
MAC Address	Displays the Media Access Control address detected for the host
DHCP (Dynamic Host Control	On (selected)
Protocol)	Off (cleared)
Mapping Application	On (selected)
	Off (cleared)
Fixed IP address	On (selected)
	Off (cleared)
IP Address	Text entry for the Internet Protocol address of the configured device.
Subnet Mask	Text entry
Default Gateway	Text entry
Media Type	Hardware Default
	AUTOSELECT
	100BASETX
	10BASET
Duplex Mode	Hardware Default
	Half Duplex
	Full Duplex

DICOM Storage Server Setup Screen

Field	Settings
Storage Server	Displays a list of configured devices.
	You can activate up to three storage servers.
	Note: The selected servers in this list are displayed in the server list on the Image screen.
Uses Commitment	Select this check box if the storage server is configured for the DICOM service "storage commitment."
Alias	Text entry to identify the configured device.
AE Title	Text entry for the application entity title.
IP Address	Text entry for the Internet Protocol address of the configured device.
Port Number	Text entry for the network port that the configured device uses to communicate with the ultrasound system.
Ping and Echo Timeout in seconds	Text entry for the timeout value used by basic communication tests with the host.
Autostore to DICOM	Specifies when images are queued for transfer to the storage server:
	 Store During Exam adds each image to the DICOM Store Queue when you store the image to the study.
	 Store At End Of Exam adds all images to the DICOM Store Queue when you close the study.
Send fourSight TEE clips to the DICOM server	Specifies each angle of the <i>four</i> Sight TEE clips to display and send to the DICOM server.
After Every Image is Stored	Sends notification to the storage commitment server when each image is stored.
	On (selected)
	Off (cleared)
After All Images are Stored	Sends notification to the storage commitment server after all images are stored.
	On (selected)
	Off (cleared)
Number of Times to Retry Failure	Text entry
Seconds Between Each Retry	Text entry
Write Timeout in Seconds	Text entry for the timeout value for sending data to the queue.
Connect Timeout in Seconds	Text entry for the timeout value for attempted connections between the host and the server.
Send SR	Note: Available only for Cardiac, Vascular, and OB/EOB exams.
	When enabled (checked), includes the structured report when sending the study to this device.
	On (checked)
	Off (cleared)

3 - 10 System Reference

Field	Settings
Image Format	Specifies the DICOM format used to transfer images to the storage server.
	Note: Calibration information is included only with the "New Ultrasound" format.
	 Automatic specifies the highest quality format that is supported by the server: "New Ultrasound," "Old Ultrasound," or "Secondary Capture" (listed in sequence from highest quality to lowest quality).
	 Old Ultrasound specifies the highest quality format that is supported by the server: "Old Ultrasound" (highest quality) or "Secondary Capture" (lowest quality).
	 Secondary Capture specifies the "Secondary Capture" format. The "Secondary Capture" format does not support clips.
No Monochrome conversion	Disables monochrome conversion for gray scale images and clips stored on the storage server.
Store grayscale images as Monochrome	Converts gray scale images (stored on the storage server) to monochrome format.
	Note: The system adds the DICOM attributes for "window" and "level" information to monochrome-formatted images.
Store grayscale images and clips as Monochrome	Converts gray scale images and clips (stored to the storage server) to monochrome format.
	Note: The system adds the DICOM attributes for "window" and "level" information to monochrome-formatted images.
Store all images as Monochrome	Stores all images on the storage server in monochrome format.
Store all images and clips as Monochrome	Stores all images and clips on the storage server in monochrome format.

Worklist Server Setup Screen

Field	Settings
Worklist Server	Displays a list of configured devices.
Alias	Text entry to identify the configured device.
AE Title	Text entry for the application entity title.
IP Address	Text entry for the IP address of the configured device.
Port Number	Text entry for the network port that the configured device uses to communicate with the ultrasound system.
Ping and Echo Timeout in Seconds	Text entry for the timeout value for basic communication tests with the host.
Streamlined Search	(Applies to all configured worklist servers)
	When enabled, the system searches all procedures on the Worklist server for the next 24 hours.
	Note: If you perform a streamlined search from the patient data form, the system uses data entered on the form to narrow the search.
	On (checked)
	Off (cleared)
Strict Verification	(Applies to all configured worklist servers)
	When enabled, the system verifies the DICOM standard tags on each study list retrieved from the worklist server.
	On (checked)
	Off (cleared)
Maximum number of worklist item	Text entry for the maximum number of search results to display.
Write Timeout in Seconds	Text entry for the timeout value for sending data to the queue.
Connect Timeout in Seconds	Text entry for the timeout value for attempted connections between the host and the server.

3 - 12 System Reference

DICOM Modality Performed Procedure Steps (MPPS) Server Setup Screen

Field	Settings
MPPS Server	Displays a list of configured devices.
Alias	Text entry to identify the configured device.
AE Title	Text entry for the application entity title.
IP Address	Text entry for the Internet Protocol address of the configured device.
Port Number	Text entry for the network port that the configured device uses to communicate with the ultrasound system.
Ping and Echo Timeout in seconds	Text entry for the timeout value for basic communication tests with the host.
Number of Times to Retry Failure	Text entry
Seconds Between Each Retry	Text entry
Write Timeout in Seconds	Text entry for the timeout value for sending data to the queue.
Connect Timeout in Seconds	Text entry for the timeout value for attempted connections between the host and the server.
Store Image Format	Note: Calibration information is included with the "New Ultrasound" format only.
	 New Ultrasound specifies the highest quality format that is supported by the server: "New Ultrasound," "Old Ultrasound," or "Secondary Capture" (listed in sequence from highest quality to lowest quality).
	 Old Ultrasound specifies the highest quality format that is supported by the server: "Old Ultrasound" (highest quality) or "Secondary Capture" (lowest quality).
	 Secondary Capture specifies the "Secondary Capture" format.

DICOM Printer Setup Screen

Note: Both the Color Printer and B/W Printer tabs list these fields.

Field	Settings
Alias	Text entry to identify the configured device.
AE Title	Text entry for the application entity title.
IP Address	Text entry for the Internet Protocol address of the configured device.
Port Number	Text entry for the network port that the configured device uses to communicate with the ultrasound system.
	Note: If a separate computer controls the printer, the port number may differ from the port number used for the host and storage server.
Ping and Echo Timeout in Seconds	Text entry for the timeout value used by basic communication tests with the host.
Number of Times to Retry Failure	Text entry
Seconds Between Each Retry	Text entry
Write Timeout in Seconds	Text entry for the timeout value for sending data to the queue.
Connect Timeout in Seconds	Text entry for the timeout value for attempted connections between the host and the DICOM printer.
Orientation	Portrait
	Landscape
Display Format	Defines the column and row format used for assembling pages to print
	Note: Verify that the selected format is supported by the destination printer.
	1x1
	1x2
	2x2
	2x3
	3x2
	3x3
	3x5
	4x5
	4x6
	5x6
Copies	Text entry for the number of copies to print.

3 - 14 System Reference

Field	Settings
Film Size	8in x 10in
	8.5in x 11in
	10in x 12in
	10in x 14in
	11in x 14in
	11in x 17in
	14in x 14in
	14in x 17in
	24cm x 24cm
	24cm x 30cm
	A3
	A4
more	
Medium Type	Paper
	clear film
	blue film
	transparency
	Current
Min. Density	Note: Consult the printer manufacturer for appropriate values.
	Text entry
Max. Density	Note: Consult the printer manufacturer for appropriate values.
	Text entry
Border Density	Defines the region outside of the print area on the output medium; typically black for film and white for paper.
	Black
	White
Trim	When selected, outlines each printed image with a box.
Print Priority	high
	medium
	low
Film Destination	magazine
	processor
	current
Magnification	replicate
	bilinear
	cubic
	none
Smoothing Type	Note: This field is not required.
	Text entry used with cubic magnification.

Field	Settings
Empty Image Density	Black (typically used for transparencies)
	White (typically used for paper)
Polarity	normal
	reverse
Configuration	Note: This string is sent to the printer exactly as it displays in this field. This field is not required.
Print When Page is Full	On (checked)
	Off (cleared)
Print At End of Exam	On (checked)
	Off (cleared)

Query/Retrieve Screen

Field	Settings
Alias	Text entry to identify the configured device.
AE Title	Text entry for the application entity title.
IP Address	Text entry for the Internet Protocol address of the configured device.
Port Number	Text entry for the network port that the configured device uses to communicate with the ultrasound system.
	Note: If a separate computer controls the printer, the port number may differ from the port number used for the host and storage server.
Ping and Echo Timeout in Seconds	Text entry for the timeout value for basic communication tests with the host.
Number of Times to Retry Failure	Text entry
Seconds Between Each Retry	Text entry
Write Timeout in Seconds	Text entry for the timeout value for sending data to the queue.
Connect Timeout in Seconds	Text entry for the timeout value for attempted connections between the host and the server.
\(\frac{1}{2}\)	

3 - 16 System Reference

DICOM Storing and Printing

You can store and print images to DICOM devices.

Configuring Clip Options for DICOM

Use the system presets to configure clip options, for example, length and acquisition timing (retrospective or prospective).

□ Clip Capture

Consider the following issues when storing multiple clips to DICOM devices:

- Multiple, longer clips can require considerable storage server memory and transfer time.
- High compression requires less storage server memory and transfer time.
- The number of clip frames in a clip is determined by two parameters: the duration, which is selected in the system presets, and the number of clip frames to acquire per second.

Configuring the System for In-Progress Store

When the system is configured for in-progress store and you press a documentation key that is configured for disk storage, the system stores the image or report to the DICOM storage server and to the system's hard disk.

To configure the system for in-progress store:

- Press Presets on the keyboard to display the system presets and then select DICOM on the left of the screen.
- 2. Select the Storage Sever tab and select the alias from the server list.
- 3. Select the Autostore to DICOM check box and then select Store During Exam.
- 4. Click Save to save the settings.

Storing Images to DICOM Storage Servers

You can send selected studies to a connected DICOM storage server.

You can also automatically send stored images during the current study when the system is configured for in-progress store.

To send studies to a connected DICOM storage server:

Note: The selected studies must be stored on the hard disk.

- 1. Press Patient Browser on the keyboard.
- 2. Click Study Screen, if necessary.
- 3. Select Local Disk in the Archive Source drop-down list on the Study screen.
- 4. Select one or more studies.
 - To select consecutive studies in the list, select the first required study, press and hold the **Shift** key on the keyboard, and then select the last study to send to the server.
 - To select non-consecutive studies, press and hold the Ctrl key on the keyboard and then select each study to send to the server.
- 5. Select **DICOM Store** from the drop-down list in the **Network** section.

Note: DICOM Store is displayed only when the storage servers are defined in the system presets.

- 6. Click [...] to display a list of configured storage servers.
- Select up to three storage servers and then click **OK**.
 The system displays the selected storage servers in the **Network** section.
- 8 Click Send

The system sends all images from the selected studies to the DICOM Store Queue.

To verify the status of the DICOM Store Queue, click DICOM Screen and then select the DICOM Store Queue tab.

3 - 18 System Reference

Printing Images to DICOM Printers

You can send an image to a connected DICOM printer during the current study. You can also print all images or selected images from a study to a connected DICOM printer.

Note: The current number of images and the number of images necessary for each full-page layout display in the lower left of the live image screen.

To send an image to a printer layout page during the current study:

- 1. Freeze the image.
- 2. Press the documentation key that is configured in the system presets for DICOM printing. The system saves the image to the system's hard disk and copies the image to the Image screen and to the corresponding layout page.
- 3. Press Patient Browser on the keyboard.

The system displays the print image and any other images in the Image screen.

- 4. Select additional images from the Image screen for the printer layout, if necessary. The system displays an outline around each selected image.
- Click BW Print or Color Print on the Image screen to copy the selection to the respective printer layout page.

Note: The Image screen displays the current number of images and the images required for a full-page layout display next to the **BW Print** or **Color Print** button.

- The print image is transferred to the **DICOM Print Queue** when one of the following actions occurs:
 - The DICOM BW Printer Layout or DICOM Color Printer Layout page is filled and Print When Page Is Full is selected in the system presets for DICOM.

Note: The **Display Format** setting for the printer determines the number of images in a full page. If display format for a printer is set to "1/1," a page fills and is sent to the **DICOM Print Queue** immediately with each press of a documentation key configured for DICOM printing.

- The Print Page or Print All Pages button is selected in the layout page.
- The study is closed or a previous study is selected and Print At End of Exam is selected for this printer in the DICOM system presets.

The print queue displays a separate entry for each page.

- 7. To verify the status of the **DICOM Print Queue**, click **DICOM Screen** on the Study screen and then select the **DICOM Print Queue** tab.
- To change printing options for a set of printed images, click **DICOM Screen** on the Study screen, select the **DICOM BW Printer Layout** or **DICOM Color Printer Layout** tab, and then click **Change**.

To print all images from one or more studies to a DICOM printer:

Note: The studies must be stored on the hard disk.

- 1. Press Patient Browser on the keyboard and then click Study Screen, if necessary.
- 2. Select Local Disk, CD/DVD, or Removable Disk in the Archive Source drop-down list.
- 3. Select one or more studies.
 - To select consecutive studies in the list, select the first required study, press and hold the Shift key on the keyboard, and then select the last study to send to the server.
 - To select non-consecutive studies, press and hold the Ctrl key on the keyboard and then select each study to send to the server.
- Select the printer from the drop-down box in the Network section on the lower right of the Study screen and then click Send.

The system sends all images from the selected studies to the corresponding layout page(s) and to the printer queue.

To confirm that the study was sent to the printer, click DICOM Screen and then select the DICOM Print Queue tab.

The system lists the studies that were sent to the printer.

To print individual images from a study to a DICOM printer:

Note: The studies must be stored on the hard disk.

- 1. Press Patient Browser on the keyboard and then click Study Screen, if necessary.
- 2. Select Local Disk, CD/DVD, or Removable Disk in the Archive Source drop-down list.
- Select a study from the Study screen.
- 4. Click Image Screen.

The system displays all images from the selected study in the Image screen.

- 5. Select the required image to print.
- 6. Click **BW Print** or **Color Print** to send the image to the layout page.
- 7. To send the layout page(s) to the **DICOM Print Queue**:
 - a. Click Study Screen and then click DICOM Screen.
 - Click Print Page or Print All Pages on the DICOM BW Printer Layout or DICOM Color Printer Layout page.

Note: If a layout page becomes full and **Print When Page is Full** is selected in the DICOM system presets, the system automatically sends the page to the **DICOM Print Queue**. If **Print At End of Exam** is selected in the DICOM system presets, multiple layout pages can be assembled prior to printing. With either selection, all pages are sent to the **DICOM Print Queue** when the current study is closed.

3 - 20 System Reference

Arranging Printer Layout Pages

Use the printer layout pages to assemble images for printing on the same page.

To delete an image from a printer layout page:

Note: A deleted print image is removed from the printer layout page only. The image remains on the system's hard disk as a part of the study and is displayed in the Image screen.

- 1. Click DICOM Screen on the Study screen.
- 2. Select the DICOM BW Printer Layout or DICOM Color Printer Layout tab.
- 3. Select an image on the layout page.

The system displays a blue outline around the selected image.

4. Click **Delete** on the layout page.

The system removes the selected image from the layout page.

To rearrange print images:

- 1. Click DICOM Screen on the Study screen.
- 2. Select the DICOM BW Printer Layout or DICOM Color Printer Layout tab.
- 3. Select an image on the layout page.

The system displays a blue outline around the selected image.

4. Click Cut.

The system displays a yellow outline around the image. The image remains in place until you complete the paste operation.

- 5. Select another image as the paste location.
- 6. Click Paste.

The system inserts the cut image in the paste location and displays a blue outline around the image.

- 7. To rearrange images across pages:
 - a. Select an image and then click Cut.
 - b. Click **Next** or **Previous** to select a different page.
 - c. Select a new paste location and then click **Paste** to insert the image in the paste location on the new page.

Queue Status	Description
Queued	The queue entry has been received by the currently displayed queue. The system has not yet initiated the print/store operation.
Succeeded	The system successfully completed the print/store operation.
In Progress	The system is currently completing the print/store operation.
Suspended	Reserved for future use.
Failed	The system attempted to complete the print/store operation but timed out. If retries are still available, the system displays the number of remaining retries in parentheses (for example, "Failed (2)" indicates two remaining retries). The system continues attempts indefinitely if the TCP/IP connection to the destination device cannot be initiated (for example, if the ultrasound system is temporarily located away from network connections). If the TCP/IP connection can be initiated, the system stops attempts when retries are no
	longer available.
	Note: If this status indicator remains and no more retries are available, ensure that the system presets settings for the connected devices are complete and compatible and then click Retry Job .

To delete jobs:

• Select the jobs in Queue screen and then click **Delete Job**.

3 - 22 System Reference

4 Network Export Function

About the Network Export Function		
Configuring the Network Export Function	3	
Setting Up the Export Host	3	
Defining and Deleting Settings for the Host and the Export Host		
Accessing the Setup Screens	4	
Defining the Host and the Export Host Settings	5	
Deleting the Host and the Export Host Settings	6	
Fields in the Setup Screens	6	
Fields in the Host Setup Screen	6	
Fields in the Export Host Setup Screen		
Sending Studies to the Export Host	8	
Configuring Export Selections	9	

4 Network Export Function

4 - 2 System Reference

About the Network Export Function

The network export function facilitates the transfer of images, clips, and summaries (patient studies) from the ultrasound system to a shared folder on a destination computer, such as a workstation, server, or personal computer.

Note: The system only transfers summaries that were accessed during the active study.

To avoid file conflicts, move the transferred studies from the shared folder on the export host before using the files.

Configuring the Network Export Function

Prerequisite: A working knowledge of Windows networking principles is necessary and beneficial for completing configuration of the network export function.

Configuring the network export function involves setting up the export host and then defining the host and the export host settings on the ultrasound system.

Setting Up the Export Host

The **export host** is the destination for the shared files. Examples of export hosts are off-line workstations, servers, and personal computers.

The export host must meet the following prerequisites:

- Windows 2000 or later operating system
- Compatible remote share access
- Ethernet card that supports TCP/IP

To set up the export host:

Note: For detailed instructions, refer to the user manual for the operating system on the workstation (export host).

- 1. On the export host, create a shared folder and specify security access settings as required.
- Locate the following information on the export host and write the information down. This information will be used to define the host and the export host settings on the ultrasound system.

Note: If the export host uses DHCP (Dynamic Host Configuration Protocol), then the IP address may change frequently. Each time the IP address changes, you must reconfigure the system presets on the ultrasound system with the new IP address.

- Shared folder name
- Computer name (if defined by the export host)
- IP address
- Subnet mask (not required if using DHCP)
- Gateway (not required if using DHCP)
- Account and password used to log onto the export host, including domain name (if applicable)
- Media type and duplex mode required for connection

System Reference 4 - 3

- To connect the export host directly to the ultrasound system, use a cross-over ethernet cable.
- 4. To connect the export host to the ultrasound system through a hub or switch, use a standard ethernet cable.

Defining and Deleting Settings for the Host and the Export Host

You can define the settings for the host and the export host. You can also delete existing host and export host configurations.

The *host* is the ultrasound system. The *export host* is the destination for the shared files. Examples of export hosts are off-line workstations, servers, and personal computers.

Use the system presets to access the setup screens and define and delete the settings for the host and the export host.

■ Network Export

Accessing the Setup Screens

You can access the Host Setup screen and the Export Host Setup screen.

To access the Host Setup screen:

- Press the Presets key on the keyboard to display the system presets and then select Network Export on the left of the screen.
 - The system displays the **Network Export** screen.
- 2. To define a new host configuration, select the New button on the right of the Host line.
- 3. To edit an existing host configuration, select the configuration from the **Host** drop-down list and then select the **Edit** button on the right of the **Host** line.

To access the Export Host Setup screen:

- Press the Presets key on the keyboard to display the system presets and then select Network Export on the left of the screen.
 - The system displays the Network Export screen.
- To define a new export host configuration, select the New button on the right of the Export Host line.
- 3. To edit an existing export host configuration, select the configuration from the **Export Host** drop-down list and then select the **Edit** button on the right of the **Export Host** line.

4 - 4 System Reference

Defining the Host and the Export Host Settings

You can define the settings for the host and the export host.

See also: Setting Up the Export Host, p. 4-3 **See also:** Fields in the Setup Screens, p. 4-6

To define the host and the export host settings:

Prerequisite: Before configuring the system presets on the ultrasound system, you must set up the export host.

- Access the Host Setup screen and use the keyboard to enter values for the fields on the screen.
- 2. Select the **OK** button to save the changes.
- Access the Export Host Setup screen and use the keyboard to enter values for the fields on the screen.
- 4. To verify successful connection to the export host, select the **Ping** button.
- 5. To test writing to the specified shared folder, select the **Test Write** button.

Note: If connection is successful, but writing is not, then complete this procedure and test the writing again. A successful writing test may require cycling the power to the system (rebooting the system).

6. Select the **OK** button to save the changes.

Note: You must also select the **Save** button on the **Network Export** screen to store all the configuration changes.

The system redisplays the **Network Export** screen.

- 7. Ensure that the required host and the required export host are activated: Select the host configuration from the **Host** drop-down list and select the export host configuration from the **Export Host** drop-down list. For example, to activate the "archive1" export host configuration, select "archive1" from the **Export Host** drop-down list.
- 8. Select the **Save** button at the bottom of the **Network Export** screen to save all configuration changes.
- 9. Cycle power to the ultrasound system.
 - a. From the live image screen, power off $(\begin{cal} (\begin{cal} ($
 - b. Wait approximately 20 seconds before powering on ($^{\circlearrowleft}$) the ultrasound system.

System Reference 4 - 5

Deleting the Host and the Export Host Settings

You can delete existing configurations containing host or export host settings.

To delete a configuration:

Select the configuration from the related drop-down list (such as the Export Host drop-down list), select the Delete button to the right of the selected alias, and then select OK to confirm.

Fields in the Setup Screens

Fields in the Host Setup Screen

Field	Description
Alias	User-designated name for host.
AE Title	Application Entity Title as configured for DICOM.
	Note: Disregard this field. The system automatically populates this field if the ultrasound system is configured for DICOM. Otherwise, the system does not use this field.
Host Name	User-designated name for host (you can use the value entered for Alias)
MAC Address	Indicates the Media Access Control (MAC) address detected for the host (this field is display only).
DHCP	When checked (enabled), activates Dynamic Host Control Protocol for the host (ultrasound system).
	Note: Do not configure the host to use DHCP if DICOM is installed. DHCP is not compatible with DICOM.
Mapping Application	Supports communication through a direct LAN connection. When selected (enabled), displays the IP address of the ultrasound system.
Fixed IP Address	When selected (enabled), activates fields for entering a fixed IP address for the host (ultrasound system).
IP Address	IP address for the host (ultrasound system).
Subnet Mask	Subnet mask for the host (ultrasound system). Typically identical to the subnet mask for the export host.
Default Gateway	Default gateway for the host (ultrasound system). Typically identical to the default gateway for the export host.
Media Type	HardwareDefault
	AUTOSELECT
	100BASETX
	10BASET
Duplex Mode	HardwareDefault
	HalfDuplex
	FullDuplex

4 - 6 System Reference

Fields in the Export Host Setup Screen

Field	Description
Alias	System-defined "computer name" or user-defined name for the export host.
IP Address	IP address of the export host.
	Note: If DHCP is used for the export host, then reconfigure this field when the IP address changes.
Shared Folder	Exact name of the shared folder on the export host, following standard MS Windows conventions for specifying access.
	Note: Disregard this field if Export to PACS is enabled.
Account	Account name used to log on to the export host.
	Examples:
	"archive1\jsmith" ("computer name" and user name for local account on export host)
	"jsmith" (user name for local account on export host)
	"domain1\jsmith" (domain and user name)
Password	Password used to log on to the export host, if applicable.
	Note: This field is case sensitive. The system indicates the status (on/off) of the Caps Lock key on the keyboard on the right of the screen.
Ping and Echo Timeout in seconds	Time limit (in seconds) for confirming a successful connection.
Ping	Confirm successful connection.
Test Write	Attempt storing "test" files to the export host.

System Reference 4 - 7

Sending Studies to the Export Host

You can send studies from the system's hard disk to the selected, configured export host. You can also automatically send a study to the export host when the study is closed and automatically indicate the status of the network connection.

Note: Before using the transferred studies on the export host (destination device), move the studies from the shared folder to avoid file conflicts.

Use the system presets to select and configure the export host, to automatically send studies to the export host as they are closed, and to automatically indicate the status of the network connection.

■ Network Export

To send one or more studies to the export host:

Note: If you send a study that already exists on the export host, then the system overwrites the existing study.

Note: Studies to be sent to the network must be closed.

- 1. Press the **Patient Browser** key on the keyboard to display the Study screen.
- If the system displays the Image screen, then select the Study Screen button to display the Study screen.

The system displays the Study screen.

- 3. Ensure that Local Disk is selected in the Archive Source section of the Study screen.
- 4. Select one or more studies for export.
- In the Network section of the Study screen, select the export host from the drop-down list and then select Send.

The system indicates successful transfer by displaying **Network** in the **Archived** column listed on the Study screen. The system indicates unsuccessful transfers by displaying errors.

To automatically send a study to the export host as the study is closed:

- 1. Press the **Presets** key on the keyboard to display the system presets.
- Select Network Export on the left of the screen to display the Network Export screen and then select the Autostore to Network check box located under the export host line.

The system automatically sends each study to the export host when the study is closed.

To automatically indicate the status of the network connection:

- 1. Press the **Presets** key on the keyboard to display the system presets.
- Select Network Export on the left of the screen to display the Network Export screen and then select the Show network status check box located under the host line.

The system automatically indicates the status of the network connection in the $\bf Network$ section of the Study screen.

4 - 8 System Reference

Configuring Export Selections

Use the system presets to select the study data to send to the export host.

Images, clips, and summaries are exported to a shared folder on the export host. The folder is labeled with the patient identification and the date and time of the study (using the format of year, month, day and hours, minutes, seconds).

Note: The date format used to name the study folders is unrelated to the date format set in the system presets.

To select the study data to export:

 Press the Presets key on the keyboard and then select Network Export on the left of the screen.

The system displays the **Network Export** screen.

- 2. In the Export Format section, select the images and clips saved with a study to export.
 - To export all images and clips as .jpg and .avi files into the same folder, click Export all Images/Clips.
 - To export only selected images and clips as .jpg and .avi files into the same folder, click Export selected Images/Clips.
 - To export all images and clips as .tif and .avi files with a calibration (.cal) file into separate folders, click Export Legacy Format.
 - A calibration (.cal) file for video format and pixel spacing is exported into the images folder with the images.
- To export the summaries as .pdf and .rtf files with the exported images and clips, click Export pdf/rtf.
 - If **Export Legacy Format** is selected, the summaries and reports are stored in the reports folder.
- Click Save.

System Reference 4 - 9

4 Network Export Function

4 - 10 System Reference

3	Nireless Network Selections
4	Network Profile Settings
5	Internet Protocol Properties
6	Configuring a Connection to a Wireless Network

System Reference 5 - 1

5 - 2 System Reference

Use the system presets to enable and disable a wireless network adapter connected to the ultrasound system. You can require a password to prevent unauthorized changes to the wireless network selections.

■ Wireless

Selection	Option(s)	Allows you to
Wireless Network	Enabled	Activate or deactivate wireless connectivity.
	Disabled	
	(available selections)	Select a wireless adapter that is connected to the ultrasound system.
	[]	Update the list of wireless adapters that are connected to the ultrasound system.
Network Settings	Available Network List	Select a wireless network for the ultrasound system to use.
	New Edit	Access the Network Profile Settings dialog box to configure the network profile. The ultrasound system uses the network profile to connect to the selected wireless network.
		See also: Network Profile Settings, p. 5-4
	Connect	Connect to the selected wireless network.
	Disconnect	Disconnect from the selected wireless network.
	Scan	Refresh the list of available wireless networks.
Connection Information		
SSID (Service Set Identification)		View the name of the connected wireless network.
Signal Strength		View the strength of the connection to the wireless networks:
		 86 to 100 (Strong)
		■ 51 to 85 (Good)
		26 to 50 (Weak)
		■ 1 to 25 (Poor)
		■ 0 (No Signal)
Link Speed		View the speed of the wireless network connection.
Refresh		Update the information of the connected wireless network.
Properties		Access the Internet Protocol Properties dialog box to enter the IP address and the DNS (Domain Name System) server address for the selected wireless network.
		See also: Internet Protocol Properties, p. 5-5
Lock		Enable and disable password protection to restrict changes to the wireless network options.

System Reference 5 - 3

Network Profile Settings

■ Wireless > Network Settings > New

■ Wireless > Network Settings > Edit

Selection	Option(s)	Allows you to
Network Name (SSID)	(text entry)	Enter the name of a wireless network.
Non-broadcast network	on, off	Configure the network profile for a wireless network that broadcasts its name (off) or does not broadcast its name (on).
Security Type	OPEN	Specify the network security method for the connection to a wireless network
	Shared	***************************************
	WPA	Note: The options for the security method are dependent on the wireless network.
	WPAPSK	
	WPA2	
	WPA2PSK	
Encryption Type	None	Select the encryption method for the connection to a wireless
	WEP	network.
	TKIP	Note: The options for the encryption method are dependent or
	AES	the wireless network.
Security Key	(text entry)	Enter the security key for the connection to a wireless network
EAP Authentication		
		Note: EAP authentication options are enabled only when you select WPA or WPA2 for the security type.
EAP Type	PEAP	Select the EAP (Extensible Authentication Protocol) authentication method for the connection to a wireless network.
		Note: The options for the EAP authentication method are dependent on the wireless network.
Username	(text entry)	Specify the user name for EAP (Extensible Authentication Protocol) authentication.
Password	(text entry)	Specify the password for EAP (Extensible Authentication Protocol) authentication.

5 - 4 System Reference

Internet Protocol Properties

■ Wireless > Connection Information > Properties

Selection	Option(s)	Allows you to
Obtain an IP address automatically (DHCP)	on, off	Configure the ultrasound system to use dynamic IP addresses assigned by a DHCP (Dynamic Host Configuration Protocol) server (on) or to use a static IP (Internet Protocol) address (off).
Use the following IP address		
IP Address	(text entry)	Specify a static IP address.
Subnet Mask	(text entry)	Specify the subnet mask for a LAN (Local Area Network).
Default Gateway	(text entry)	Specify the gateway for the LAN.
Obtain DNS server address automatically	on, off	Configure the ultrasound system to use the address of the DNS (Domain Name Server) sent by the DNS service (on) or to use the address specified in the Use the following DNS server address selection.
Use the following DNS server address		
Preferred DNS Server	(text entry)	Configure the ultrasound system to use the DNS address.

System Reference 5 - 5

Configuring a Connection to a Wireless Network

You can enable and disable connections to wireless networks without a password even when changes to the wireless network options are protected by a password.

Note: If the ultrasound system is connected to both a wireless network and a local area network (LAN), the system uses the LAN connection for sending files to network locations.

To configure a connection:

Prerequisite: The wireless adapter is connected to the leftmost USB port on the Input/Output panel of the ultrasound system.

- 1. Access the system presets.
- Select Wireless.
- 3. Enter a password, if required.

То	Do This
Activate a connection to a wireless network	Note: Siemens recommends using secured networks to ensure data security.
	Select Enabled.
Deactivate the connection to a wireless network	Select Disabled .
Connect to the selected network	1. Click Scan to refresh the list of wireless networks.
	Note: The wireless adapter must remain connected to the ultrasound system while refreshing the list.
	2. Select a network from the list.
	3. Click Connect.
	 If the system displays the Network Profile Settings dialog box, enter the required profile settings and then click OK.
	The ultrasound system displays the wireless icon indicating a connection to a wireless network and the signal strength on the status bar.
	See also: System Setup, Chapter 3, Instructions for Use
Disconnect from the selected	Select the connected network from the list.
wireless network	2. Click Disconnect.
	The ultrasound system disconnects from the wireless network. If connected to a LAN, the system reverts to using the LAN connection for sending files to network locations.

5 - 6 System Reference

То	Do This
Create a network profile	1. Click New.
	The ultrasound system displays the Network Profile Settings dialog box.
	2. Enter the required network profile settings and then click OK .
	The ultrasound system displays the new network profile.
Change network profile settings	Select a wireless network.
	2. Click Edit.
	3. Enter the required network profile settings and then click OK .
	4. To delete the existing profile setting, click Remove .
Enable password protection to	1. Click Lock.
restrict changes to the wireless network options	2. Enter a new password and then click OK .
Disable password protection to	1. Click Unlock.
provide unrestricted access to the wireless network options	2. Enter the password and then click OK .
Change a password	1. Click Change.
	2. Enter the password.
	3. Reenter the new password and then click OK .
Display characters of a password as you enter the password	Select Show password.

System Reference 5 - 7

5 - 8 System Reference

6 Cardiac References

Body Surface Area	3
2D-Mode Measurements and Calculations	3
Cardiac Index	
Cardiac Output	3
Left Ventricular End-Diastolic Volume and Left Ventricular End-Systolic Volume	3
Teichholz Formula	
Simpson Single Plane Formula	
Simpson Bi-Plane	
Ejection Fraction	
Fractional Shortening	
Stroke Index	
Stroke Volume	
Volume	
M-Mode Measurements and Calculations	4
Cardiac Index	
Cardiac Output	4
Left Ventricular End-Diastolic Volume and Left Ventricular End-Systolic Volume	4
Teichholz Formula	
Ejection FractionFractional Shortening	
AO/LA (Aorta/Left Atrium) Ratio	
Heart Rate	
Stroke Index Stroke Volume	
Stroke volume	o
Doppler Mode Measurements and Calculations	5
Doppler References	5
Acceleration Slope/Time	5
Deceleration Slope/Time	5
Pressure Half-Time	5
MVA (Mitral Valve Area Continuity Equation)	5
AVA (Aortic Valve Area)	5
Heart Rate	5
CO (Cardiac Output)	6

	MV E/A (Mitral Valve, E point to A point Ratio)	6
	MV A/E (Mitral Valve, A point to E point Ratio)	6
	MV CA/CE (Mitral Valve, CA amplitude to CE amplitude Ratio)	6
	IVRT (Isovolumic Relaxation Time)	6
	LVIMP (Left Ventricular Index of Myocardial Performance)	6
	RVIMP (Right Ventricular Index of Myocardial Performance)	6
	Right Ventricular Systolic Pressure (RVSP)	6
	TR V max (Tricuspid Regurgitant Jet Plus Right Atrial Pressure)	6
	Max PG (Maximum Pressure Gradient)	7
	Mean PG (Mean Pressure Gradient)	7
	AV PG max (Aortic Valve maximum Pressure Gradient)	7
	AV PG mean (Aortic Valve mean Pressure Gradient)	7
	MV PG max (Mitral Valve maximum Pressure Gradient)	7
	MV PG mean (Mitral Valve mean Pressure Gradient)	7
	MR PG max (Mitral Regurgitation maximum Pressure Gradient)	7
	PV PG max (Pulmonary Valve maximum Pressure Gradient)	7
	PV PG mean (Pulmonary Valve mean Pressure Gradient)	7
	TR PG max (Tricuspid Regurgitation maximum Pressure Gradient)	8
	TR PG mean (Tricuspid Regurgitation mean Pressure Gradient)	8
	TV PG max (Tricuspid Valve maximum Pressure Gradient)	8
	TV PG mean (Tricuspid Valve mean Pressure Gradient)	8
	LVOT PG max (Left Ventricular Outflow Tract maximum Pressure Gradient)	8
	LVOT PG mean (Left Ventricular Outflow Tract mean Pressure Gradient)	8
	VSD PG max (Ventricular Septal Defect maximum Pressure Gradient)	8
Add	ditional Cardiac References	8
	Left Atrial and Right Atrial Volumes	8
	Left Ventricular Mass	9
	Mitral Valve Area and Aortic Valve Area Using Continuity Equation with both the Peak Velocity and Velocity-time Integral	9
	Cardiac Normal Range Values	10
	Shortening / Wall Stress	10

6 - 2 System Reference

Body Surface Area

Du Bois D, Du Bois EF. "A Formula to Estimate the Approximate Surface Area if Height and Weight Be Known." *Archives of Internal Medicine* 17:863, 1916, as reprinted in *Nutrition* 5(5):303-311. 1989.

2D-Mode Measurements and Calculations

Cardiac Index

- Berkow R, Editor. *The Merck Manual of Diagnosis and Therapy, 16th Edition.* Rahway, New Jersey: Merck and Co., 1992, p. 378.
- Schiller NB, Shah PM, Crawford M, et al. "Recommendations for Quantitation of the Left Ventricle by Two-Dimensional Echocardiography." *Journal of the American Society of Echocardiography* 2(5):364, 1989.

Cardiac Output

- Belenkie I, Nutter DO, Clark DW, McCraw DB, Raizner AE. "Assessment of Left Ventricular Dimensions and Function by Echocardiography." *American Journal of Cardiology* 31:755-762, June 1973.
- Haites NE, McLennan FM, Mowat DHR, Rawles JM. "Assessment of Cardiac Output by Ultrasound Technique Alone." *British Heart Journal* 53:123-129, 1985.
- Huntsman LL, Stewart DK, Barnes SR, Franklin SB, Colocousis JS, Hessel EA. "Noninvasive Doppler Determination of Cardiac Output in Man." *Circulation* 67(3):593-602, 1983.
- Ihlen H, Amlie JP, Dale J, et. al. "Determination of cardiac output by Doppler echocardiography." British Heart Journal 51:54-60, 1984.

Left Ventricular End-Diastolic Volume and Left Ventricular End-Systolic Volume

Teichholz Formula

Teichholz LE, Kreulen T, Herman MV, Gorlin R. "Problems in Echocardiographic Volume Determinations: Echocardiographic-Angiographic Correlations in the Presence or Absence of Asynergy." *American Journal of Cardiology* 37(1):7-11, 1976.

Simpson Single Plane Formula

Schiller NB, Shah PM, Crawford M, et al. "Recommendations for Quantitation of the Left Ventricle by Two-Dimensional Echocardiography." *Journal of the American Society of Echocardiography* 2(5):364, 1989.

Simpson Bi-Plane

Schiller NB, Shah PM, Crawford M, et al. "Recommendations for Quantitation of the Left Ventricle by Two-Dimensional Echocardiography." *Journal of the American Society of Echocardiography* 2(5):364, 1989.

Ejection Fraction

Pombo JF, Troy BL, Russell RO. "Left Ventricular Volumes and Ejection Fraction by Echocardiography." *Circulation* 43:480-490, 1971.

Fractional Shortening

Belenkie I, Nutter DO, Clark DW, McCraw DB, Raizner AE. "Assessment of Left Ventricular Dimensions and Function by Echocardiography." *American Journal of Cardiology* 31:755-762, June 1973.

Stroke Index

Görge G, Erbel R, Brennecke R, Rupprecht HJ, Todt M, Meyer J. "High-Resolution Two-dimensional Echocardiography Improves the Quantification of Left Ventricular Function." *Journal of the American Society of Echocardiography* 5(2):125-134, 1992.

System Reference 6 - 3

Stroke Volume

Görge G, Erbel R, Brennecke R, Rupprecht HJ, Todt M, Meyer J. "High-Resolution Two-dimensional Echocardiography Improves the Quantification of Left Ventricular Function." *Journal of the American Society of Echocardiography* 5(2):125-134, 1992.

Roelandt J. *Practical Echocardiography* Ultrasound in Biomedicine, No. 1. Research Studies Press (a division of John Wiley & Sons Ltd), 1977, p. 270.

Volume

Schiller NB, Shah PM, Crawford M, et al. "Recommendations for Quantitation of the Left Ventricle by Two-Dimensional Echocardiography." *Journal of the American Society of Echocardiography* 2(5):364, 1989.

M-Mode Measurements and Calculations

Cardiac Index

Berkow, R, Editor. *The Merck Manual of Diagnosis and Therapy, 16th Edition.* Rahway, New Jersey: Merck and Co., 1992, p. 378.

Schiller NB, Shah PM, Crawford M, et al. "Recommendations for Quantitation of the Left Ventricle by Two-Dimensional Echocardiography." *Journal of the American Society of Echocardiography* 2(5):364, 1989.

Cardiac Output

Belenkie I, Nutter DO, Clark DW, McCraw DB, Raizner AE. "Assessment of Left Ventricular Dimensions and Function by Echocardiography." *American Journal of Cardiology* 31:755-762, June 1973

Haites NE, McLennan FM, Mowat DHR, Rawles JM. "Assessment of Cardiac Output by Ultrasound Technique Alone." *British Heart Journal* 53:123-129, 1985.

Huntsman LL, Stewart DK, Barnes SR, Franklin SB, Colocousis JS, Hessel EA. "Noninvasive Doppler Determination of Cardiac Output in Man." *Circulation* 67(3):593-602, 1983.

Ihlen H, Amlie JP, Dale J, et. al. "Determination of cardiac output by Doppler echocardiography." *British Heart Journal* 51:54-60, 1984.

Left Ventricular End-Diastolic Volume and Left Ventricular End-Systolic Volume

Teichholz Formula

Teichholz LE, Kreulen T, Herman MV, Gorlin R. "Problems in Echocardiographic Volume Determinations: Echocardiographic-Angiographic Correleations in the Presence or Absence of Asynergy." *American Journal of Cardiology* 37(1):7-11, 1976.

Ejection Fraction

Pombo JF, Troy BL, Russell RO. "Left Ventricular Volumes and Ejection Fraction by Echocardiography." *Circulation* 43:480-490, 1971.

Fractional Shortening

Belenkie I, Nutter DO, Clark DW, McCraw DB, Raizner AE. "Assessment of Left Ventricular Dimensions and Function by Echocardiography." *American Journal of Cardiology* 31:755-762, June 1973

AO/LA (Aorta/Left Atrium) Ratio

Roelandt J. Practical Echocardiography in Ultrasound in Biomedicine, No. 1. Letchworth, Herts, England: Research Studies Press (a division of John Wiley & Sons Ltd), 1977, p. 270.

Schiller NB, Shah PM, Crawford M, et al. "Recommendations for Quantitation of the Left Ventricle by Two-Dimensional Echocardiography." *Journal of the American Society of Echocardiography* 2(5):364, 1989.

6 - 4 System Reference

Heart Rate

Urdang, L Ed. Mosby's Medical & Nursing Dictionary. St. Louis, Missouri: The C.V. Mosby Company, 1983, p. 492.

Stroke Index

Görge G, Erbel R, Brennecke R, Rupprecht HJ, Todt M, Meyer J. "High-Resolution Two-dimensional Echocardiography Improves the Quantification of Left Ventricular Function." *Journal of the American Society of Echocardiography* 5(2):125-134, 1992.

Stroke Volume

Görge G, Erbel R, Brennecke R, Rupprecht HJ, Todt M, Meyer J. "High-Resolution Two-dimensional Echocardiography Improves the Quantification of Left Ventricular Function." *Journal of the American Society of Echocardiography* 5(2):125-134, 1992.

Roelandt J. Practical Echocardiography in Ultrasound in Biomedicine, No. 1. Letchworth, Herts, England: Research Studies Press (a division of John Wiley & Sons Ltd), 1977, p. 270.

Doppler Mode Measurements and Calculations

Doppler References

Burns PN. "The Physical Principles of Doppler and Spectral Analysis." *Journal of Clinical Ultrasound*, 15:567-590, 1987.

Acceleration Slope/Time

Gardin JM, Burn CS, Childs WJ, Henry WL. "Evaluation of blood flow velocity in the ascending aorta and main pulmonary artery of normal subjects by Doppler echocardiography." *American Heart Journal*, 107(2):310-319, 1984.

Deceleration Slope/Time

Gardin JM, Burn CS, Childs WJ, Henry WL. "Evaluation of blood flow velocity in the ascending aorta and main pulmonary artery of normal subjects by Doppler echocardiography." *American Heart Journal*, 107(2):310-319, 1984.

Pressure Half-Time

Hatle L, Angelsen B, Tromsdal A. "Noninvasive Assessment of Atrioventricular Pressure Half-time by Doppler Ultrasound" *Circulation* 60(5):1096-1103, 1979.

MVA (Mitral Valve Area Continuity Equation)

Hatle L, Angelsen B, Tromsdal A. "Noninvasive Assessment of Atrioventricular Pressure Half-time by Doppler Ultrasound" *Circulation* 60(5):1096-1103, 1979.

AVA (Aortic Valve Area)

Oh JK, Taliercio CP, Holmes DR, et. al. "Prediction of the Severity of Aortic Stenosis by Doppler Aortic Valve Area Determination: Prospective Doppler-Catheterization Correlation in 100 Patients." *Journal of the American College of Cardiology* 11(6):1227-1234, 1988.

Richards KL, Cannon SR, Miller JF, Crawford MH. "Calculation of aortic valve area by Doppler echocardiography: a direct application of the continuity equation." *Circulation* 73(5):964-969, 1986.

Heart Rate

Cohn PF, Brown EJ, Vlay SC. *Clinical Cardiovascular Physiology*. Philadelphia, Pennsylvania: W.B. Saunders Company, 1985, pp. 85-86.

Urdang, L Ed. Mosby's Medical & Nursing Dictionary. St. Louis, Missouri: The C.V. Mosby Company, 1983, p. 492.

System Reference 6 - 5

CO (Cardiac Output)

- Calafiore P, Stewart WJ. "Doppler Echocardiographic Quantitation of Volumetric Flow Rate." *Cardiology Clinics* 8(2):191-202, 1990.
- Haites NE, McLennan FM, Mowat DHR, Rawles JM. "Assessment of Cardiac Output by Ultrasound Technique Alone." *British Heart Journal* 53:123-129, 1985.
- Huntsman LL, Stewart DK, Barnes SR, Franklin SB, Colocousis JS, Hessel EA. "Noninvasive Doppler Determination of Cardiac Output in Man." *Circulation* 67(3):593-602, 1983.
- Ihlen H, Amlie JP, Dale J, et. al. "Determination of cardiac output by Doppler echocardiography." British Heart Journal 51:54-60, 1984.
- Magnin PA, Stewart JA, Myers S, von Ramm O, Kisslo JA. "Combined Doppler and Phased-array Echocardiographic Estimation of Cardiac Output." *Circulation* 63(2):388-392, 1981.

MV E/A (Mitral Valve, E point to A point Ratio)

Maron BJ, Spirito P, Green KJ, Wesley YE, Bonow RO, Arce J. "Noninvasive Assessment of Left Ventricular Diastolic Function by Pulsed Doppler Echocardiography in Patients with Hypertrophic Cardiomyopathy." *Journal of the American College of Cardiology* 10(4):733-742, 1987.

MV A/E (Mitral Valve, A point to E point Ratio)

Maron BJ, Spirito P, Green KJ, Wesley YE, Bonow RO, Arce J. "Noninvasive Assessment of Left Ventricular Diastolic Function by Pulsed Doppler Echocardiography in Patients with Hypertrophic Cardiomyopathy." *Journal of the American College of Cardiology* 10(4):733-742, 1987.

MV CA/CE (Mitral Valve, CA amplitude to CE amplitude Ratio)

Maron BJ, Spirito P, Green KJ, Wesley YE, Bonow RO, Arce J. "Noninvasive Assessment of Left Ventricular Diastolic Function by Pulsed Doppler Echocardiography in Patients with Hypertrophic Cardiomyopathy." *Journal of the American College of Cardiology* 10(4):733-742, 1987.

IVRT (Isovolumic Relaxation Time)

- Hatle L, Angelsen B, Tromsdal A. "Non-invasive estimation of pulmonary artery systolic pressure with Doppler ultrasound" *British Heart Journal* 45:157-165, 1981.
- Stevenson, JG. "Comparison of Several Noninvasive Methods for Estimation of Pulmonary Artery Pressure." *Journal of the American Society of Echocardiography*, 2(3):157-166, 1989.

LVIMP (Left Ventricular Index of Myocardial Performance)

Tei C, Ling LH, Hodge DO, Bailey KR, Oh JK, Rodeheffer RJ, Tajik AJ, Seward JB. "New Index of Combined Systolic and Diastolic Myocardial Performance: A Simple and Reproducible Measure of Cardiac Function – A Study in Normals and Dilated Cardiomyopathy." *Journal of Cardiology*, 26:357-366, 1995.

RVIMP (Right Ventricular Index of Myocardial Performance)

Tei C, Dujardin KS, Hodge DO, et al. "Doppler echocardiographic index for assessment of global right ventricular function." *Journal American Society of Echocardiography*, 9:838-847, 1996.

Right Ventricular Systolic Pressure (RVSP)

Yock PG, Popp RL. "Noninvasive estimation of right ventricular systolic pressure by Doppler ultrasound in patients with tricuspid regurgitation." *Circulation* 70(4):657-662, 1984.

TR V max (Tricuspid Regurgitant Jet Plus Right Atrial Pressure)

Yock PG, Popp RL. "Noninvasive estimation of right ventricular systolic pressure by Doppler ultrasound in patients with tricuspid regurgitation." *Circulation* 70(4):657-662, 1984.

6 - 6 System Reference

Max PG (Maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

Mean PG (Mean Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

AV PG max (Aortic Valve maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

AV PG mean (Aortic Valve mean Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

MV PG max (Mitral Valve maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

MV PG mean (Mitral Valve mean Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

MR PG max (Mitral Regurgitation maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

PV PG max (Pulmonary Valve maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

PV PG mean (Pulmonary Valve mean Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

System Reference 6 - 7

TR PG max (Tricuspid Regurgitation maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

TR PG mean (Tricuspid Regurgitation mean Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

TV PG max (Tricuspid Valve maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

TV PG mean (Tricuspid Valve mean Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

LVOT PG max (Left Ventricular Outflow Tract maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

LVOT PG mean (Left Ventricular Outflow Tract mean Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

VSD PG max (Ventricular Septal Defect maximum Pressure Gradient)

Yoganathan AP, Cape EG, Sung H, Williams FP, Jimoh A. "Review of Hydrodynamic Principles for the Cardiologist: Applications to the Study of Blood Flow and Jets by Imaging Techniques." *Journal of the American College of Cardiology*, 12(5):1344-1353, 1988.

Additional Cardiac References

Left Atrial and Right Atrial Volumes

Bommer W, Weinert L, Neumann A, et al. "Determination of Right Atrial and Right Ventricular Size by Two-Dimensional Echocardiography." *Circulation* 60(1):91-100. 1979.

Lambertz H, Flachskampf FA, Heiliger R, et al. "New Echocardiographic and Angiographic Methods for Right Atrial Volume Determination: In Vitro Validation and In Vivo Results." *International Journal of Cardiac Imaging* 5(1):39-51, 1989.

Schabelman SE, Schiller NB, Anschultz RA, et al. "Comparison of Four Two-Dimensional Echocardiographic Views for Measuring Left Atrial Size." *American Journal of Cardiology* 41:391-6. 1978.

Wang Y, Gutman JM, Heilbron D, et al. "Atrial Volume in a Normal Adult Population by Two-Dimensional Echocardiography." *Chest* 86(4):595-601, 1984.

6 - 8 System Reference

Left Ventricular Mass

- Bommer W, Weinert L, Neumann A, et al. "Determination of Right Atrial and Right Ventricular Size by Two-Dimensional Echocardiography." *Circulation* 60(1):91-100. 1979.
- Reichek N, Helak J, Plappert T, et al. "Anatomic Validation of Left Ventricular Mass Estimates from Clinical Two-Dimensional Echocardiography: Initial Results." *Circulation* 67(2):348-52, 1983.

Mitral Valve Area and Aortic Valve Area Using Continuity Equation with both the Peak Velocity and Velocity-time Integral

- Berger M, Berdoff RL, Gallerstein PE, et al. "Evaluation of Aortic Stenosis by Continuous Wave Doppler Ultrasound." *Journal of the American College of Cardiology* 3(1):150-6, 1984.
- Gossler KB, Goldberg SJ. "Velocity Gradients Across Normal Cardiac Valves." *American Journal of Cardiology* 67(1):99-101, 1991.
- Hatle L, Angelsen B. *Doppler Ultrasound in Cardiology: Physical Principles and Clinical Applications*, 2nd edition. Philadelphia, Pennsylvania: Lea & Febiger, 1985.
- Holen J, Aaslid R, Landmark K, et al. "Determination of Effective Orifice Area in Mitral Stenosis from Non-Invasive Ultrasound Doppler Data and Mitral Flow Rate." *Acta Medica Scandinavica* 201(1-2):83-8, 1977.
- Labovitz A. "Pressure Halftime, Deceleration Rate." American Heart Journal 8:1341-7, 1986.
- Loperfido F, Laurenzi F, Gimigliano F, et al. "A Comparison of the Assessment of Mitral Valve Area by Continuous Wave Doppler and by Cross Sectional Echocardiography. *British Heart Journal* 57(4):348-55, 1987.
- Nakatani S, Masuyama T, Kodama K, et al. "Value and Limitations of Doppler Echocardiography in the Quantification of Stenotic Mitral Valve Area: Comparison of the Pressure Half-Time and the Continuity Equation Methods. *Circulation* 77(1):78-85, 1988.
- Nishimura RA, Tajik AJ. "Quantitative Hemodynamics by Doppler Echocardiography: A Noninvasive Alternative to Cardiac Catheterization." *Progress in Cardiovascular Diseases* 36(4):309-42, 1994.
- Oh JK, Taliercio CP, Holmes DR, et. al. "Prediction of the Severity of Aortic Stenosis by Doppler Aortic Valve Area Determination: Prospective Doppler-Catheterization Correlation in 100 Patients." *Journal of the American College of Cardiology* 11(6):1227-1234, 1988.
- Otto CM, Pearlman AS, Comess KA, et al. "Determination of the Stenotic Aortic Valve Area in Adults Using Doppler Echocardiography." *Journal of the American College of Cardiology* 7(3):509-17, 1986
- Otto CM, Pearlman AS, Gardner CL, et al. "Simplification of the Doppler Continuity Equation for Calculating Stenotic Aortic Valve Area." *Journal of the American Society of Echocardiography* 1(2):155-7, 1988
- Skjaerpe T, Hegrenaes L, Hatle L. "Noninvasive Estimation of Valve Area in Patients with Aortic Stenosis by Doppler Ultrasound and Two-Dimensional Echocardiography." *Circulation* 72(4):810-8, 1985.
- Stamm RB, Martin RP. "Quantification of Pressure Gradients Across Stenotic Valves by Doppler Ultrasound." *Journal of the American College of Cardiology* 2(4):707-18, 1983.
- Taylor R. "Evolution of the Continuity Equation in the Doppler Echocardiographic Assessment of the Severity of Valvular Aortic Stenosis." *Journal of the American Society of Echocardiography* 3(4):326-30, 1990.
- Thomas JD, Weyman AE. "Doppler Mitral Pressure Half-Time: A Clinical Tool in Search of Theoretical Justification." *Journal of the American College of Cardiology* 10(4):923-9, 1987.
- Wranne B, Ask P, Loyd D. "Analysis of Different Methods of Assessing the Stenotic Mitral Valve Area with Emphasis on the Pressure Gradient Half-Time Concept." *American Journal of Cardiology* 66(5):614-20, 1990.
- Young JB, Quinones MA, Waggoner AD, et al. "Diagnosis and Quantification of Aortic Stenosis with Pulsed Doppler Echocardiography." *American Journal of Cardiology* 45(5):987-94, 1980.
- Zoghbi WA, Farmer KL, Soto JG, et al. "Accurate Noninvasive Quantification of Stenotic Aortic Valve Area by Doppler Echocardiography." *Circulation* 73(3):452-9, 1986.

System Reference 6 - 9

Cardiac Normal Range Values

- Baumgartner H, Hung J, Bermego J, Chambers JB, Evangelista A, Griffin BP, et al. "Echocardiographic Assessment of Valve Stenosis: EAE/ASE Recommendations for Clinical Practice." *Journal of the American Society of Echocardiography* 22(1): 1-23, 2009.
- Lang RM, Bierig M, Devereux RB, Flachskampf FA, Foster E, Pellikka PA, et al. "Recommendations for Chamber Quantification." *Journal of the American Society of Echocardiography* 18(12):1440-1463, 2005.

Shortening / Wall Stress

- Colan SD, Borow KM, Newmann A. "Left ventricular end-systolic wall stress-velocity of fiber shortening relation: A load independent index of myocardial contractility." *JAmColl Cardiol* 4:715-724, 1984.
- Engle SJ, DiSessa TG, Perloff JK, et al. "Mitral valve E point to ventricular septal separation in infants and children." *AmJCardiol* 52:1084-1087, 1983.
- Ginzton LE, Kulick D "Mitral valve E-point septal separation as an indicator of ejection fraction in patients with reversed septal motion." *Chest* 88:429-431, 1985.
- Massie BM, Schiller NB, Ratshin RA, et al. "Mitral-septal separation: A new echocardiographic index of left ventricular function." *AmJCardiol* 39:1008-1016, 1977.
- Quinones MA, Mokotoff DM, Nouri S, et al. "Noninvasive quantification of left ventricular wall stress: Validation of method and application to assessment of chronic pressure overload." *AmJCardiol* 45:782-790, 1980.
- Reichek N, Wilson J, St. John Sutton M, Plappert TA, Goldberg S, Hirshfeld J. "Noninvasive Determination of Left Ventricular End-systolic Stress: Validation of the Method and Initial Application." *Circulation* 65(1), 1982.
- Sahn DJ, Deely WJ, Hagen AD, et al. "Echocardiographic assessment of left ventricular performance in normal newborns." *Circulation* 49:232-236, 1974.

6 - 10 System Reference

7 Obstetrical References

Ob	stetrical References	. 3
	Mean Gestational Sac Diameter	. 3
	Gestational Sac	. 3
	Crown Rump Length	. 3
	Biparietal Diameter	. 3
	Occipital Frontal Diameter	. 4
	Abdominal Transverse Diameter	. 4
	Abdominal Sagittal Diameter	. 4
	Fractional Shortening	. 4
	Fetal Weight Estimation	. 4
	Head Circumference	. 4
	Abdominal Circumference	. 4
	AXT	. 5
	Fetal Trunk Area	. 5
	Femur Length	. 5
	Humerus Length	. 5
	Ulna Length	. 5
	Binocular Distance	. 5
	Tibia Length	. 5
	Foot Length	. 5
Gra	owth Analysis Ratios and Indexes	6
GIC	Cephalic Index	
	Fetal Weight Estimation	
	Femur Length/Abdominal Circumference Ratio	
	Femur Length/Biparietal Diameter Ratio	
	Head Circumference/Abdominal Circumference Ratio	
Ме	nstrual Age by Ultrasound and Estimated Date of Confinement	. 6
	CLINICAL EDC - Estimated Date of Confinement by Last Menstrual	_
	Period	
	CLINICAL MA - Clinical Menstrual Age	
	US MA - Composite Menstrual Age Estimation by Ultrasound	
	Simple Average - US MA(ave)	
	Regression Equations, Hadlock	
	US EDC Estimated Date of Confinement by Ultrasound	. 7

Par	Parameters for Growth Analysis Graphs7			
	Mean Gestational Sac Diameter	. 7		
	Gestational Sac	. 7		
	Crown Rump Length	. 7		
	Biparietal Diameter	8 .		
	Biparietal Diameter (Outer to Inner)	8		
	Biparietal Diameter (Outer to Outer)	8 .		
	Occipital Frontal Diameter	8		
	Head Circumference	9		
	Head Circumference (Plotted)	9		
	Abdominal Circumference	9		
	Abdominal Circumference (Plotted)	. 9		
	AXT	9		
	Facial Angle1	10		
	Fetal Trunk Area1	10		
	Femur Length	10		
	Humerus Length1	10		
	Ulna Length	11		
	Tibia Length1	11		
	Foot Length	11		
	Thoracic Circumference	11		
	Clavicle Length1	11		
	Renal Length	11		
	Renal Anterior Posterior	11		
	Transcerebellar Diameter	12		
	Cisterna Magna (Posterior Fossa)	12		
	Anterior Cerebral Ventricle Diameter	12		
	Posterior Cerebral Ventricle Diameter	12		
	Umbilical Artery (Resistive Index)	12		
	Umbilical Artery (Pulsatility Index)			
	Middle Cerebral Artery (Resistive Index)	12		
	Middle Cerebral Artery (Pulsatility Index)	12		
Est	imated Fetal Weight (EFW) for Growth Analysis Graphs1	13		
Rat	ios and Indices for Growth Analysis Graphs1	13		
	AFI (Amniotic Fluid Index)			
	LVW/HW (Lateral Ventricular Width/Hemispheric Width) Ratio			
	TCD/AC Ratio			
Oth	er Calculations1	13		
J (11	Corrected BPD			
	Corrected Dr D	J		

Obstetrical References

Mean Gestational Sac Diameter

Hellman LM, Kobayashi M, Fillisti L, Lavenhar M, Cromb E. "Growth and development of the human fetus prior to the twentieth week of gestation." *American Journal of Obstetrics and Gynecology* 103(6):789, 1969.

Rempen A. "Biometrie in der Frühgravidität (I. Trimenon) (Biometry in Early Pregnancy (1st Trimester))." *Der Frauenarzt* 32:425, 1991.

Gestational Sac

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Tokvo

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." Perinatal Care 8:719-726.

Crown Rump Length

Hadlock FP, Shah YP, Kanon DJ, Lindsey JV. "Fetal Crown-Rump Length: Reevaluation of Relation to Menstrual Age (5-18 weeks) with High-Resolution Real-Time US." *Radiology* 182(2):501, 1992

Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985, p. 439.

Lasser DM, Peisner DB, Vollebergh J, Timor-Tritsch I. "First-trimester fetal biometry using transvaginal sonography." *Ultrasound in Obstetrics and Gynecology* 3:104, 1993.

Robinson HP and Fleming JEE. "A critical evaluation of sonar 'crown-rump length' measurements." British Journal of Obstetrics and Gynaecology 82:702, 1975.

ASUM:

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Tokvo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." Perinatal Care 8:719-726.

Biparietal Diameter

Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.

Lasser DM, Peisner DB, Vollebergh J, Timor-Tritsch I. "First-trimester fetal biometry using transvaginal sonography." *Ultrasound in Obstetrics and Gynecology* 3:104, 1993.

Merz E. *Ultrasound in Gynecology and Obstetrics*. Stuttgart and New York: Thieme Medical Publishers, Inc., 1991, p. 326.

Rempen A. "Biometrie in der Frühgravidität (I. Trimenon) (Biometry in Early Pregnancy (1st Trimester))." *Der Frauenarzt* 32:425, 1991.

ASUM:

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

System Reference 7 - 3

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Tokvo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." Perinatal Care 8:719-726.

Occipital Frontal Diameter

ASUM

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

Abdominal Transverse Diameter

Merz E, Wellek S. "Normal Fetal Growth Profile – A Uniform Model for Calculating Normal Current Head and Abdomen Parameters and Long Limb Bones." *Ultraschall in der Medizin* 17(4):153-162, 1996.

Abdominal Sagittal Diameter

Merz E, Wellek S. "Normal Fetal Growth Profile – A Uniform Model for Calculating Normal Current Head and Abdomen Parameters and Long Limb Bones." *Ultraschall in der Medizin* 17(4):153-162, 1996.

Fractional Shortening

Cyr DR, Guntheroth WG, Mack LA. "Fetal Echocardiography." In: Berman MC (ed.) Diagnostic Medical Sonography, Vol I: Obstetrics and Gynecology, 249-271, 1991.

Fetal Weight Estimation

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Tokyo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." *Perinatal Care* 8:719-726.

Head Circumference

Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.

Lasser DM, Peisner DB, Vollebergh J, Timor-Tritsch I. "First-trimester fetal biometry using transvaginal sonography." *Ultrasound in Obstetrics and Gynecology* 3:104, 1993.

Merz E. *Ultrasound in Gynecology and Obstetrics*. Stuttgart and New York: Thieme Medical Publishers, Inc., 1991, p. 326.

Abdominal Circumference

Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.

Lasser DM, Peisner DB, Vollebergh J, Timor-Tritsch I. "First-trimester fetal biometry using transvaginal sonography." *Ultrasound in Obstetrics and Gynecology* 3:104, 1993.

Merz E. *Ultrasound in Gynecology and Obstetrics*. Stuttgart and New York: Thieme Medical Publishers, Inc., 1991, p. 326.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

7 - 4 System Reference

AXT

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Tokvo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." Perinatal Care 8:719-726.

Fetal Trunk Area

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Femur Length

Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.

Jeanty P, Rodesch F, Delbeke D, Dumont JE. "Estimation of Gestational Age from Measurements of Fetal Long Bones." *Journal of Ultrasound in Medicine* 3:75, 1984.

Merz E. *Ultrasound in Gynecology and Obstetrics*. Stuttgart and New York: Thieme Medical Publishers, Inc., 1991, p. 326.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Tokvo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." *Perinatal Care* 8:719-726.

Humerus Length

Jeanty P, Rodesch F, Delbeke D, Dumont JE. "Estimation of Gestational Age from Measurements of Fetal Long Bones." *Journal of Ultrasound in Medicine* 3:75, 1984.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Ulna Length

Jeanty P, Rodesch F, Delbeke D, Dumont JE. "Estimation of Gestational Age from Measurements of Fetal Long Bones." *Journal of Ultrasound in Medicine* 3:75, 1984.

Binocular Distance

Jeanty P, Cantraine F, Cousaert E, Romero R, Hobbins JC. "The Binocular Distance: A New Way to Estimate Fetal Age." *Journal of Ultrasound in Medicine* 3:241, 1984.

Tongsong T, Wanapirak C, Jesadapornchai S, Tathayathikom E. "Fetal binocular distance as a predictor of menstrual age." *International Journal of Gynecology and Obstetrics* 38:87, 1992.

Tibia Length

Jeanty P, Rodesch F, Delbeke D, Dumont JE. "Estimation of Gestational Age from Measurements of Fetal Long Bones." *Journal of Ultrasound in Medicine* 3:75, 1984.

Foot Length

Mercer BM, Sklar S, Shariatmadar A, Gillieson MS, Dalton ME. "Fetal foot length as a predictor of gestational age." *American Journal of Obstetrics and Gynecology* 156(2):350, 1987.

System Reference 7 - 5

Growth Analysis Ratios and Indexes

Cephalic Index

- Chitty, LS, Altman, DG. "Charts of Fetal Size: 2. Head Measurements." *British Journal of Obstetrics & Gynaecology* 101:35-43, 1994.
- Hadlock FP, Deter RL, Carpenter RJ, Park SK. "Estimating Fetal Age: Effect of Head Shape on BPD." *American Journal of Roentgenology* 137:83, 1981.

Fetal Weight Estimation

- Hadlock FP, Harrist RB, Sharman RS, Deter RL, Park SK. "Estimation of fetal weight with the use of head, body, and femur measurements—A prospective study." *American Journal of Obstetrics and Gynecology* 151:333, 1985.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1986.
- Merz E. *Ultrasound in Gynecology and Obstetrics*. Stuttgart and New York: Thieme Medical Publishers, Inc., 1991, p. 157.
- Shepard MJ, Richards VA, Berkowitz RL, Warsof SL, Hobbins JC. "An evaluation of two equations for predicting fetal weight by ultrasound." *American Journal of Obstetrics and Gynecology*. 142(1):47, 1982.

Femur Length/Abdominal Circumference Ratio

Hadlock FP, Deter RL, Harrist RB, Roecker E, Park SK. "A Date-Independent Predictor of Intrauterine Growth Retardation: Femur Length/Abdominal Circumference Ratio." *American Journal of Roentgenology* 141: 979, 1983.

Femur Length/Biparietal Diameter Ratio

Hohler CW, Quetel TA. "Comparison of ultrasound femur length and biparietal diameter in late pregnancy." *American Journal of Obstetrics and Gynecology* 141(7):759, 1981.

Head Circumference/Abdominal Circumference Ratio

- Campbell S, Thoms A. "Ultrasound measurement of the fetal head to abdomen circumference ratio in the assessment of growth retardation." *British Journal of Obstetrics and Gynaecology*, 84:165, 1977.
- Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.

Menstrual Age by Ultrasound and Estimated Date of Confinement

CLINICAL EDC - Estimated Date of Confinement by Last Menstrual Period

280 days added to date of LMP date.

CLINICAL MA - Clinical Menstrual Age

Source data for Clinical MA is determined by the user during the Patient ID operation calculated weeks and days since LMP.

7 - 6 System Reference

US MA - Composite Menstrual Age Estimation by Ultrasound

Simple Average - US MA(ave)

The sum of all menstrual ages determined by single parameter tables/formulas, divided by the number of parameters summed.

Regression Equations, Hadlock

Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.

US EDC Estimated Date of Confinement by Ultrasound

280 days - today's US MA (in days), add to today's date = US EDC

Parameters for Growth Analysis Graphs

The references in this section are used to analyze fetal growth by plotting a measured parameter against clinical menstrual age. The plotted points are displayed on a graph that indicates the 5%, 50%, and 95% for an expected parameter measurement determined by a function using menstrual age.

Mean Gestational Sac Diameter

Rempen A. "Biometrie in der Frühgravidität (I. Trimenon) (Biometry in Early Pregnancy (1st Trimester))." *Der Frauenarzt* 32:425, 1991.

Gestational Sac

Tokyo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." *Perinatal Care* 8:719-726.

Crown Rump Length

Hadlock FP, Shah YP, Kanon DJ, Lindsey JV. "Fetal Crown-Rump Length: Reevaluation of Relation to Menstrual Age (5-18 weeks) with High-Resolution Real-Time US." *Radiology* 182(2):501, 1992

Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985.

Rempen A. "Biometrie in der Frühgravidität (I. Trimenon) (Biometry in Early Pregnancy (1st Trimester))." *Der Frauenarzt* 32:425, 1991, p. 427.

Robinson HP and Fleming JEE. "A critical evaluation of sonar 'crown-rump length' measurements." British Journal of Obstetrics and Gynaecology 82:702, 1975.

ASUM

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." *Obstetrics and Gynecology* 47:547-556, 1983. **Tokyo:**

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." *Perinatal Care* 8:719-726.

System Reference 7 - 7

Biparietal Diameter

- Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985, p. 176.
- Lasser DM, Peisner DB, Vollebergh J, Timor-Tritsch I. "First-trimester fetal biometry using transvaginal sonography." *Ultrasound in Obstetrics and Gynecology* 3:104, 1993.
- Merz E, Kim-Kern M-S, Pehl S. "Ultrasonic Mensuration of Fetal Limb Bones in the Second and Third Trimesters." *Journal of Clinical Ultrasound* 15:175, March/April 1987.
- Rempen A. "Biometrie in der Frühgravidität (I. Trimenon) (Biometry in Early Pregnancy (1st Trimester))." *Der Frauenarzt* 32:425, 1991, p. 427.
- Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.
- Verburg BO, Steegers EA, De Ridder M, Snijders RJ, Smith E, Hofman A, et al. "New charts for ultrasound dating of pregnancy and assessment of fetal growth: longitudinal data from a population-based cohort study." *Ultrasound in Obstetrics and Gynecology* 31:388-396, 2008.

ASUM

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

JSHM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Tokyo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." Perinatal Care 8:719-726.

Biparietal Diameter (Outer to Inner)

Chitty, LS, Altman, DG. "Charts of Fetal Size: 2. Head Measurements." *British Journal of Obstetrics & Gynaecology* 101:35-43, 1994.

Biparietal Diameter (Outer to Outer)

Chitty, LS, Altman, DG. "Charts of Fetal Size: 2. Head Measurements." *British Journal of Obstetrics & Gynaecology* 101:35-43, 1994.

Occipital Frontal Diameter

- Chitty, LS, Altman, DG. "Charts of Fetal Size: 2. Head Measurements." *British Journal of Obstetrics & Gynaecology* 101:35-43, 1994.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985, p. 176.
- Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.

ASUM:

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

7 - 8 System Reference

Head Circumference

- Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985, p. 176.
- Merz E. *Ultrasound in Gynecology and Obstetrics*. Stuttgart and New York: Thieme Medical Publishers, Inc., 1991, p. 312.
- Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48. 1994.
- Verburg BO, Steegers EA, De Ridder M, Snijders RJ, Smith E, Hofman A, et al. "New charts for ultrasound dating of pregnancy and assessment of fetal growth: longitudinal data from a population-based cohort study." *Ultrasound in Obstetrics and Gynecology* 31:388-396, 2008.

ASUM:

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302. 2000.

Head Circumference (Plotted)

Chitty, LS, Altman, DG. "Charts of Fetal Size: 2. Head Measurements." *British Journal of Obstetrics & Gynaecology* 101:35-43, 1994.

Abdominal Circumference

- Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.
- Jeanty P, Cousaert E, Cantraine F. "Normal growth of the abdominal perimeter." *American Journal of Perinatalogy* 1:136, 1984, p. 133.
- Merz E. *Ultrasound in Gynecology and Obstetrics*. Stuttgart and New York: Thieme Medical Publishers, Inc., 1991, p. 312.
- Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.
- Verburg BO, Steegers EA, De Ridder M, Snijders RJ, Smith E, Hofman A, et al. "New charts for ultrasound dating of pregnancy and assessment of fetal growth: longitudinal data from a population-based cohort study." *Ultrasound in Obstetrics and Gynecology* 31:388-396, 2008.

ASUM:

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

JSUM

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Abdominal Circumference (Plotted)

Chitty, LS, Altman, DG. "Charts of Fetal Size: 2. Head Measurements." *British Journal of Obstetrics & Gynaecology* 101:35-43, 1994.

AXT

Tokyo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." Perinatal Care 8:719-726.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

System Reference 7 - 9

Facial Angle

Sonek J. "Fronto-Maxillary Facial Angle in Screening for Trisomy 21." Fetal Medicine Foundation of the United States of America 3(1):1-2, 2007.

Fetal Trunk Area

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Femur Length

- Chitty LS, Altman DG. "Charts of fetal size: limb bones." *British Journal of Obstetrics & Gynaecology* 109:919-929, August 2002.
- Hadlock FP, Deter RL, Harrist RB, Park SK. "Estimating Fetal Age: Computer-Assisted Analysis of Multiple Fetal Growth Parameters." *Radiology* 152:497, 1984.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985.
- Jeanty P, Dramaix-Wilmet M, van Kerkem J, Petroons P, Schwers J. "Ultrasonic Evaluation of Fetal Limb Growth, Part II." *Radiology* 143:751, 1982.
- Merz E, Kim-Kern M-S, Pehl S. " Ultrasonic Mensuration of Fetal Limb Bones in the Second and Third Trimesters." *Journal of Clinical Ultrasound* 15:175, March/April 1987.
- Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.
- Verburg BO, Steegers EA, De Ridder M, Snijders RJ, Smith E, Hofman A, et al. "New charts for ultrasound dating of pregnancy and assessment of fetal growth: longitudinal data from a population-based cohort study." *Ultrasound in Obstetrics and Gynecology* 31:388-396, 2008.

ASUM:

Australian Society of Ultrasound Medicine (ASUM) - Policy on Obstetric Exams, 1998.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Tokyo:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." *Perinatal Care* 8:719-726.

Humerus Length

- Chitty LS, Altman DG. "Charts of fetal size: limb bones." *British Journal of Obstetrics & Gynaecology* 109:919-929, August 2002.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985.
- Jeanty P, Dramaix-Wilmet M, van Kerkem J, Petroons P, Schwers J. "Ultrasonic Evaluation of Fetal Limb Growth, Part II." *Radiology* 143:751, 1982.
- Merz E, Kim-Kern M-S, Pehl S. "Ultrasonic Mensuration of Fetal Limb Bones in the Second and Third Trimesters." *Journal of Clinical Ultrasound* 15:175, March/April 1987.

ASIIM

Westerway SC. "Ultrasonic Fetal Measurements: New Australian Standards for the New Millennium." Aust NZ J Obstet Gynaecol 40:3:297-302, 2000.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

7 - 10 System Reference

Ulna Length

- Chitty LS, Altman DG. "Charts of fetal size: limb bones." *British Journal of Obstetrics & Gynaecology* 109:919-929, August 2002.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1986.
- Jeanty P, Dramaix-Wilmet M, van Kerkem J, Petroons P, Schwers J. "Ultrasonic Evaluation of Fetal Limb Growth, Part II." *Radiology* 143:751, 1982.
- Merz E, Kim-Kern M-S, Pehl S. "Ultrasonic Mensuration of Fetal Limb Bones in the Second and Third Trimesters." *Journal of Clinical Ultrasound* 15:175, March/April 1987.

Tibia Length

- Chitty LS, Altman DG. "Charts of fetal size: limb bones." *British Journal of Obstetrics & Gynaecology* 109:919-929, August 2002.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985.
- Jeanty P, Dramaix-Wilmet M, van Kerkem J, Petroons P, Schwers J. "Ultrasonic Evaluation of Fetal Limb Growth, Part II." *Radiology* 143:751, 1982.
- Merz E, Kim-Kern M-S, Pehl S. "Ultrasonic Mensuration of Fetal Limb Bones in the Second and Third Trimesters." *Journal of Clinical Ultrasound* 15:175, March/April 1987.

Foot Length

- Chitty LS, Altman DG. "Charts of fetal size: limb bones." *British Journal of Obstetrics & Gynaecology* 109:919-929, August 2002.
- Mercer BM, Sklar S, Shariatmadar A, Gillieson MS, Dalton ME. "Fetal foot length as a predictor of gestational age." *American Journal of Obstetrics and Gynecology* 156(2):350, 1987.

Thoracic Circumference

Chitkara U, Rosenberg J, Chervenak FA, Berkowitz GS, Levine R, Fagerstrom RM, Walker B, Berkowitz RL. "Prenatal sonographic assessment of the fetal thorax: Normal values." *American Journal of Obstetrics and Gynecology* 156:1069, 1987.

Clavicle Length

Yarkoni S, Schmidt W, Jeanty P, Reece EA, Hobbins JC. "Clavicular Measurement: A New Biometric Parameter for Fetal Evaluation." *Journal of Ultrasound in Medicine* 4:467, 1985.

Renal Length

- Bertagnoli L, Lalatta F, Gallicchio R, Fantuzzi M, Rusca M, Zorzoli A, Deter RL. "Quantitative Characterization of the Growth of the Fetal Kidney." *Journal of Clinical Ultrasound* 11:349, 1983.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985.

Renal Anterior Posterior

- Bertagnoli L, Lalatta F, Gallicchio R, Fantuzzi M, Rusca M, Zorzoli A, Deter RL. "Quantitative Characterization of the Growth of the Fetal Kidney." *Journal of Clinical Ultrasound* 11:349, 1983.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1985.

System Reference 7 - 11

Transcerebellar Diameter

Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.

Verburg BO, Steegers EA, De Ridder M, Snijders RJ, Smith E, Hofman A, et al. "New charts for ultrasound dating of pregnancy and assessment of fetal growth: longitudinal data from a population-based cohort study." *Ultrasound in Obstetrics and Gynecology* 31:388-396, 2008.

Cisterna Magna (Posterior Fossa)

Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.

Anterior Cerebral Ventricle Diameter

Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.

Posterior Cerebral Ventricle Diameter

Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.

Umbilical Artery (Resistive Index)

JSUM

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Umbilical Artery (Pulsatility Index)

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 28:844-872, 2001.

Middle Cerebral Artery (Resistive Index)

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Middle Cerebral Artery (Pulsatility Index)

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

7 - 12 System Reference

Estimated Fetal Weight (EFW) for Growth Analysis Graphs

- Hadlock FP, Harrist RB, Martinez-Poyer J. "In Utero Analysis of Fetal Growth: A Sonographic Weight Standard." *Radiology* 181:129, 1991.
- Hansmann M, Hackelöer B-J, Staudach A. *Ultrasound Diagnosis in Obstetrics and Gynecology*. New York: Springer-Verlag, 1986.
- Jeanty P, Cantraine F, Romero R, Cousaert E, Hobbins JC. "A Longitudinal Study of Fetal Weight Growth." *Journal of Ultrasound in Medicine* 3:321, 1984.
- Williams RL, Creasy RK, Cunningham GC, Hawes WE, Norris FD, Tashiro M. "Fetal Growth and Perinatal Viability in California." *Obstetrics and Gynecology* 59:624:632, 1982.
- Yarkoni S, Reece EA, Holford T, O'Connor TZ, Hobbins JC. "Estimated Fetal Weight in the Evaluation of Growth in Twin Gestations: A Prospective Longitudinal Study." *Obstetrics and Gynecology* 69:636, 1987.

JSUM:

Japan Society of Ultrasonics in Medicine. "Standardization of Fetometry and Official Announcement of Diagnostic Guidelines." *J. Med. Ultrasonics* 30:415-440, 2003.

Osaka:

Aoki M, Yamada M. "Examining Fetal Growth." Obstetrics and Gynecology 47:547-556, 1983.

Toyko:

Masuda H, Shinozuka N, Okai T, Mizuno M. "Diagnosis of the Week of Pregnancy and Prognosis." Perinatal Care 8:719-726.

Ratios and Indices for Growth Analysis Graphs

AFI (Amniotic Fluid Index)

Moore TR, Cayle JE. "The amniotic fluid index in normal human pregnancy." *American Journal of Obstetrics and Gynecology* 162:1168, 1990.

LVW/HW (Lateral Ventricular Width/Hemispheric Width) Ratio

Johnson ML, Dunne MG, Mack LA, Rashbaum CL. "Evaluation of Fetal Intracranial Anatomy by Static and Real-Time Ultrasound." *Journal of Clinical Ultrasound* 8:311, 1980.

TCD/AC Ratio

- Meyer WJ, Gauthier DW, Goldenberg B, Santolaya J, Sipos J, Cattledge F. "The Fetal Transverse Cerebellar Diameter/Abdominal Circumference Ratio: A Gestational Age-Independent Method of Assessing Fetal Size." *Journal of Ultrasound in Medicine* 12:379, 1993.
- Snijders RJ, Nicolaides KH. "Fetal biometry at 14-40 weeks' gestation." *Ultrasound in Obstetrics and Gynecology* 4:34-48, 1994.

Other Calculations

Corrected BPD

Doubliet PM, Greenes RA. "Improved Prediction of Gestational Age from Fetal Head Measurements." American Journal of Roentgenology. 142:797, 1984.

System Reference 7 - 13

7 Obstetrical References

7 - 14 System Reference