
New as of: 10.2007



# ORTHOPHOS XG<sup>Plus</sup> DS / Ceph ORTHOPHOS XG 5 DS / Ceph ORTHOPHOS XG 3 DS

## **Maintenance Instructions**



# **General information**

## **ATTENTION!**

Proper shielding of room and operator position is essential.

Since these requirements vary from state to state it is the assembler's/installer's responsibility that all local radiation safety requirements are met.

New as of: 10.2007

## Changes since the last version: 07.2005

Chapter or section	page
12 Checking the laser	45

# Contents

1	General		5
2	Visual Check		6
3	Indicator Lights and audible Signal  Power supply adequacy		
4			
5	kV – verification, kV ramp during panoramic exposure		
6	Tube Current Verification		
7	Exposure Time Verification		17
8	Checking the X-Ray Beam.	Diaphragm/system adjustment menu	
9	Checking the X-Ray Beam for panorama exposure		
	9.1	Preparing the Pan adjustment	
	9.2	Checking the pan sensor adjustment	
	9.3	Checking the pan diaphragm adjustment	
	9.4 9.5	Checking the pan filter adjustment	
	9.6	Checking the TSA sensor (full version only)	
10	Checking the X-Ray Beam	for cephalometer exposure	
	10.1	Preparing the Ceph adjustment	
	10.2	Checking the Ceph primary diaphragm adjustment	
	10.3	Checking the ceph rotation fixpoint adjustment	
	10.4	Checking the ceph main X-ray beam direction adjustment	39
11		the ear plugs	
	11.1	Preparing the ear olives	
	11.2	Checking the ear plug alignment	42
12	Checking the laser		45

Sirona Dental Systems GmbH Maintenance Instructions ORTHOPHOS XG

## General

To stay in compliance with the DHHS requirements the ORTHOPHOS XG must be maintained annually following date of installation.

It is the responsibility of the user to insure that the equipment is maintained with the manufacturer's recommended Maintenance Instructions to insure compliance with the Federal Performance Standard.

The manufacturer and the assembler/installer are relieved from responsibility in those cases where noncompliance with the standard results from the user's failure to have the manufacturer's recommended maintenance performed. The actual maintenance inspection and consequent service must be accomplished by a trained serviceman. Neither the inspection nor service is part of the equipment warranty.

#### **Technical instructions required**

Operating Instructions Service Manual

#### Instruments and adjustment tools required

All measuring devices must be suitable for measurements on the mains potential.

This includes the pulse counter.

This means: A voltage of 1000 V between a connection and ground must be possible.

1. Digital multimeter Fluke 87 III or equivalent. Accuracy:

DC voltage  $\pm$  0.1 % of reading plus 0.02% of range DC current  $\pm$  0.4 % of reading plus 0.1% of range.



Electromechanical pulse counter, model KESSLER ELLIS KT 203 ±1 pulse, or equivalent..



3. Adjustment set with alignment tool for X-ray beam, test block and needle phantom delivered with the unit, (customer's property).



## **ATTENTION**

#### RADIATION!

Observe the radiation protection guide lines as outlined in the Operating Instructions manual.

X-radiation is emitted as long as the release button is depressed.

The X-ray indicator must light up on the Easypad during radiation. An acoustic signal must also be heard.

#### Power Supply Adequacy

To assure that the ORTHOPHOS XG system performance is in accordance with Sirona specifications, an adequate power supply for permanently installation is essential.

The Federal Performance Standard for diagnostic X-ray units, code of Federal Regulations, Title 21 CFR, Subchapter J, mandates an adequate power supply.



#### **Duty Cycle**

Between exposures maintain at least a cool-off time (automatic exposure blockage, see Operating Instructions man-

#### **Operating Instructions**

During measurements and controls it is necessary to energize or de-energize the unit. For all operating steps please refer to the Operating Instructions manual.

#### **CAUTION** with PC Boards!

All PC boards are fitted with electronic components sensitive to electrostatic discharge (ESD). In an environment of moving people electrostatic charges are unavoidable due to friction caused by clothing, carpeting etc.



## **ATTENTION**

To prevent damage of electronic chips do not touch same. Always handle circuit boards by their edges.





#### **ATTENTION**

Electrical Shock Hazard!

Always turn unit OFF before connecting and disconnecting the test leads to the test points

> ON OFF








#### WARNING

Life-threatening voltage on DX6.


# 2 Visual Check



- Look for mechanical damage possibly affecting radiation safety.
- Verify that all labels are affixed and legible.
   Defaced labels must be replaced.
   Order same from Sirona (address, see rear) in writing stating:
- Customer Name
- Customer Address

All Model Numbers with Serial Numbers still legible on the unit for identification purposes. For serial numbers see also **Installation Report/Warranty Passport.** 

# 3 Indicator Lights and audible Signal



#### Unit ON LED

Depress the main switch into the " $\mathbf{I}$ " position to turn unit ON.


The unit adjusts itself automatically, wait about 1 minute.

The "Unit ON LED" in the upper right corner of the **user interface** will then indicate that the unit is ON.

# Testing the keys and the functions on the user interface.

- When the height adjustment is made the loudspeaker should hum.
- If the forehead support functions correctly, the max. holding torque is still present.
- If remote is installed, test the remote keys and display in addition.
- The release button must not be defective or broken.

See also Operating Instructions under "Preparing the Exposure" subchapter "Switching the system on".



#### Make a exposure:

- X-ray head must be in the initial position (If not, press return key R).
- Establish exposure readiness via SIDEXIS.
   For more details and possible error messages see Operating Instructions.
- Set the P1 exposure program using the menu keys (XG 5 / 3) or - + keys (XG<sup>Plus</sup>).
- Select 68kV/8mA using submenu keys (XG 5 / 3) or submenu – + keys (XG<sup>Plus</sup>).

## $oldsymbol{\Delta}$ CAUTION RADIATION

- Depress the exposure button and hold until the exposure terminates automatically.
- The exposure ends when the rotation and radiation automatically switch off.
- The radiation indication must light up during the exposure period.
- Simultaneously an audible beep must sound at the unit.

- Interrupt an exposure deadman feature:
  - Observe a cool-off time of max. 5 mins. between exposures (automatic exposure blockage).
  - Setting same as above.

## $\Delta$ CAUTION RADIATION

 Depress the release button until X-ray lights up and subsequently release – the exposure must terminate immediately. The radiation indicator lights up.




#### ATTENTION

**Defective light indicators** constitute a safety hazard to the patient as well as to the operator.

The user is not permitted to use the unit, until repairs are made!

# 4 Power supply adequacy



- To determine power supply adequacy, the line voltage drop during exposure must be measured.
- 1. Be sure power is disconnected at the central distribution panel!
- Remove front cover (for details see Service Manual).
- Select 300VAC line voltage range on multimeter.
   Connect measuring leads to terminal K1, L and N.
- Connect power and switch unit ON ●.
   Wait 1 min. for self-adjustment of the unit.
   Press key R ② to return X-ray tube head into the initial position.
- 4. Establish exposure readiness via SIDEXIS.
- 5. Select highest exposure level e.g. 90kV/12mA.

## $\Delta$ CAUTION RADIATION

Depress the exposure key until meter reading is obtained.

Line voltage, no load:	Max. permissible line voltage drop:
180 – 208V	9V
208 – 230V	8V
230 – 240V	7.5V
240 – 264V	7V

#### Record reading.


- Turn unit OFF.
- · Remove meter leads and refit cover.




If the voltage drop is not within the specified range advise the customer, that an adequate power supply must be installed. Refer to Pre-Installation Instructions.

Disconnect unit and do not release for use!

# kV - verification, kV ramp during panoramic exposure







## 🔔 WARNING

The electronics of the X-ray tube assembly are always connected to line voltage.

Always switch the X-ray unit off and wait until V203 is no longer illuminated before contacting the test leads.



#### **!** WARNING

The test leads and measuring instruments used must have a dielectric strength of at least 1000V!

Be sure to use a battery-powered measuring instrument with shock-hazard-protected sockets.

Use only test leads with shock protection.



## **!**ATTENTION

The X-ray tube assembly moves during the measurement. Therefore, be sure to use test leads of sufficient length and place the measuring instrument in a location where it is firmly seated so that it doesn't fall down.




Measurements:


62kV correspond to 3.1V, permissible tolerance +/-10%




During exposure the kV is increased in the central region depending on kV/mA selected by up to 10%. This increase can be measured in VDC.


- 1. Remove cover (for details see Service Manual).
- Loosen the four screws A and remove cover plate B of the electronics box.





- 4. Refit cover C and tighten screw D securely.
- Switch unit ON ●.
   Wait 1 min. for self-adjustment of the unit.
   Press key R ❷ to return X-ray tube head into the initial position.
- **6.** Establish exposure readiness via SIDEXIS.
- 7. Select P1 program and 62kV/8mA.





#### Measurement:

## $\Delta$ CAUTION RADIATION

Depress the exposure key until the exposure terminates automatically.


# The following values must be obtained (see also diagram on next page)

- up to 5.25 seconds: 3.1 V ±0.3V
- from 6.25 to 7.85 s KV-ramp: e.g.  $4 V \pm 0.4V$
- after 8.85 seconds: **3 V** ±0.3V




If specified values cannot be obtained, see Service Manual, "Radiograph Density in Central Region Incorrect"

# kV - Verification, kV-ramp during panoramic exposure



## kV ramp diagram

with program P1 and 62kV/8mA set on the Easypad (XG<sup>Plus</sup>) or Multipad (XG 5 / 3) and temple support fully open.



- Turn unit OFF.
- 8. Remove top cover and meter leads.

# **Tube Current Verification**



## **WARNING**

The electronics of the X-ray tube assembly are always connected to line voltage.

Always switch the X-ray unit off and wait until V203 is no longer illuminated before contacting the test leads.



## **WARNING**

The test leads and measuring instruments used must have a dielectric strength of at least 1000V!


Be sure to use a battery-powered measuring instrument with shock-hazard-protected sockets.


Use only test leads with shock protection.




#### **!** WARNING

Be sure to switch the X-ray unit off before removing the jumper for the mA measuring jack.







- Remove jumper A from MA+/MA test points on PC board DX6. Connect digital ammeter to MA+ and MA– and select range 20 mADC.
- 2. Reattach cover C and tighten screw D securely.
- Switch unit ON ●.
   Wait 1 min. for self-adjustment of the unit.
   Press key R ② to return X-ray tube head into the initial position.
- Select 66kV/8mA. Establish exposure readiness via SIDEXIS.
- 5. If P1 program and 66kV/8mA are selected . The unit must be ready for radiation.

#### Measurement:

## $oldsymbol{\Delta}$ CAUTION RADIATION

Depress the exposure key and hold depressed until meter reading is obtained.


The ammeter shall indicate 8mA ±1.6mA. Record reading.



Readings: 1mA corresponds to a tube current of 1mA, permissible tolerance +/-20%.





If specified values cannot be obtained, see Service Manual, chapter "Tube Current Verification".



- If specified value is obtained switch unit OFF.
- 6. Remove upper cover and meter leads
- Replace jumper!

# 7 Exposure Time Verification







## 🔔 WARNING

The electronics of the X-ray tube assembly are always connected to line voltage.

Always switch the X-ray unit off and wait until V203 is no longer illuminated before contacting the test leads.



#### **!** WARNING


The test leads and measuring instruments used must have a dielectric strength of at least 1000V!


Be sure to use a battery-powered measuring instrument with shock-hazard-protected sockets.

Use only test leads with shock protection.

### 1. Connect...

- test point T2 of terminal on PC board DX6 to L of 110V power receptacle
- the common lead of the pulse counter to N of the 110V power receptacle
- the second measuring lead of the pulse counter to test point T1
- 2. Refit cover C and tighten screw D securely.





- Switch unit ON ●.
   Wait 1 min. for self-adjustment of the unit.
   Press key R ② to return X-ray tube head to the initial position.
- Select 66kV/8mA. Establish exposure readiness via SIDEXIS.

#### Measurement:

## **A** CAUTION RADIATION


- Depress the exposure key and hold depressed until the exposure terminates automatically.
- **5.** Select service routine **S2** (Selecting a service routine: See Service Manual):
- Set radiation time to 1 sec.
- Measured values at 50 Hz 50 pulses +/-10%
- Measured values at 60 Hz 60 pulses +/-10%


## Record average pulse count.



If specified value cannot be obtained, see Service Manual, chapter "Exposure Time Verification".

- If specified value is obtained, switch unit OFF.
- 6. Remove upper cover and meter leads.







- 7. Screw the cover plate back on to the electronics box.
- 8. Reattach the housing covers.

# 8 Checking the X-Ray Beam

## 1.



2.



## 8.1 Diaphragm/system adjustment menu

The **DIAPHRAGM/SYSTEM ADJUSTMENT** menu guides you through the adjustment of the panoramic unit and the cephalometer. This service routine is started from **SIDEXIS XG**:


EXTRAS  $\rightarrow$  CONSTANCY TEST  $\rightarrow$  XCXP  $\rightarrow$  SELECT X-RAY DEVICE  $\rightarrow$  SERVICE EXPOSURE  $\rightarrow$  DIAPHRAGM/SYSTEM ADJUSTMENT



The DIAPHRAGM/SYSTEM ADJUSTMENT menu is password-protected. As password, enter the first four digits of the current system date (PC) in reverse order.

Example: On 05/30/2004, the service password is 5003

3.



NOTE

When you open the **DIAPHRAGM/SYSTEM ADJUSTMENT** menu, the unit switches from the user mode to the PC service mode logged by the PC.

## ORTHOPHOS XG<sup>Plus</sup> DS / Ceph:

This mode is indicated by the **PC service screen** (2.) displayed on the Easypad. In PC service mode, the Easypad control options are determined by SIDEXIS and the currently selected service routine. General control of the unit by means of the Easypad (as in the user mode) is not possible in this mode.


ORTHOPHOS XG 5 DS / Ceph, ORTHOPHOS XG 3 DS. This mode is indicated by the message SERVICE (3.) on the Multipad. In PC service mode, the Multipad control options are determined by SIDEXIS and the currently selected service routine. General control of the unit by means of the Multipad (as in the user mode) is not possible in this mode.


# The **DIAPHRAGM/SYSTEM ADJUSTMENT** menu has 11 submenus:

- Pan Sensor adjustment
- Pan Diaphragm
- Pan Filter
- Pan Symmetry
- Ceph Primary diaphragm
- Ceph Fixed point of rotation
- Ceph Main X-ray beam direction
- Ceph -Quickshot (full version only)
- TSA Sensor (full version only)
- Pan Reset adjustment
- Ceph Reset adjustment
- Sirona Service Sheet (internal SIRONA information)

You can change between the individual submenus by clicking the **tabs** with the mouse. To quit the **DIAPHRAGM/ SYSTEM ADJUSTMENT** menu, click **CANCEL**.

# Checking the X-Ray Beam for panorama exposure





## **Preparing the Pan adjustment**

In order to perform the PAN sensor adjustment and the symmetry adjustment you must insert needle phantom A in the bite block holder of the panoramic X-ray unit.

The needle phantom must be removed from the bite block holder for the pan diaphragm adjustment.




## **ATTENTION**

It is essential that the needle phantom is removed from bite block holder of the panoramic X-ray unit again before a Ceph exposure is taken; otherwise the phantom may collide with the sensor.



When fitting the needle phantom, make sure that it is correctly oriented. For the adjustment of the X-ray unit, the phantom must be fitted in such a way that the needles point upward (2.).



## 9.2 Checking the pan sensor adjustment

- Plug the sensor into the sensor slot on the panoramic X-ray unit.
- Insert the needle phantom in the bite block holder of the panoramic X-ray unit (see page 22).
- 1. Open the PAN SENSOR ADJUSTMENT submenu.



The menu provides a precision adjustment and a coarse adjustment (precision adjustment is preset). Perform a precision adjustment first. In most cases, previous coarse adjustment is not necessary.

2. Make SIDEXIS XG ready for exposure: Click IMAGE ACQUISITION.

#### Orthophos XG 5 / 3:

The exposure dialog box showing the exposure status appears in Sidexis.


The initialization status is visualized by a progress indicator on the Multipad.

The initialization procedure is completed when the exposure parameters of service routine  ${\bf S010.1}$  (60 kV/3 mA; 0.6 s) are displayed and the progress indicator disappears.


#### Orthophos XGPlus:

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **S010.1** is displayed on the Easypad touchscreen.



4.




Adjustment: ok

- 3. Take an exposure (60 kV/3 mA):
  - Press the **R key** to move the unit back to the starting position.
  - Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.
- 4. Evaluate the exposed image:
  - The three needle images must lie in the center of the exposed areas and inside the auxiliary lines (see image 4.).

NOTE

If the criteria specified above are not fulfilled, the sensor must be adjusted. The procedure for adjusting the unit is described in the service manual.



# 9.3 Checking the pan diaphragm adjustment

- Remove the needle phantom from the bite block holder of the panoramic X-ray unit.
- 1. Change to the PAN DIAPHRAGM submenu.

## **1** NOTE

For XGPlus, XG 5

The menu provides a precision adjustment and a coarse adjustment. Always try to use precision adjustment first when adjusting the unit. In most cases, it is not necessary to perform a coarse adjustment prior to precision adjustment.

2. Make SIDEXIS XG ready for exposure: Click IMAGE ACQUISITION.

#### Orthophos XG 5 / 3:

The exposure dialog box showing the exposure status appears in Sidexis.


The initialization status is visualized by a progress indicator on the Multipad.

The initialization procedure is completed when the exposure parameters of service routine **\$030.2** (60 kV/3 mA; 0.6 s) are displayed and the progress indicator disappears.


#### Orthophos XG<sup>Plus</sup>:

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **S030.2** is displayed on the Easypad touchscreen.



## 4.



## 3. Take an exposure (60 kV/3 mA):

- Press the **R key** to move the unit back to the starting position.
- Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.

#### 4. Evaluate the exposed image:


 The exposed diaphragm area must lie horizontally centered in the image field as well as inside the superimposed auxiliary lines.

## Adjustment: ok

 A white border surrounding the image on all sides must be visible. The maximum density must lie in the center of the diaphragm area.



If the current image differs from the ideal image (see image 4.), the diaphragm must be adjusted. The procedure for adjusting the unit is described in the service manual.



## 9.4 Checking the pan filter adjustment

Not necessary for ORTHOPHOS XG 3 DS

- 1. Change to the PAN FILTER submenu.
- 2. Make SIDEXIS XG ready for exposure: Click IMAGE ACQUISITION.

#### Orthophos XG 5:

The exposure dialog box showing the exposure status appears in Sidexis.


The initialization status is visualized by a progress indicator on the Multipad.

The initialization procedure is completed when the exposure parameters of service routine **S030.3** (60 kV/3 mA; 0.6 s) are displayed and the progress indicator disappears.


## Orthophos XGPlus:

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **\$030.3** is displayed on the Easypad touchscreen.




4.



- 3. Take an exposure (60 kV/3 mA):
  - Press the **R key** to move the unit back to the starting position.
  - Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.
- 4. Evaluate the exposed image:
  - The superimposed filter must cover one half of the diaphragm (see image 4.).

If the current image differs from the ideal image (see image 4.), the diaphragm must be adjusted. The procedure for adjusting the unit is described in the service manual.



## 9.5 Checking the pan symmetry

- Insert the needle phantom in the bite block holder of the panoramic X-ray unit (see page 22).
- 1. Change to the **PAN SYMMETRY** submenu.
- 2. Make SIDEXIS XG ready for exposure: Click IMAGE ACQUISITION.

### Orthophos XG 5 / 3:

The exposure dialog box showing the exposure status appears in Sidexis.


The initialization status is visualized by a progress indicator on the Multipad.

The initialization procedure is completed when the exposure parameters of service routine **S010.2** (60 kV/3 mA; 0.6 s) are displayed and the progress indicator disappears.


## Orthophos XGPlus:

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **S010.2** is displayed on the Easypad touchscreen.



## 4.




Adjustment: ok

- 3. Take an exposure (60 kV/3 mA):
  - Press the **R key** to move the unit back to the starting position.
  - Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.
- 4. Evaluate the captured image.
  - The shadow of the center needle, the needle image and the auxiliary line must be congruent and located behind each other.
    - A tolerance (offset of needle from the central auxiliary line) of  $\pm$  0.75 mm is admissible.

- Distance A1 must be 88.6 ± 1 mm.
- Distances A2 must be identical, each being 44.3 ± 0.5 mm.
- A white border surrounding the image on all sides must be visible (when zoomed out fully).

## 1 NOTE


If these criteria are not fulfilled, the symmetry must be adjusted. The procedure for adjusting the unit is described in the service manual.



#### in SIDEXIS




3.



#### on the touchscreen

1

3



## **9.6 Checking the TSA sensor** (full version only)

- 1. Change to the TSA SENSOR submenu.
- 2. Make SIDEXIS XG ready for exposure: Click IMAGE ACQUISITION

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **S030.4** is displayed on the Easypad touchscreen.

- 3. Take an exposure (60 kV/3 mA):
  - Press the **R key** on the Easypad to move the unit back to the starting position.

The procedure is completed when the status message "ORTHOPHOS is ready for exposure" appears on the touchscreen.

 Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.



Adjustment: ok


- 4. Evaluate the X-ray image:
  - The exposed diaphragm area must lie horizontally centered in the image field.
  - A white border surrounding the image on all sides must be visible. The maximum density must lie in the center of the diaphragm area.

## NOTE

If these criteria are not fulfilled, the symmetry must be adjusted. The procedure for adjusting the unit is described in the service manual.

# 10 Checking the X-Ray Beam for cephalometer exposure


## 1.



## 10.1 Preparing the Ceph adjustment

You must insert test phantom B in the sensor slot on the panoramic X-ray unit in order to perform the adjustment of the ceph primary diaphragm and the adjustment of the ceph main X-ray beam direction.

The test phantom must be removed from the sensor slot on the panoramic X-ray unit for the **adjustment of the ceph fixed point of rotation** and for the **ceph quickshot**.



# 10.2 Checking the Ceph primary diaphragm adjustment

- Move the ear plug holders on the cephalometer completely apart and swing them out of the beam direction (ap).
- Insert the test phantom in the sensor slot on the panoramic X-ray unit (see page 33).
- Plug the sensor into the sensor slot on the cephalometer.
- Open the DIAPHRAGM/SYSTEM ADJUSTMENT menu.
- 1. Select the CEPH PRIMARY DIAPHRAGM submenu.
- 2. Make SIDEXIS XG ready for exposure: Click IMAGE ACQUISITION.

#### Orthophos XG 5:

The exposure dialog box showing the exposure status appears in Sidexis.


The initialization status is visualized by a progress indicator on the Multipad.

The initialization procedure is completed when the exposure parameters of service routine \$010.3 (60 kV/3 mA; 0.6 s) are displayed and the progress indicator disappears.


## Orthophos XG<sup>Plus</sup>:

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **S010.3** is displayed on the Easypad touchscreen.




- 3. Take an exposure (80 kV/14 mA):
  - Press the **R key** to move the unit back to the starting position.
  - Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.





If S3 is significantly larger than 60 mm, check whether light barrier V61\_1 (LB on the horizontal diaphragm slider) is properly installed. If necessary, correct the alignment of the light barrier and then repeat the entire pan and ceph adjustment procedure.




- 4. Evaluate the captured image.
  - The vertical pin must be horizontally centered in the exposed image area.
  - A uniform white border surrounding the image on all sides must be visible.
  - Distance S3 must be approx. 60 mm.



A slight vertical offset of the grid is permissible.



If the image differs from the ideal image 4., the ceph primary diaphragm must be readjusted. The procedure for adjusting the unit is described in the service manual.



# 10.3 Checking the ceph rotation fixpoint adjustment

- Remove the ceph test phantom from the sensor slot of the panoramic X-ray unit.
- Change to the CEPH FIXED POINT OF ROTATION submenu.

### NOTE

The menu provides a precision adjustment and a coarse adjustment. Always try to use precision adjustment first when adjusting the unit. In most cases, it is not necessary to perform a coarse adjustment prior to precision adjustment.

**2.** Make SIDEXIS XG ready for exposure: Click **IMAGE ACQUISITION**.

### Orthophos XG 5:

The exposure dialog box showing the exposure status appears in Sidexis.


The initialization status is visualized by a progress indicator on the Multipad.

The initialization procedure is completed when the exposure parameters of service routine **S010.5** (60 kV/3 mA; 0.6 s) are displayed and the progress indicator disappears.


### Orthophos XGPlus:

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **S010.5** is displayed on the Easypad touchscreen.



4.




sides must be visible.

- 3. Take an exposure (80 kV/14 mA):
  - Press the **R key** to move the unit back to the starting position.
  - Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.
- 4. Evaluate the exposed image:
  - The exposed diaphragm area must lie centered and straight in the image field as well as inside the superimposed auxiliary lines (see image 4.).
  - A white border surrounding the image on all

### **1** NOTE

If the criteria specified above are not fulfilled, the ceph fixed point of rotation must be adjusted. The procedure for adjusting the unit is described in the service manual.



# 10.4 Checking the ceph main X-ray beam direction adjustment

- Insert the test phantom in the sensor slot on the panoramic X-ray unit (see page 33).
- Swing the ear plug holders out of the beam direction.
- 1. Change to the CEPH MAIN X-RAY BEAM DIRECTION submenu.
- 2. Make SIDEXIS XG ready for exposure: Click IMAGE ACQUISITION.

### Orthophos XG 5:

The exposure dialog box showing the exposure status appears in Sidexis.


The initialization status is visualized by a progress indicator on the Multipad.

The initialization procedure is completed when the exposure parameters of service routine **S010.6** (60 kV/3 mA; 0.6 s) are displayed and the progress indicator disappears.

### Orthophos XGPlus:

The exposure dialog box showing the exposure status appears in Sidexis.

Service routine **S010.6** is displayed on the Easypad touchscreen.



Adjustment: ok


- 3. Take an exposure (80 kV/14 mA):
  - Press the **R key** to move the unit back to the starting position.
  - Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.
- 4. Evaluate the exposed image:
  - A horizontal bar must be visible in the center of the image (see image 4.). If this bar is visible, the exposure is OK and ...
  - the two beams imaged are within the tolerance band of ± 10 mm (see image 4.).




If the criteria specified above are not fulfilled, the ceph main X-ray beam direction must be adjusted. The procedure for adjusting the unit is described in the service manual.


# 11 Checking the alignment of the ear plugs

1. 2.





3.



### 11.1 Preparing the ear olives



The sensor must be plugged into the sensor slot on the cephalometer. No sensor may be plugged into the sensor slot on the panoramic X-ray unit.

 Select the CEPH mode on the Multipad (XG 5) or Easypad (XG<sup>Plus</sup>).


- Move the ear plug holders completely apart and swing them into the beam direction.
- 2. Fit adjusting caps **D** onto the ear plugs and secure them with adhesive tape.
  - Black adjusting cap on the outside (sensor side), Transparent adjusting cap on the inside (tube assembly side).
- 3. Unscrew the cover from the cephalometer.











### 11.2 Checking the ear plug alignment

1. In Sidexis XG, select the constancy test:

### **EXTRAS** → **CONSTANCY TEST**

The typical SIDEXIS user interface is started. The constancy test is preset.

2. Start the exposure mode:

### Click XCXP

The dialog box for selecting the X-ray device appears on the screen.

3. Select/confirm the X-ray device:


Select e.g. Room2 (Kammer2) and click OK

The dialog box for selecting the test type appears on the screen.

4. Select/confirm the test type:

### Click SERVICE EXPOSURE

The dialog box for selecting the service exposure appears on the screen.



### 1 NOTE


The ceph mode must be activated on the Multipad (XG 5) or Easypad (XG $^{Plus}$ ) for the ceph quality test exposure.

**5.** Select/confirm the service exposure: Click **QUALITY TEST EXPOSURE**.

### 1 NOTE

If necessary, select the X-ray component.

The exposure dialog box showing the exposure status appears in Sidexis.




- 6. Take an exposure (80 kV/14 mA):
  - Press the R key to move the unit back to the starting position.
  - Press the release button. Hold down the release button until image acquisition is completed and the preview image appears in the exposure dialog box.
- The lead balls in the adjusting caps appear as dots on the image. The two dots must be coincident.




If the criteria specified above is not fulfilled, the ear olives must be adjusted. The procedure for adjusting the ear olives is described in the service manual.


## **Checking the laser**


### 1.





2.





Label

- 1. Insert the forehead and temple supports.
- 2. Check the laser:
- Fasten a piece of white cardboard between the temple
- Swivel the mirror by pressing the left recess **A** on the
- Switch on the light localizer with key B on the Easypad. The Lasers generate a red line.



### **!** WARNING

Class 1 radiation is emitted during installation. Always keep eyes a minimum distance of 100mm away from the laser. Do not stare into the beam.

### SAG laser (vertical line)

The light beam must strike the center of the head support in a vertical direction.

### FH laser (horizontal line)

The light beam must strike the FH line of the sheet of cardboard attached to the head support. It must be possible to displace the light beam vertically using slide C. Unwanted movement of the FH light localizer is not permitted.



To adjust the lasers, see Maintenance Instructions. No controls are available to adjust the laser power.



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352



## Yearly Maintenance Checklist

Technician:

Customer: A		Address:				
Dealer:		A	Address:			
Date of original instal	llation:	D	ate of in:	spection:		
Report of Assembly I	FD 2579 #					
SCHEDULE			Yes	No	Remarks	
All manuals are present						
Test instruments as requir	ed					
	Manufacturer	Model		Accuracy	Last calibrated	
Voltmeter						
mAmeter						
Pulse counter						
Any mechanical damage r	noticed					
All labels are present and	legible					
All indicator lights are OK						
Radiation indicator X-ray I	ights up, audible buzze	er OK				
Deadman feature OK						
Power supply adequate					ltage: V drop: V	
kV – Verification is OK						
Tube current is within spec	cified limits			Measur	ement: mA	
Specified exposure time, (pulses) OK			Pulse o	count:		
X-ray beam position, panoramic OK						
X-ray beam position, ceph	ОК					
The unit is in compliance with MFG specified tests and safe		ety				

D3352.103.01.04.02 59 38 373 D3352

We reserve the right to make any alterations which may be required due to technical improvements.

Sprache: englisch Printed in Germany Ä.-Nr.: 108 965 Imprimé en Allemagne

**Sirona Dental Systems GmbH** 

D3352.103.01.04.02 10.2007

in the USA:

Fabrikstraße 31 Sirona Dental Systems LLC 64625 Bensheim 4835 Sirona Drive, Suite 100 Germany Charlotte, NC 28273 www.sirona.com USA Order No **59 38 373 D3352**