

Contents

Preparations 2

Replacement 2

Calibration 4


Log sheet 6

The sealed unit contains a caustic liquid which may cause severe burns to skin and eyes. In case of contact, immediately flush with plenty of water for at least 15 minutes. For eyes, get medical attention.

Exchange of O₂ cell

Preparations


- Unpack the O₂ cell at least 30 minutes before replacement.




- Set the mode selector to "Ventilator off Battery charging".
- Disconnect the ventilator from mains and gas.
- Remove all accessories.

Replacement

- Open the lid on the patient unit.



Exchange of O₂ cell




- Open the O₂ cell holder.
- Take the old O₂ cell out of the holder.
- Disconnect the connector from the O₂ cell.
- Discard the old O₂ cell.



An old non-functioning O₂ cell must be returned to the place of purchase or to a place where it can be disposed of properly. The O₂ cell must not be disposed of with ordinary waste.


Exchange of O₂ cell




- Put a new O₂ cell with O-ring in the holder.
- Make sure the O-ring is not damaged and is in position.
- Connect the connector to the new O₂ cell.
- Close the O₂ cell holder.

Calibration


- Connect mains. Let the ventilator run for about 15 minutes.




Exchange of O₂ cell





- Set the mode selector to “Volume Control”.



- Set “O₂ conc.%” to 21%.



- Touch the “O₂ concentration” touchpad and make sure:
 - the display “Alarms and messages” shows 20.9%. If not, adjust with trimmer 5 (O₂% ).



Exchange of O₂ cell

- A fine-adjustment of the calibration may be necessary after a few hours of operation when the O₂ cell has reached the same working temperature as the ventilator.

Log sheet

- Note on a log sheet that the O₂ cell has been exchanged.