

MODIFICATION INSTRUCTIONS

for the

KODAK MULTILOADER 700

Service Code 3053

MODIFICATION No. 6

Type 1

PURPOSE:

TO IMPROVE THE CASSETTE OPENING

IMPORTANT: Only qualified technicians should install this modification.

SERVICE EFFECTS: EXIT DOOR is modified

SERIAL NUMBERS: 1001 - 1120 and 1129
5001 - 5041 without 5024

INSTALLATION TIME: approx. 1 hour

SPECIAL TOOLS: none

PARTS REQUIREMENTS:

Part No.	Description	Quantity
919 4905	MODIFICATION-KIT includes	
919 4811	SHIM	2
919 4601	SPRING	2

PLEASE NOTE The information contained herein is based on the experience and knowledge relating to the subject matter gained by Kodak prior to publication. No patent license is granted by this information. Kodak reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from the use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

Installation

- 1.** Open TOP COVER
- 2.** Key in FDAB, Day, Day, 9, 9
- 3.** Enter Option 7.3 (Keys 7, 3)
- 4.** Press Key 1 (OPEN CASSETTE)
- 5.** Switch off ML 700
- 6.** Remove and discard the SPRINGS. See figure 1.




figure 1

- 7.** Remove the two NUTS and WASHERS. See figure 1.
- 8.** Install the two SHIMS 919 4811 figure 2 to the PLATE 918 3213.
Do not bend the SHIMS !




figure 2

- 9.** Lubricate the SHIMS 919 4811.
- 10.** Install the PLATE 918 3213.
- 11.** Install the new SPRINGS 919 4601 to the EXIT DOOR. See figure 1.
- 12.** Check that the CASSETTE OPENER GUIDES move freely in the EXIT DOOR.
If they are blocked check the position of PLATE 918 3213 and SHIMS 919 4811. See figure 2.

- 13.** Check the CASSETTE CONTROL ADJUSTMENT. Use the PROCEDURE in the CES TECHNICAL NEWSLETTER ISSUE: MAY 1989.
- 14.** Check adjustment of CASSETTE ROLLER. See figure 3.




figure 3

Loosen SCREW 1+ 2 to set the distance from ROLLER SHAFT to CASSETTE STOP to 185 mm.

Loosen SCREW 3+ 4 to set the distance between ROLLER SHAFT and CASSETTE DRIVE BELT to 31 mm - 1mm.

15. Check the adjustment of the FILM PRESENCE DETECTORS.

16. Circle No.6 on the MODIFICATION LABEL.




figure 4

NOTE

If CASSETTE opening problems persist, they could be caused by:

1. CASSETTE LATCH misadjusted.
Solution: Follow the LATCH ADJUSTMENT PROCEDURE page 82 to 86 in the INSTALLATION INSTRUCTIONS .

2. HOOK at the CASSETTE OPENER SHOVEL is blocked or damaged.



CUSTOMER EQUIPMENT SERVICES KODAK AG STUTTGART GERMANY