

## Section 11: Numerical Index

### Numerical Index

Part No.	Description	Figure No.
1C0051	Screw - 4 x 6 mm	10-6
1C0055	Screw - Button, 5 x 12 mm	10-4
1C0058	Screw - 2 x 5 mm	10-3
1C0059	Mirror Assembly, Model 4L/4SL (illustrated)	10-4
1C0060	Lens Assembly, Model 4L (illustrated)	10-3
1C0061	P-A Card Holder Assembly, Model 4L/4SL	10-5
1C0062	A-P Card Holder Assembly, Model 4L/4SL	10-5
1C0063	Ring	10-4
1C0064	Mirror Assembly, Model 4 (not illustrated)	10-4
1C0065	Lens Assembly, Model 4 (not illustrated)	10-3
1C0066	P-A Card Holder Assembly, Model 4	10-5
1C0067	A-P Card Holder Assembly, Model 4	10-5
1C0068	Stay Unit Assembly	10-7
1C0200	Wire - Lens linkage, Model 4L (illustrated)	10-3
1C0201	Housing - Upper shield, Model 4L/4SL (illustrated)	10-5
1C0202	Plate, Switch actuator, Model 4L/4SL (illustrated)	10-3
1C0203	Bracket - Lens, Models 4L and 4SL (illustrated)	10-3
1C0204	Bracket - Card holder, Model 4L/4SL (illustrated)	10-5
1C0205	Bracket - Lens switch B, Model 4L	10-3
234905	Screw - Pan head, 2 x 5 mm	10-3, 10-7
238304	Screw - Pan head, 3 x 6 mm	10-2, 10-4, 10-5
251212	Screw - Pan head, 3 x 8 mm	10-2, 10-3
256700	Screw - Pan head, 3 x 10 mm	10-3, 10-5, 10-6
283112	Screw - Pan head, 3 x 20 mm	10-3
2B6325	Cover - LCD	10-1
2B6326	Screw	10-1
2B6327	Shield - EMI	10-2
2B6328	Button - Lens	10-1
2B6329	Button - Date, density or clock	10-1
2B6336	Stopper - Button	10-1
2B6337	Bracket B - Lamp	10-5
2B6338	Star - Motor linkage	10-3
2B6339	Bracket - Lens shift rod, Models 4 and 4L (illustrated)	10-3
2B6340	Lens - C-1N (not used on 4SL)	10-3
2B6341	Bracket - Lens, Models 4 and 4L (illustrated)	10-3
2B6342	Wire - Ground	10-5
2B6343	Plate - Ground	10-6
2B6344	Bearing	10-4
2B6345	Roller - Card	10-5
2B6346	Bracket - Card roller	10-5
2B6347	Spring - Card roller	10-5
2B6348	Holder - A-P card	10-5

## Numerical Index

Part No.	Description	Figure No.
2B6349	Bracket B - Card holder	10-5
2B6350	Bracket A - Card holder	10-5
2B6351	Bracket - Card holder, Model 4 (not illustrated)	10-5
2B6352	Wire - Ground	10-5
2B6355	Nut	10-6
2B6356	Microswitch	10-6
2B6357	Frame	10-6
2B6358	Base	10-2
2B6359	Plate - Reinforcement	10-1
2B6360	Cap - Voltage selector	10-6
2B6361	Spring	10-6
2B6362	Pin B	10-6
2B6363	Pin A	10-6
2B6364	Spring - Pin	10-6
2B6365	Roller	10-6
2B6366	Pin - Roller	10-6
2B6367	Stay	10-6
2B6368	Stiffener - Pin	10-6
2B6369	Stopper	10-7
2B6370	Stopper - Rod, right	10-6
2B6371	Stopper - Bearing	10-6
2B6372	Bearing - Slide	10-7
2B6373	Pin - Stay linkage	10-7
2B6374	Bracket - Stay	10-7
2B6375	Mount - Pin traveler	10-7
2B6376	Rod	10-7
2B6377	Rod	10-7
2B6378	Stopper - Rod, left	10-6
2B6379	Microswitch	10-7
2B6380	Spring	10-6
2B6381	Ring - Switch	10-7
2B6382	Bracket - Microswitch	10-7
2B6383	Pin - Microswitch	10-7
2B6384	Spring	10-7
2B6385	Guide - Cassette	10-7
2B6386	Spring	10-7
2B6387	Pin	10-6
2B6388	Pin - Open	10-6
2B6389	Bracket - Window detector	10-6
2B6390	Microswitch	10-6
2B6407	Screw - Flat head, 3 x 10 mm	10-2, 10-6
2B6408	Screw - Flat head, 4 x 10 mm	10-6
2B6411	Screw - Pan head, 4 x 4 mm	10-5
2B6416	Screw - Pan head, 3 x 15 mm	10-2, 10-4, 10-6
2B6419	Screw - Pan head, 4 x 12 mm	10-1, 10-7

## Numerical Index

Part No.	Description	Figure No.
2B6421	Screw - Pan head, 4 x 35 mm	10-6
2B6423	Screw - Pan head, 3 x 12 mm	10-3
324259	Screw - Pan head, 3 x 5 mm	10-5
476324	Cord - Power, AC 220 V	10-2
499222	Bolt - Cap, 3 x 10 mm	10-3
605777	Nut - M3	10-2
616289	Cord - Power, AC 100-120 V	10-2
654373	Screw - Pan head, 2 x 10 mm	10-3, 10-7
714284	Screw - Pan head, 4 x 6 mm	10-2
731091	Bolt - Cap, 3 x 8 mm	10-4
731104	Bolt - Cap, 4 x 12 mm	10-6
732335	Screw - Pan head, 4 x 8 mm	10-1, 10-2, 10-3, 10-5, 10-6
755244	Screw - Pan head, 4 x 25 mm	10-2
8B6727	Strip - Derlin	10-1
8B7325	Wire - Lens linkage, Model 4SL (not illustrated)	10-3
8B7326	Bracket - Lens shift rod, Model 4SL (not illustrated)	10-3
8B7327	Bracket - Lens, Model 4SL (not illustrated)	10-3
8B7328	Lens Assembly, Model 4SL (not illustrated)	10-3
990807	Finger - EMI	10-2
990808	Cover - Power switch	10-2
990810	Button - Power	10-2
990811	Spring - Return, power switch actuator	10-2
990812	Bracket - Actuator, power switch	10-2
990813	Rod - Actuator, power switch	10-2
990814	Bracket - Power switch	10-2
990815	Window	10-2
990816	Switch - Power	10-2
990817	Bracket - Power switch	10-2
990818	Socket - Power switch	10-2
990819	Foot	10-2
990820	Cable - Ribbon, display	10-1
990821	Display - LCD	10-1
990822	Cover - Card positioning, Models 4L and 4SL	10-1
990823	Cover - Card positioning, Model 4	10-1
990824	Cover - Top	10-1
990825	Bracket - Lens Motor	10-3
990826	Motor - Lens/Mirror	10-3
990827	Nut	10-3, 10-4
990828	Wire - Lens linkage, Model 4 (not illustrated)	10-3
990829	Cover - C-1N lens	10-3
990830	Cover - Front shield, upper housing	10-5
990831	Bracket - Lens alignment	10-3
990832	Rod - Lens shift	10-3
990833	Bracket - Lens stop	10-3

## Numerical Index

Part No.	Description	Figure No.
990834	Cover - Back shield, upper housing	10-5
990835	Housing - Upper shield, Model 4 (not illustrated)	10-5
990836	Linkage - Lens	10-3
990837	Plate, Switch actuator, Model 4 (not illustrated)	10-3
990838	Microswitch	10-3
990840	Lamp	10-5
990841	Socket - Lamp	10-5
990842	Bracket - C1-N In switch, Model 4L	10-3
990842	Bracket - C1-N In switch, Models 4 and 4SL	10-3
990844	Bracket A - Lamp	10-5
990845	Bracket - Mirror motor	10-4
990846	Star - Motor linkage	10-4
990847	Wire - Mirror linkage	10-4
990848	Switch - Mirror	10-4
990849	Bracket - Mirror switch	10-4
990850	Bracket - Lens, Model 4 (not illustrated)	10-3
990851	Mount - Mirror traveler	10-3
990852	Stiffener - Mirror bracket	10-4
990853	Actuator - Mirror switch	10-4
990855	Plate - Base, mirror	10-4
990856	Bracket - Adjustment, mirror	10-4
990857	Mirror	10-4
990858	Bracket - Mirror	10-4
990861	Lens - C-1	10-3
990863	Holder - P-A card	10-5
990864	Holder - P-A card	10-5
990867	Cable - P-A ribbon	10-5
990868	Bulb - Clock	10-5
990869	Cable - A-P ribbon	10-5
990874	LCD - IDK-13A	10-5
990879	Linkage - Actuator	10-6
990880	Bearing	10-6
990881	Hub	10-6
990882	Pin	10-6
990883	Cam	10-6
990884	Gearbox	10-6
990885	Motor - Actuator drive	10-6
990886	Switch - Window open	10-6
990887	Bracket - Switch mount	10-6
990893	Board - CPU	10-2
990894	Plate - CPU circuit board	10-2
990895	Switch - Voltage selector	10-6
990896	Fuse - 3 A, Model 4/4SL	10-6
990897	Fuse - 1 A, Model 4L	10-6
990898	Transformer	10-6