



Publication No. 981778  
September 1992  
Supersedes 635818 and 635039  
12/87

**PARTS LIST**  
**for the**  
**KODAK *M35 and M35A* X-OMAT Processors**

#### PLEASE NOTE

The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.

Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from the use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

#### CAUTION



This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.

## Table of Contents


Description	Page
<b>Overview</b> .....	1-1
Locators, Feed End .....	1-2
Locators, Receiving End.....	1-3
Feed End .....	1-5
Receiving End.....	1-7
<b>Roller Transport System</b> .....	2-1
Rack Positions .....	2-3
Detector Crossover Assembly .....	2-5
Detector Crossover - Drive Side .....	2-7
Detector Crossover - Non-drive Side .....	2-9
Developer/Fixer Crossover Assembly .....	2-11
Developer/Fixer Crossover - Drive Side.....	2-13
Developer/Fixer Crossover - Non-drive Side .....	2-15
Fixer/Wash Crossover Assembly.....	2-17
Fixer/Wash Crossover - Drive Side.....	2-19
Fixer/Wash Crossover - Non-drive Side.....	2-21
Rack Assemblies .....	2-23
Developer and Fixer Racks - Top Exit Rollers .....	2-25
Wash Rack - Top Exit Rollers.....	2-27
Developer and Wash Racks - Other Rollers.....	2-29
Fixer Rack - Other Rollers.....	2-31
Turnaround Assemblies.....	2-33
Dryer Rack.....	2-35
Dryer Rack - Frame.....	2-37
Dryer Rack - Rollers .....	2-39
Dryer Rack - Miscellaneous Parts.....	2-41
<b>Main Drive Assembly</b> .....	3-1
Main Drive Shaft and Motor .....	3-3
<b>Blower Assembly</b> .....	4-1
Blower Assembly .....	4-3
<b>Plumbing</b> .....	5-1
Developer Plumbing Circulation Diagram.....	5-3

<b>Description</b>	<b>Page</b>
Fixer and Wash Plumbing Circulation Diagram .....	5-5
Developer Termowell Assembly .....	5-7
Heat Exchangers .....	5-9
Recirculation Pump.....	5-11
Replenishment Pump.....	5-13
Weirs .....	5-15
<b>Electrical</b> .....	6-1
Switches, Safelight Receptacle, and CB3.....	6-3
Electrical Box .....	6-5
<b>Miscellaneous</b> .....	7-1
Miscellaneous Parts .....	7-3
Accessories .....	7-5
120 Power Cord and Wall Receptacle .....	7-6
Replenishment Tank Kits.....	7-7
Seismic Bracket .....	7-8
<b>Numerical Index</b> .....	8-1
<b>Alphabetical Index</b> .....	9-1
<b>Publication Change Table</b> .....	10-1

**BLANK PAGE**


## SECTION 1 Overview

This publication is part of a series of instruction books that provide technical support information on the KODAK *M35 and M35A* X-OMAT Processors. It is recommended that these publications be kept in the binder provided. If an individual book is misplaced or destroyed, order another copy from your Eastman Kodak Representative using the Publication Part Numbers below.




H112\_9002BC

### Related Publications for the M35 and M35A Processors




H112\_0071DCA  
H112\_0071DA

**Figure 1-1 Locators, Feed End**



**Figure 1-2 Locators, Receiving End**




H112\_0022ECA  
H112\_0022EC



Item	Part No.	Description	Qty.	Notes
1	287680	Cover - Evaporation.....	2	Each includes items 2 & 4.
2	261180	Screw - Captive, and washer .....	6	
	499753	Retainer.....	6	
3	333981	Side Panel Assembly.....	2	
4	264439	Panel - Side .....	2	
5	468535	Adapter - Exhaust .....	1	
	544194	Screw .....	2	
	852620	Nut.....	2	
	165627	Washer .....	2	
	853096	Washer - Lock.....	2	
6	240518	Guide - Film, right edge.....	1	Includes the Feed Shelf and the Protector.
7	852682	Screw .....	3	
	852611	Washer .....	3	
	853100	Washer - Lock.....	3	
	853080	Nut.....	3	
8	240726	Feed Shelf Assembly.....	1	
	287685	Protector.....	1	
	852805	Screw .....	4	
	853086	Washer - Lock.....	4	
	852799	Washer .....	4	
9	333978	Panel - Front .....	1	M35A Processor only
	333980	Panel - Front .....	1	M35 Processor only
10	264445	Cover Assembly.....	1	Includes the following items.
	963312	Magnet .....	2	
	484688	Handle .....	1	
	485291	Handle - Support.....	1	
	852682	Screw .....	2	
	853100	Washer - Lock.....	2	
	470363	Label.....	1	

**Figure 1-3 Feed End  
Order by Part Number**



H112\_0068ECA  
H112\_0068EC


**Figure 1-4 Receiving End  
Order by Part Number**

Item	Part No.	Description	Qty.	Notes
1	333981	Side Panel Assembly .....	2	Includes the Side Panel and Captive Screws and Retainers; see page 1-4.
2	459229	Screw - Leveling .....	4	
3	459548	Plate - Floor .....	4	
4	489726	Bolt - Hook .....	2	
5	564694	Washer .....	2	
6	852623	Nut - Hook.....	4	
7	914441	Circuit Breaker .....	1	
8	333995	Exit Panel Assembly - M35A Processor.....	1	
	333994	Exit Panel Assembly - M35 Processor .....	1	Includes the Nameplate and the Overlay and item 11. Does not include a power cord.
	240566	Nameplate - M35A Processor .....	1	
	240565	Nameplate - M35 Processor.....	1	
	240736	Overlay - Dryer Temperature.....	1	
9	585721	Knob - Dryer Temperature Control.....	1	
	651872	Potentiometer Assembly .....	1	
10	333975	Cover - Pump Access .....	1	
11	261180	Screw - Captive, and washer .....	2	
	499753	Retainer.....	2	
12	261183	Bin - Receiving.....	1	
13	261185	Deflector .....	1	
14	486742	Fastener - Bin .....	2	
15	333796	Dryer Rack Assembly .....	1	
16	261276	Fixer/Wash Crossover Assembly.....	1	
17	333795	Developer/Fixer Crossover Assembly.....	1	
18	333794	Detector Crossover Assembly .....	1	
19	261275	Developer Rack Assembly.....	1	
20	748165	Fixer Rack Assembly .....	1	
21	261277	Wash Rack Assembly .....	1	
22	287089	Strip - Light Lock.....	1	
	852682	Screw .....	3	
	853100	Washer - Lock.....	3	
	852611	Washer .....	3	
	240226	Power Cord Assembly .....	1	For the M35A Processor (120 volt) only, not shown
	161777	Relief - Strain .....	1	For the M35A Processor (120 volt) only, not shown

**Figure 1-4 Receiving End  
Order by Part Number**

**BLANK PAGE**

**SECTION 2**  
**Roller Transport System**



H112\_0144BC

**Figure 2-1 Rack Positions  
Order by Part Number**


Item	Part No.	Description	Qty.	Notes
<b>Crossover Rollers</b>				
1	246882	Roller - Detector, driven.....	1	
2	246883	Roller - Detector, drive.....	1	
3	485406	Roller .....	1	
4	240747	Roller .....	1	
5	748147	Roller .....	1	
6	287048	Roller .....	1	
<b>Rack Roller Assemblies</b>				
7	287028	Roller .....	2	G Roller; each includes 2 Bearings, Part No. 650710.
8	287030	Roller .....	2	F Roller
9	287032	Roller .....	2	Rewet Roller
10	287066	Roller .....	6	E Roller
11	287059	Roller .....	8	C Roller
12	287020	Roller .....	3	D Roller
13	287004	Roller .....	3	B Roller; each includes 2 Bearings, Part No. 650702.
14	287005	Roller .....	2	A Roller; each includes the 2 Bearings.
15	419788	Roller .....	1	C Roller
16	748126	Roller .....	4	A Roller; each includes the 2 Bearings.
17	246917	Roller .....	1	G Roller
18	246918	Roller .....	1	F Roller
<b>Dryer Rollers and Air Tubes</b>				
19	287083	Roller .....	1	Upper Entrance Roller
20	287656	Roller .....	1	Lower Entrance Roller
21	287081	Roller .....	2	Main Drive and Lower Exit Rollers
22	287067	Roller .....	9	
23	287078	Roller .....	1	Upper Exit Roller
24	484674	Tube - Air .....	10	

**Figure 2-1 Rack Positions**  
Order by Part Number


**BLANK PAGE**



**Figure 2-2 Detector Crossover Assembly**



H112\_0050DA




H112\_0051DCA  
H112\_0051DA

Figure 2-3 Detector Crossover - Drive Side  
Order by Part Number

Item	Part No.	Description	Qty.
	333794	Detector Crossover Assembly .....	1
1	287035	Rod - Tie .....	1
2	852807	Screw .....	2
3	246879	Sideplate - Detector Crossover .....	2
4	650707	Bearing .....	2
5	472592	Bearing - Rocker .....	2
6	474180	Support .....	2
7	650876	Actuator - Magnet .....	2
8	575822	Washer .....	2
9	187283	Washer - Lock .....	2
10	575821	Screw .....	2
11	852611	Washer .....	4
12	853087	Washer - Lock .....	4
13	852682	Screw .....	4
14	544194	Screw .....	2
15	853096	Washer - Lock .....	2
16	165627	Washer .....	2
17	452044	Key .....	1
18	550781	Gear - Drive, crossover .....	1
19	458174	Spacer .....	1
20	489997	Standoff .....	2
21	183322	Screw .....	2
22	650703	Bearing .....	2
23	472756	Nut - Tie Rod, nylon .....	1
24	474596	Bracket - Guide Shoe .....	2
25	852941	Screw .....	2
26	287041	Shoe - Guide .....	1
27	287036	Rod - Tie .....	1
28	287039	Shaft - Drive .....	1
29	246883	Roller - Detector, drive .....	1
30	246882	Roller - Detector, driven .....	1
31	287037	Shaft .....	1

**Figure 2-3 Detector Crossover - Drive Side**  
**Order by Part Number**



H112\_0052DCA  
H112\_0052DA


**Figure 2-4 Detector Crossover - Non-drive Side**  
**Order by Part Number**

Item	Part No.	Description	Qty.
	333794	Detector Crossover Assembly .....	1
1	246882	Roller - Detector, driven.....	1
2	287037	Shaft.....	1
3	246883	Roller - Detector, drive.....	1
4	287039	Shaft - Drive.....	1
5	287036	Rod - Tie .....	1
6	287041	Shoe - Guide.....	1
7	852941	Screw .....	2
8	474596	Bracket - Guide Shoe .....	2
9	472755	Nut - Tie Rod, nylon .....	1
10	183322	Screw .....	2
11	650703	Bearing.....	2
12	489997	Standoff.....	2
13	458236	Spacer .....	1
14	852611	Washer .....	4
15	853087	Washer - Lock.....	4
16	852682	Screw .....	4
17	544194	Screw .....	2
18	853096	Washer - Lock.....	2
19	165627	Washer .....	2
20	575821	Screw .....	2
21	187283	Washer - Lock.....	2
22	575822	Washer .....	2
23	650876	Actuator - Magnet .....	2
24	474180	Support.....	2
25	472592	Bearing - Rocker.....	2
26	650707	Bearing.....	2
27	852807	Screw .....	2
28	246879	Sideplate - Detector Crossover .....	2
29	287035	Rod - Tie .....	1


**Figure 2-4 Detector Crossover - Non-drive Side**  
**Order by Part Number**

**BLANK PAGE**

**Figure 2-5 Developer/Fixer Crossover Assembly**



H112\_0056DA




H112\_0057DCA  
H112\_0057DA

**Figure 2-6 Developer/Fixer Crossover - Drive Side**  
**Order by Part Number**



Item	Part No.	Description	Qty.	Notes
	333795	Developer/Fixer Crossover Assembly.....	1	On drive side
1	287036	Rod - Tie .....	2	
2	472756	Nut - Tie Rod, nylon .....	2	
3	477005	Sideplate .....	2	
4	490092	Bearing .....	2	
5	183322	Screw .....	4	
6	459946	Washer - Identification .....	1	
7	853087	Washer - Lock.....	2	
8	852682	Screw .....	2	
9	452044	Key .....	1	
10	852611	Washer .....	2	
11	550781	Gear - Drive, crossover .....	1	
12	240065	Spacer .....	1	
13	459344	Spring .....	2	
14	240060	Bearing .....	2	
15	474596	Bracket - Guide Shoe .....	4	
16	287049	Shoe - Guide.....	1	
17	240747	Roller .....	1	
18	485406	Roller .....	1	
19	544081	Pin .....	1	Drive Roller Driven Roller; includes a Pin. 3/32 x 5/8 inch
20	287045	Shoe - Guide.....	1	

**Figure 2-6 Developer/Fixer Crossover - Drive Side**  
Order by Part Number



H112\_0058DCA  
H112\_0058DA


**Figure 2-7 Developer/Fixer Crossover - Non-drive Side**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
	333795	Developer/Fixer Crossover Assembly.....	1	
1	485406	Roller .....	1	Driven Roller
2	240747	Roller .....	1	Drive Roller
3	287049	Shoe - Guide.....	1	
4	852941	Screw .....	4	
5	474596	Bracket - Guide Shoe .....	4	
6	183322	Screw .....	4	
7	240060	Bearing .....	2	
8	459344	Spring .....	2	
9	852611	Washer .....	3	
10	853087	Washer - Lock.....	4	
11	852682	Screw .....	4	
12	490092	Bearing .....	2	
13	472755	Nut - Tie Rod, nylon .....	2	On non-drive side
14	477005	Sideplate .....	2	
15	287036	Rod - Tie .....	2	
16	287045	Shoe - Guide.....	1	


**Figure 2-7 Developer/Fixer Crossover - Non-drive Side**  
**Order by Part Number**

**BLANK PAGE**

**Figure 2-8 Fixer/Wash Crossover Assembly**



H112\_0053DA




H112\_0055DCA  
H112\_0055DA

**Figure 2-9 Fixer/Wash Crossover - Drive Side**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
	261276	Fixer/Wash Crossover Assembly.....	1	On drive side
1	287036	Rod - Tie.....	2	
2	472756	Nut - Tie Rod, nylon .....	2	
3	477005	Sideplate .....	2	
4	650701	Bearing .....	2	
5	183322	Screw .....	4	
6	459947	Washer - Identification .....	1	
7	853087	Washer - Lock.....	4	
8	852682	Screw .....	4	
9	550781	Gear - Drive, crossover .....	1	
10	452044	Key .....	1	
11	852611	Washer .....	3	
12	458174	Spacer .....	1	
13	650703	Bearing .....	2	
14	474596	Bracket - Guide Shoe .....	4	
15	852941	Screw .....	4	
16	287049	Shoe - Guide.....	1	
17	287047	Shaft.....	1	
18	287048	Roller .....	1	Drive Roller
19	287037	Shaft.....	1	Driven Roller
20	748147	Roller .....	1	
21	287045	Shoe - Guide.....	1	

**Figure 2-9 Fixer/Wash Crossover - Drive Side**  
**Order by Part Number**



H112\_0054DCA  
H112\_0054DA

**Figure 2-10 Fixer/Wash Crossover - Non-drive Side**  
**Order by Part Number**




Item	Part No.	Description	Qty.	Notes
	261276	Fixer/Wash Crossover Assembly.....	1	
1	287037	Shaft.....	1	
2	748147	Roller .....	1	Driven Roller
3	287047	Shaft.....	1	
4	287048	Roller .....	1	Drive Roller
5	287049	Shoe - Guide.....	1	
6	852941	Screw .....	4	
7	474596	Bracket - Guide Shoe .....	4	
8	183322	Screw .....	4	
9	650701	Bearing.....	2	
10	650703	Bearing.....	2	
11	852611	Washer .....	3	
12	853087	Washer - Lock.....	4	
13	852682	Screw .....	4	
14	477005	Sideplate .....	2	
15	472755	Nut - Tie Rod, nylon .....	2	On non-drive side only
16	287036	Rod - Tie .....	2	
17	287045	Shoe - Guide.....	1	

**Figure 2-10 Fixer/Wash Crossover - Non-drive Side**  
**Order by Part Number**

**BLANK PAGE**

**Figure 2-11 Rack Assemblies**




H112\_0060DA



Item	Part No.	Description	Qty.	Notes
	261275	Developer Rack Assembly .....	1	
	748165	Fixer Rack Assembly .....	1	
1	240058	Tie - Red .....	1	Developer Rack
	240059	Tie - Blue .....	1	Fixer Rack
2	287002	Rod - Tie .....	1	
3	477092	Spacer .....	1	
4	287027	Shaft .....	1	
5	287028	Roller .....	1	G Roller
6	454354	Key .....	2	
7	459355	Spacer .....	1	
8	458240	Chain .....	1	
9	454285	Sprocket .....	1	
10	463100	Washer - Thrust .....	3	
11	911809	Sideplate - Drive .....	1	
12	459943	Washer - Identification .....	1	Developer
	459944	Washer - Identification .....	1	Fixer
13	852807	Screw .....	2	
14	463004	Spacer .....	2	
15	467843	Spring .....	2	
16	650710	Bearing .....	2	
17	534791	Spacer .....	1	
18	550774	Gear - Drive .....	1	
19	852682	Screw .....	4	
20	853087	Washer - Lock .....	4	
21	852611	Washer .....	2	
22	473221	Plate - Keeper .....	2	
23	473220	Bushing .....	2	
24	183624	Screw .....	4	
25	459347	Collar .....	2	
26	852889	Setscrew .....	2	
27	287032	Roller .....	1	Rewet Roller
28	287030	Roller .....	1	F Roller; stainless steel. Includes 2 Bearings, Part No. 650710.
29	287003	Shaft .....	1	
30	911845	Sideplate - Non-drive .....	1	
31	458205	Spacer .....	1	

**Figure 2-12 Developer and Fixer Racks - Top Exit Rollers**  
Order by Part Number




H112\_0048ECA  
H112\_0048EA

**Figure 2-13 Wash Rack - Top Exit Rollers**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
	261277	Wash Rack Assembly .....	1	
1	287002	Rod - Tie .....	1	
2	474100	Spacer .....	2	
3	479820	Spring .....	2	
4	246917	Roller .....	1	G Roller; includes items 5 - 7.
5	458384	Gear .....	1	
	463950	O-Ring .....	1	Not shown
6	175381	Pin .....	1	
7	597096	Collar - Split .....	2	
8	458240	Chain .....	1	
9	454285	Sprocket .....	1	
10	454354	Key .....	2	
11	463100	Washer - Thrust .....	1	
12	650702	Bearing .....	2	
13	459945	Washer - Identification .....	1	
14	852807	Screw .....	2	
15	473538	Spacer .....	1	
16	550774	Gear - Drive .....	1	
17	852682	Screw .....	4	
18	853087	Washer - Lock.....	2	
19	852611	Washer .....	4	
20	459343	Washer .....	2	
21	650701	Bearing .....	2	
22	183624	Screw .....	4	
23	286912	Sideplate - Drive .....	1	
24	246918	Roller .....	1	F Roller
25	477093	Spacer .....	1	
26	286910	Sideplate - Non-drive .....	1	
27	458205	Spacer .....	1	Not shown

**Figure 2-13 Wash Rack - Top Exit Rollers**  
**Order by Part Number**




H112\_0076DCA  
H112\_0076DA

Figure 2-14 Developer and Wash Racks - Other Rollers  
Order by Part Number



Item	Part No.	Description	Qty.	Notes
	261275	Developer Rack Assembly .....	1	
	261277	Wash Rack Assembly .....	1	
1	911845	Sideplate - Non-drive .....	1	Developer Rack
	286910	Sideplate - Non-drive .....	1	Wash Rack
2	287018	Guide Rod Assembly .....	1	
3	287059	Roller .....	3	C Roller; 3 for each Rack.
4	911809	Sideplate - Drive .....	1	Developer Rack
	286912	Sideplate - Drive .....	1	Wash Rack
5	474777	Stud .....	12	
6	183624	Screw .....	4	
7	287066	Roller .....	2	E Roller
8	287020	Roller .....	1	D Roller
9	852682	Screw .....	1	

**Figure 2-14 Developer and Wash Racks - Other Rollers**  
**Order by Part Number**




H112\_0076DCA  
H112\_0076DA

**Figure 2-15 Fixer Rack - Other Rollers**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
	748165	Fixer Rack Assembly .....	1	
1	911845	Sideplate - Non-drive .....	1	
2	287018	Guide Rod Assembly .....	1	
3	287059	Roller .....	2	C Roller
	419788	Roller .....	1	C Roller
4	911809	Sideplate - Drive .....	1	
5	474777	Stud .....	12	
6	183624	Screw .....	4	
7	287066	Roller .....	2	E Roller
8	287020	Roller .....	1	D Roller
9	852682	Screw .....	1	

**Figure 2-15 Fixer Rack - Other Rollers**  
**Order by Part Number**



H112\_0075ECC  
H112\_0075EA


**Figure 2-16 Turnaround Assemblies**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
1	287003	Shaft .....	3	B Roller
2	287004	Roller .....	1	
3	650702	Bearing .....	2	
4	287005	Roller .....	2	
	748126	Roller .....	2	A Roller. In Developer Rack. Includes the 2 Bearings.
				A Roller. In Fixer and Wash Racks; 2 Rollers each. Includes 2 Bearings each.
5	852941	Screw .....	6	
6	287006	Shoe - Guide.....	2	
7	474596	Bracket - Guide Shoe .....	6	
8	852682	Screw .....	4	
9	490096	Screw .....	4	
10	477001	Sideplate - Turnaround, drive side .....	1	
11	183322	Screw .....	6	
12	463100	Washer - Thrust .....	6	
13	463004	Spacer .....	6	
14	474645	Spring .....	2	
15	472265	Plate - Locking .....	1	
16	190596	Screw .....	2	
17	459343	Washer .....	6	
18	287009	Shoe - Guide.....	1	
19	477000	Sideplate - Turnaround, non-drive.....	1	
	287002	Rod - Tie .....	2	Not shown
	852807	Screw .....	4	Not shown


Figure 2-16 Turnaround Assemblies  
Order by Part Number

**BLANK PAGE**

**Figure 2-17 Dryer Rack**



H112\_0064DA





H112\_0063ECA  
H112\_0063EA

**Figure 2-18 Dryer Rack - Frame**  
**Order by Part Number**



Item	Part No.	Description	Qty.
	333796	Dryer Rack Assembly .....	1
1	287696	Cover - Dryer, top .....	1
2	480366	Fastener .....	8
3	287694	Spacer - Sideplate, upper entrance.....	1
4	490123	Sideplate - Drive Side.....	1
5	852682	Screw .....	5
6	287692	Spacer - Sideplate, lower entrance .....	1
7	287695	Cover - Dryer, bottom .....	1
8	287691	Spacer - Sideplate, exit .....	1
9	264432	Sideplate - Non-drive Side.....	1
10	287697	Plenum .....	1

Figure 2-18 Dryer Rack - Frame  
Order by Part Number




H112\_0061ECA  
H112\_0061EA

**Figure 2-19 Dryer Rack - Rollers**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
1	482274	Spacer .....	2	Upper Entrance Roller
2	287083	Roller .....	1	
3	571241	Bearing .....	7	
4	287079	Shaft .....	1	
5	543993	Bearing .....	10	
6	482271	Washer .....	10	
7	482270	Washer .....	9	
8	183851	O-Ring .....	1	Lower Entrance Roller
9	287656	Roller .....	1	
10	287085	Shaft .....	1	
11	543884	Pin .....	1	
12	532165	Gear .....	1	
13	333543	Bearing .....	1	
14	482272	Spacer .....	1	
15	852611	Washer .....	1	Main Drive & Lower Exit Rollers
16	853087	Washer - Lock.....	1	
17	544132	Screw .....	1	
18	287081	Roller .....	1	
19	287088	Shaft .....	1	
20	473085	O-Ring .....	1	
21	482275	Gear .....	1	
22	489727	Stud .....	9	Upper Exit Roller
23	287067	Roller .....	9	
24	287078	Roller .....	1	
25	287079	Shaft .....	1	
26	482277	Spacer .....	1	
27	287085	Shaft .....	1	
28	182391	O-Ring .....	1	
29	543891	Pin .....	1	
30	482273	Collar .....	1	

**Figure 2-19 Dryer Rack - Rollers**  
Order by Part Number



H112\_0062ECA  
H112\_0062EA


**Figure 2-20 Dryer Rack - Miscellaneous Parts**  
**Order by Part Number**

Item	Part No.	Description	Qty.
1	287689	Rod - Tie .....	2
2	852682	Screw .....	4
3	853087	Washer - Lock.....	4
4	852611	Washer .....	4
5	482262	Support.....	1
6	287045	Shoe - Guide.....	1
7	166856	Screw .....	2
	178145	Washer - Lock .....	2
8	287676	Rod - Tie .....	2
9	482283	Nut.....	2
10	490123	Sideplate - Drive Side.....	1
11	852871	Screw .....	2
12	459060	Stud .....	10
13	562609	Spring.....	10
14	484674	Tube - Air .....	10
15	264432	Sideplate - Non-drive Side.....	1
16	495710	Support.....	1

**Figure 2-20 Dryer Rack - Miscellaneous Parts**  
**Order by Part Number**

**BLANK PAGE**

**SECTION 3**  
**Main Drive Assembly**



**Figure 3-1 Main Drive Shaft and Motor**  
**Order by Part Number**




Item	Part No.	Description	Qty.	Notes
	595425	Support Assembly .....	1	Includes items 4 - 8
1	188807	Screw .....	4	
2	535004	Washer - Lock.....	4	
3	852799	Washer .....	4	
4	852621	Nut.....	8	
5	474186	Plate .....	1	
6	532071	Support.....	4	
7	853165	Screw .....	8	
8	595426	Bearing .....	2	
9	486689	Fan - Drive Motor.....	1	
10	246839	Drive Motor Assembly - M35A Processor .....	1	120 volts
	651863	Drive Motor Assembly - M35 Processor.....	1	220 volts
11	852683	Screw .....	2	
12	489744	Guard - Motor .....	1	
13	082248	Washer - Rubber .....	8	
14	852611	Washer .....	12	
15	853100	Washer - Lock.....	4	
16	486472	Screw .....	4	
17	287728	Guard - Chain .....	1	
18	532363	Sprocket - 16 Tooth .....	1	For 60 Hz
	532247	Sprocket - 19 Tooth .....	1	For 50 Hz, Prepack Kit
19	852558	Setscrew.....	3	
20	466640	Sprocket - 17 Tooth .....	1	
21	480168	Chain - Drive .....	1	
22	853000	Pin .....	7	
23	488169	Spacer .....	1	
24	482222	Shaft - Drive .....	1	
25	748955	Gear - Worm, left hand.....	4	
26	748956	Gear - Worm, right hand.....	3	
27	650733	Shim .....	2	

**Figure 3-1 Main Drive Shaft and Motor**  
Order by Part Number

**BLANK PAGE**

**SECTION 4**  
**Blower Assembly**



H112\_0082ECA  
H112\_0082EA

**Figure 4-1 Blower Assembly**  
**Order by Part Number**


Item	Part No.	Description	Qty.	Notes
1	484689	Heater Element Assembly - M35A Processor.....	1	120 volts
	651892	Heater Element Assembly - M35 Processor .....	1	220 volts
2	594795	Overtemperature - Dryer Thermostat, safety .....	1	
3	852888	Screw .....	6	
4	852611	Washer .....	6	
5	485293	Guard - Overtemperature .....	1	
6	852807	Screw .....	2	
7	433708	Washer - Lock.....	2	
8	456215	Spacer .....	2	
9	246806	Clamp .....	2	
10	264425	Hose - Exhaust .....	1	
11	779215	Bracket - Blower Mounting .....	1	
12	852799	Washer .....	6	
13	535004	Washer - Lock.....	6	
14	264429	Screw .....	2	
15	240225	Blower Assembly - M35A Processor.....	1	
	651864	Blower Assembly - M35 Processor .....	1	
16	853100	Washer - Lock.....	1	
17	852682	Screw .....	4	

**Figure 4-1 Blower Assembly**  
Order by Part Number

**BLANK PAGE**

## **SECTION 5**

### **Plumbing**




H112\_0073ECA  
H112\_0073EA

**Figure 5-1 Developer Plumbing Circulation Diagram**  
**Order by Part Number**



Item	Part No.	Description	Qty.	Notes
1	287000	Tank - Wash .....	1	Developer Tank to the Recirculation Pump
2	779003	Tank - Fixer.....	1	
3	779002	Tank - Developer .....	1	
4	489788	Tube .....	1	
5	579383	Elbow.....	1	
6	594534	Washer .....	1	
7	594535	Gasket .....	1	
8c	246800	Clamp .....	2	
9	619251	Fitting - Quick Release, female .....	1	
10	619252	Insert - Quick Release, male .....	1	
11	240058	Tie - Red .....	1	
12	240004	Tube .....	1	
13	240227	Replenishment Pump Assembly - M35A Processor	1	
	651861	Replenishment Pump Assembly - M35 Processor...	1	
14	240002	Tube .....	1	
15c	246808	Clamp .....	5	
16	287736	Tube .....	1	From the Recirculation Pump
17c	246801	Clamp .....	15	
18	240500	Recirculation Pump Assembly - M35A Processor....	1	
	418703	Recirculation Pump Assembly - M35 Processor .....	1	
19	531270	Tube .....	1	
20	539151	Orifice - 0.250 ID .....	1	
21	180281	Connector - Tee.....	2	
22	463029	Tube .....	1	
23	531263	Orifice - 0.109 ID .....	1	
24	527068	Tube .....	2	
25	488190	Tube .....	1	From the Tee Connector to the Fixer Heat Exchanger
26	287735	Tube .....	1	
27	914568	Tube .....	1	
28	536827	Filter Assembly.....	1	
29	287740	Tube .....	1	
30	287053	Exchanger - Heat.....	2	
	264461	Kit - Tubing .....	1	
				Includes Part No. 240002, 240003, 240004, 240005, 287733 (2), 287735, 287736, 287740, 471393, 489788 (3), & 914568.

**Figure 5-1 Developer Plumbing Circulation Diagram**  
Order by Part Number



H112\_0072DCA  
H112\_0072DA

**Figure 5-2 Fixer and Wash Plumbing Circulation Diagram**  
**Order by Part Number**


Item	Part No.	Description	Qty.	Notes
1	287000	Tank - Wash .....	1	
2	779003	Tank - Fixer.....	1	
3	779002	Tank - Developer .....	1	
4c	246808	Clamp .....	1	
5	489788	Tube .....	1	
6	579383	Elbow.....	2	
7c	246801	Clamp .....	15	
8	240003	Tube .....	1	
9	594534	Washer .....	1	
10	594535	Gasket .....	1	
11c	246800	Clamp .....	2	
12	619251	Fitting - Quick Release, female .....	1	
13	619252	Insert - Quick Release, male .....	1	
14	240059	Tie - Blue .....	1	
15	240005	Tube .....	1	
16	240227	Replenishment Pump Assembly - M35A Processor	1	
	651861	Replenishment Pump Assembly - M35 Processor...	1	
17	287733	Tube .....	2	
18	240500	Recirculation Pump Assembly - M35A Processor....	1	
	418703	Recirculation Pump Assembly - M35 Processor .....	1	
19	539152	Orifice - 0.209 ID .....	1	
20	261590	Water Inlet Assembly .....	1	
	261650	Kit - Flow Control Valve.....	1	Includes these 5 items:
	185101	Nipple .....	1	
	287730	Bracket - Water Inlet.....	1	
	472477	Control - Flow .....	1	
	556104	Adapter.....	1	
	551400	Elbow.....	1	
21	471393	Tube .....	1	
22	287053	Exchanger - Heat.....	2	
23	779214	Water Inlet Tube and Tab Assembly.....	1	
	264461	Kit - Tubing .....	1	Includes Part No. 240002, 240003, 240004, 240005, 287733 (2), 287735, 287736, 287740, 471393, 489788 (3), & 914568.

**Figure 5-2 Fixer and Wash Plumbing Circulation Diagram**  
**Order by Part Number**



Item	Part No.	Description	Qty.	Notes
1	651868	Thermostat - Overtemperature .....	1	120 volts 220 volts
2	607793	Locator - Heater.....	1	
3	651869	Thermistor .....	1	
4	532033	Adapter.....	1	
5	607748	Header - Thermowell .....	1	
6	485399	Heater - M35A Processor.....	1	
	651862	Heater - M35 Processor .....	1	
7	852799	Washer .....	2	
8	535004	Washer - Lock.....	2	
9	187235	Screw .....	2	

**Figure 5-3 Developer Thermowell Assembly**  
Order by Part Number




H112\_0080ECA  
H112\_0080EA

**Figure 5-4 Heat Exchangers**  
**Order by Part Number**

Item	Part No.	Description	Qty.
1	613278	Nut.....	4
2	581241	Seal .....	4
3	613276	Fitting - Small.....	3
4	287053	Exchanger - Heat.....	2
5	607750	Fitting.....	4
6	492260	Seal .....	4
7	562892	Nut.....	4
8	532378	Seal .....	4
9	532379	Washer .....	4
10	562891	Nut - Gland .....	4
11	613277	Fitting - Large.....	1

Figure 5-4 Heat Exchangers  
Order by Part Number




H112\_0083DCA  
H112\_0083DA



Item	Part No.	Description	Qty.	Notes
	418701	Housing and Impeller Assembly .....	2	Includes items 4 - 7.
	240500	Recirculation Pump Assembly - M35A Processor....	1	120 volts; includes all the items below.
	418703	Recirculation Pump Assembly - M35 Processor .....	1	220 volts; includes all the items below.
	469403	Pad - Motor .....	1	Not shown
1	264429	Screw .....	4	
2	535004	Washer - Lock.....	4	
3	852799	Washer .....	4	
4	418700	Housing .....	2	
5	474362	Impeller.....	2	
6	493505	Washer .....	2	
7	852946	Screw .....	2	
8	463363	O-Ring .....	2	
9	472606	Housing - L.H.....	1	Developer
	472605	Housing - R.H. ....	1	Fixer
10	144097	Nut - Wing.....	8	
11	603538	Capacitor .....	1	
	651865	Cable Assembly .....	1	Not shown

**Figure 5-5 Recirculation Pump  
Order by Part Number**




H112\_0081ECA  
H112\_0081EA

**Figure 5-6 Replenishment Pump**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
	240227	Replenishment Pump Assembly - M35A Processor	1	120 volts; includes all the items below.
	651861	Replenishment Pump Assembly - M35 Processor...	1	220 volts; includes all the items below.
1	852683	Screw .....	2	Includes a Lock Washer, Part No. 535004, and a Washer, Part No. 852799.
2	484668	Guard - Fan .....	1	
3	532007	Body - Valve .....	1	
4	520388	O-Ring .....	2	
5	480978	Extension - Valve.....	1	
6	609817	Valve - Poppet .....	2	
7	520390	Elbow.....	2	
8	535639	O-Ring .....	2	
9	418739	Guide - Cup .....	1	
10	532008	Bellows - Pump.....	1	
11	594838	Cone.....	1	
12	594837	Rod - Connecting, and bearing .....	1	
13	520394	Washer .....	1	
14	480130	Nut.....	1	
15	520397	Cover - Splash .....	1	
16	246001	Nut - Coupling.....	1	
17	963316	Crank Assembly.....	1	
18	532390	Bracket .....	2	
19	963317	Screw .....	2	
20	474881	Motor Assembly - M35A Processor.....	1	120 volts, 50/60 Hz
	963315	Motor Assembly - M35 Processor .....	1	220 volts, 50/60 Hz
21	520381	Fan .....	1	

**Figure 5-6 Replenishment Pump  
Order by Part Number**





H112\_0074DCA  
H112\_0074DA

Item	Part No.	Description	Qty.	Notes
1	488151	Weir - Beige .....	1	Wash
2	489736	Weir - Blue .....	1	Fixer
3	489735	Weir - Red.....	1	Developer
4	554780	Seal - Tank .....	2	
5	779216	Support - Rack.....	1	
6	852799	Washer .....	2	
7	535004	Washer - Lock.....	2	
8	852683	Screw .....	2	
9	539138	O-Ring .....	3	

Figure 5-7 Weirs  
Order by Part Number

**BLANK PAGE**

**SECTION 6**  
**Electrical**




**Figure 6-1 Switches, Safelight Receptacle, and CB3**  
**Order by Part Number**



Item	Part No.	Description	Qty.	Notes
1	165626	Screw .....	6	
2	853096	Washer - Lock.....	6	
3	852831	Washer .....	6	
4	240514	Switch - Film Detector .....	2	
	182915	Tie - Wire .....	2	Not shown
5	240513	Switch - Interlock .....	1	Includes 2 each of items 1 - 3.
	914565	Plate - Nut.....	2	Not shown
6	651860	Switch - Run/Standby .....	1	
7	579424	Circuit Breaker .....	1	CB3; M35A Processor only
8	264339	Receptacle - Safelight.....	1	M35A Processor only

**Figure 6-1 Switches, Safelight Receptacle, and CB3**  
Order by Part Number



H112\_0086ECA  
H112\_0086EC


**Figure 6-2 Electrical Box  
Order by Part Number**

Item	Part No.	Description	Qty.	Notes
	246840	Electrical Box Assembly - M35A Processor .....	1	
	264436	Electrical Box Assembly - M35 Processor .....	1	
1	264464	Circuit Breaker - M35A Processor .....	1	CB2
	475409	Circuit Breaker - M35 Processor .....	1	CB2
2	544194	Screw .....	2	For TB5
	853096	Washer - Lock .....	2	
3	552361	Block - Terminal .....	1	TB5
4	240229	Transformer - M35A Processor .....	1	T1
	651850	Transformer - M35 Processor .....	1	T1
5	853165	Screw .....	4	For TB3
	853100	Washer - Lock .....	4	
6	485766	Block - Terminal .....	1	TB3
7	540928	Screw .....	2	For TB4
	187283	Washer - Lock .....	2	
8	594752	Block - Terminal .....	1	TB4
9	852683	Screw .....	5	
10	246875	Mount - Cable .....	2	
11	562693	Relay .....	1	K1
	651873	Quencharc .....	2	
12	655290	Relay .....	2	U1 & U2
13	651881	Chain .....	1	
14	852835	Screw .....	2	
	535004	Washer - Lock .....	5	
	168424	Washer - Lock .....	5	Not shown
15	532040	Screw - Cover, and washer .....	1	
16	557422	100 Circuit Board .....	1	
	544194	Screw .....	5	
	187213	Washer - Lock .....	5	
	165627	Washer .....	5	
17	484692	ESD Jack Assembly .....	1	
18	562334	Relay .....	2	K2 and K3
19	480206	Block - Terminal .....	1	TB1
	852868	Screw .....	2	
	598808	Lug - Ground .....	1	E1
20	914441	Circuit Breaker .....	1	CB1
	486265	Screw .....	4	Not shown
21	651875	Switch - Run/Standby .....	1	
22	544154	Lamp .....	1	L1
23	187296	Block - Terminal .....	1	TB2
	651853	Buzzer .....	1	Not shown
	852799	Washer .....	2	Not shown
	651893	Main Harness Assembly - M35A Processor .....	1	Not shown
	264453	Main Harness Assembly - M35 Processor .....	1	Not shown
	379381	Fuse - ¼ Amp, 250 volts .....	1	M35 Processor only; not shown

**Figure 6-2 Electrical Box  
Order by Part Number**

**BLANK PAGE**

**SECTION 7**  
**Miscellaneous**




H112\_0079ECA  
H112\_0079EA

**Figure 7-1 Miscellaneous Parts**  
**Order by Part Number**

Item	Part No.	Description	Qty.	Notes
1	852683	Screw .....	8	M35 Processor only; 220 volts
2	535004	Washer - Lock.....	8	
3	852799	Washer .....	8	
4	485391	Cover - Receiving End.....	1	
5	651851	Filter - EMI .....	1	
6	287741	Foam .....	2	
7	287731	Foam .....	2	
8	554780	Seal - Tank .....	2	
9	779214	Water Inlet Tube and Tab Assembly.....	1	
10	180126	Screw .....	2	
11	261180	Screw - Captive, and washer .....	2	
12	968802	800 Circuit Board and Cable Assembly .....	1	
13	852611	Washer .....	5	
14	853100	Washer - Lock .....	3	
15	853080	Nut.....	3	
16	183643	Spacer .....	3	
17	287683	Seal - Tank Separator .....	4	
18	287677	Clip .....	2	
19	287679	Clip - Rack End.....	2	
20	499753	Retainer.....	2	
21	575822	Washer .....	2	
22	187283	Washer - Lock.....	2	
23	852618	Nut.....	2	
24	852807	Screw .....	2	
25	484690	Guard - Circuit Board.....	1	
26	914375	Clamp .....	1	
27	651890	Support - Bin.....	2	
28	287682	Guide - Exit.....	1	

**Figure 7-1 Miscellaneous Parts**  
**Order by Part Number**




H112\_0069DCA  
H112\_0069DA




Item	Part No.	Description	Qty.	Notes
1	536827	Filter Assembly.....	1	Includes item 2.
2	473118	O-Ring .....	1	
3	562790	Cartridge - Filter.....	1	
4	479821	Cylinder - Graduate .....	2	
5	240494	Tubing - Bulk.....		Prepack
	760477	Tubing - Bulk, 3/4-inch ID.....		Order by the foot
	760476	Tubing - Bulk, 1/2-inch ID.....		Order by the foot
	452990	Tubing - Bulk, 3/8-inch ID.....		Order by the foot
6	240733	Elbow - Exhaust.....	1	
7	650939	Gasket .....	1	
8	287681	Tray - Drip.....	1	
9	287684	Guard - Splash.....	1	
10	592380	J-Tube .....	1	
		KODAK M35 X-OMAT Mounting Stand.....	1	CAT No. 150 0537, not shown

**Figure 7-2 Accessories**  
**Order by Part Number**



Item	Part No.	Description	Qty.	Notes
1	419787	Receptacle - Wall.....	1	For M35A Processor only. For the M35A Processor only. The M35 Processor does not come with a power cord.
2	240226	Power Cord Assembly .....	1	
3	246558	KODAK M35/M35A X-OMAT Lighttight Feed Tray	1	


**Figure 7-3 120 Power Cord and Wall Receptacle**  
**Order by Part Number**



H112\_0010ACB  
H112\_0010AC

Item	Part No.	Description	Qty.	Notes
1	472261	Strainer Assembly .....	2	
2		KODAK Developer Replenisher Tank Kit .....	1	CAT No. 151 1740 for 14-gallon tanks
				CAT No. 102 2987 for 30-gallon tanks
		KODAK Fixer Replenisher Tank Kit .....	1	CAT No. 151 1765 for 14-gallon tanks
				CAT No. 102 2961 for 30-gallon tanks
		KODAK Developer-Fixer Replenisher Tank Set, Model M7 .....	1	CAT No. 150 0537 for 8-gallon tanks
3	609969	Fitting .....	1	CAT No. 154 4154
	459681	Adapter .....	1	

**Figure 7-4 Replenishment Tank Kits**  
**Order by Part Number**



H108\_0193DCB  
H108\_0193DA

Item	Part No.	Description	Qty.	Notes
	261413	Seismic Kit .....	1	Includes the following items.
1	188623	Bolt - Stainless Steel .....	8	Not shown
	261929	Anchor .....	8	
2	173824	Washer - Stainless Steel .....	8	
3	240104	Bracket .....	4	
4	261898	Plate - Floor .....	4	

**Figure 7-5 Seismic Bracket**  
**Order by Part Number**

## SECTION 8

### Numerical Index

Part Number	Description	Figure Number
082248	Washer - Rubber .....	3-1
144097	Nut - Wing .....	5-5
161777	Relief - Strain.....	1-4
165626	Screw.....	6-1
165627	Washer .....	1-3, 2-3, 2-4, 6-2
166856	Screw.....	2-20
168424	Washer - Lock .....	6-2
173824	Washer - Stainless Steel.....	7-5
175381	Pin.....	2-13
178145	Washer - Lock .....	2-20
180126	Screw.....	7-1
180281	Connector - Tee .....	5-1
182391	O-Ring .....	2-19
182915	Tie - Wire.....	6-1
183322	Screw.....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10, 2-16
183624	Screw.....	2-12, 2-13, 2-14, 2-15
183643	Spacer .....	7-1
183851	O-Ring .....	2-19
185101	Nipple.....	5-2
187213	Washer - Lock .....	6-2
187235	Screw.....	5-3
187283	Washer - Lock .....	2-3, 2-4, 6-2, 7-1
187296	Block - Terminal .....	6-2
188623	Bolt - Stainless Steel .....	7-5
188807	Screw.....	3-1
190596	Screw.....	2-16
240002	Tube.....	5-1
240003	Tube.....	5-2
240004	Tube.....	5-1
240005	Tube.....	5-2
240058	Tie - Red.....	5-1, 2-12
240059	Tie - Blue.....	5-2, 2-12
240060	Bearing .....	2-6, 2-7
240065	Spacer .....	2-6
240104	Bracket.....	7-5
240225	Blower Assembly - M35A Processor .....	4-1
240226	Power Cord Assembly.....	1-4, 7-3
240227	Replenishment Pump Assembly - M35A Processor.....	5-1, 5-2, 5-6
240229	Transformer - M35A Processor.....	6-2
240494	Tubing - Bulk .....	7-2
240500	Recirculation Pump Assembly - M35A Processor.....	5-1, 5-2, 5-5
240513	Switch - Interlock.....	6-1
240514	Switch - Film Detector.....	6-1
240518	Guide - Film, right edge .....	1-3
240565	Nameplate - M35 Processor .....	1-4

Part Number	Description	Figure Number
240566	Nameplate - M35A Processor .....	1-4
240726	Feed Shelf Assembly .....	1-3
240733	Elbow - Exhaust .....	7-2
240736	Overlay - Dryer Temperature .....	1-4
240747	Roller .....	2-1, 2-6, 2-7
246001	Nut - Coupling .....	5-6
246558	KODAK M35/M35A X-OMAT Lighttight Feed Tray.....	7-3
246800	Clamp .....	5-1, 5-2
246801	Clamp .....	5-1, 5-2
246806	Clamp .....	4-1
246808	Clamp .....	5-1, 5-2
246839	Drive Motor Assembly - M35A Processor.....	3-1
246840	Electrical Box Assembly - M35A Processor .....	6-2
246875	Mount - Cable.....	6-2
246879	Sideplate - Detector Crossover .....	2-3, 2-4
246882	Roller - Detector, driven .....	2-1, 2-3, 2-4
246883	Roller - Detector, drive .....	2-1, 2-3, 2-4
246917	Roller .....	2-1, 2-13
246918	Roller .....	2-1, 2-13
261180	Screw - Captive, and washer .....	1-3, 1-4, 7-1
261183	Bin - Receiving .....	1-4
261185	Deflector .....	1-4
261275	Developer Rack Assembly .....	1-4, 2-12, 2-14
261276	Fixer/Wash Crossover Assembly .....	1-4, 2-9, 2-10
261277	Wash Rack Assembly .....	1-4, 2-13, 2-14
261413	Seismic Kit.....	7-5
261590	Water Inlet Assembly .....	5-2
261650	Kit - Flow Control Valve .....	5-2
261898	Plate - Floor.....	7-5
261929	Anchor .....	7-5
264339	Receptacle - Safelight .....	6-1
264425	Hose - Exhaust.....	4-1
264429	Screw.....	4-1, 5-5
264432	Sideplate - Non-drive Side .....	2-18, 2-20
264436	Electrical Box Assembly - M35 Processor.....	6-2
264439	Panel - Side.....	1-3
264445	Cover Assembly .....	1-3
264453	Main Harness Assembly - M35 Processor .....	6-2
264461	Kit - Tubing .....	5-1, 5-2
264464	Circuit Breaker - M35A Processor .....	6-2
286910	Sideplate - Non-drive.....	2-13, 2-14
286912	Sideplate - Drive.....	2-13, 2-14
287000	Tank - Wash .....	5-1, 5-2
287002	Rod - Tie.....	2-12, 2-13, 2-16
287003	Shaft .....	2-12, 2-16
287004	Roller .....	2-1, 2-16
287005	Roller .....	2-1, 2-16
287006	Shoe - Guide .....	2-16
287009	Shoe - Guide .....	2-16
287018	Guide Rod Assembly.....	2-14, 2-15

Part Number	Description	Figure Number
287020	Roller .....	2-1, 2-14, 2-15
287027	Shaft .....	2-12
287028	Roller .....	2-1, 2-12
287030	Roller .....	2-1, 2-12
287032	Roller .....	2-1, 2-12
287035	Rod - Tie.....	2-3, 2-4
287036	Rod - Tie.....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10
287037	Shaft .....	2-3, 2-4, 2-9, 2-10
287039	Shaft - Drive .....	2-3, 2-4
287041	Shoe - Guide .....	2-3, 2-4
287045	Shoe - Guide .....	2-6, 2-7, 2-9, 2-10, 2-20
287047	Shaft .....	2-9, 2-10
287048	Roller .....	2-1, 2-9, 2-10
287049	Shoe - Guide .....	2-6, 2-7, 2-9, 2-10
287053	Exchanger - Heat .....	5-1, 5-2, 5-4
287059	Roller .....	2-1, 2-14, 2-15
287066	Roller .....	2-1, 2-14, 2-15
287067	Roller .....	2-1, 2-19
287078	Roller .....	2-1, 2-19
287079	Shaft .....	2-19
287081	Roller .....	2-1, 2-19
287083	Roller .....	2-1, 2-19
287085	Shaft .....	2-19
287088	Shaft .....	2-19
287089	Strip - Light Lock .....	1-4
287656	Roller .....	2-1, 2-19
287676	Rod - Tie.....	2-20
287677	Clip.....	7-1
287679	Clip - Rack End .....	7-1
287680	Cover - Evaporation .....	1-3
287681	Tray - Drip .....	7-2
287682	Guide - Exit.....	7-1
287683	Seal - Tank Separator.....	7-1
287684	Guard - Splash .....	7-2
287685	Protector .....	1-3
287689	Rod - Tie.....	2-20
287691	Spacer - Sideplate, exit.....	2-18
287692	Spacer - Sideplate, lower entrance.....	2-18
287694	Spacer - Sideplate, upper entrance.....	2-18
287695	Cover - Dryer, bottom .....	2-18
287696	Cover - Dryer, top .....	2-18
287697	Plenum.....	2-18
287728	Guard - Chain.....	3-1
287730	Bracket - Water Inlet .....	5-2
287731	Foam.....	7-1

Part Number	Description	Figure Number
287733	Tube.....	5-2
287735	Tube.....	5-1
287736	Tube.....	5-1
287740	Tube.....	5-1
287741	Foam.....	7-1
333543	Bearing .....	2-19
333794	Detector Crossover Assembly.....	1-4, 2-3, 2-4
333795	Developer/Fixer Crossover Assembly.....	1-4, 2-6, 2-7
333796	Dryer Rack Assembly.....	1-4, 2-18
333975	Cover - Pump Access .....	1-4
333978	Panel - Front.....	1-3
333980	Panel - Front.....	1-3
333981	Side Panel Assembly .....	1-3, 1-4
333994	Exit Panel Assembly - M35 Processor .....	1-4
333995	Exit Panel Assembly - M35A Processor.....	1-4
379381	Fuse - ¼ Amp, 250 volts.....	6-2
418700	Housing.....	5-5
418701	Housing and Impeller Assembly .....	5-5
418703	Recirculation Pump Assembly - M35 Processor .....	5-1, 5-2, 5-5
418739	Guide - Cup.....	5-6
419787	Receptacle - Wall.....	7-3
419788	Roller .....	2-1, 2-15
433708	Washer - Lock .....	4-1
452044	Key.....	2-3, 2-6, 2-9
452990	Tubing - Bulk, ¾-inch ID .....	7-2
454285	Sprocket.....	2-12, 2-13
454354	Key.....	2-12, 2-13
456215	Spacer .....	4-1
458174	Spacer .....	2-3, 2-9
458205	Spacer .....	2-12, 2-13
458236	Spacer .....	2-4
458240	Chain .....	2-12, 2-13
458384	Gear.....	2-13
459060	Stud .....	2-20
459229	Screw - Leveling.....	1-4
459343	Washer .....	2-13, 2-16
459344	Spring .....	2-6, 2-7
459347	Collar .....	2-12
459355	Spacer .....	2-12
459548	Plate - Floor.....	1-4
459681	Adapter .....	7-4
459943	Washer - Identification.....	2-12
459944	Washer - Identification.....	2-12
459945	Washer - Identification.....	2-13
459946	Washer - Identification.....	2-6
459947	Washer - Identification.....	2-9
463004	Spacer .....	2-12, 2-16
463029	Tube.....	5-1
463100	Washer - Thrust.....	2-12, 2-13, 2-16
463363	O-Ring .....	5-5
463950	O-Ring .....	2-13
466640	Sprocket - 17 Tooth .....	3-1



Part Number	Description	Figure Number
467843	Spring .....	2-12
468535	Adapter - Exhaust.....	1-3
469403	Pad - Motor.....	5-5
470363	Label .....	1-3
471393	Tube.....	5-2
472261	Strainer Assembly .....	7-4
472265	Plate - Locking.....	2-16
472477	Control - Flow .....	5-2
472592	Bearing - Rocker .....	2-3, 2-4
472605	Housing - R.H.....	5-5
472606	Housing - L.H. ....	5-5
472755	Nut - Tie Rod, nylon.....	2-4, 2-7, 2-10
472756	Nut - Tie Rod, nylon.....	2-3, 2-6, 2-9
473085	O-Ring .....	2-19
473118	O-Ring .....	7-2
473220	Bushing.....	2-12
473221	Plate - Keeper .....	2-12
473538	Spacer .....	2-13
474100	Spacer .....	2-13
474180	Support .....	2-3, 2-4
474186	Plate.....	3-1
474362	Impeller .....	5-5
474596	Bracket - Guide Shoe.....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10, 2-16
474645	Spring .....	2-16
474777	Stud .....	2-14, 2-15
474881	Motor Assembly - M35A Processor .....	5-6
475409	Circuit Breaker - M35 Processor.....	6-2
477000	Sideplate - Turnaround, non-drive .....	2-16
477001	Sideplate - Turnaround, drive side.....	2-16
477005	Sideplate.....	2-6, 2-7, 2-9, 2-10
477092	Spacer .....	2-12
477093	Spacer .....	2-13
479820	Spring .....	2-13
479821	Cylinder - Graduate .....	7-2
480130	Nut .....	5-6
480168	Chain - Drive .....	3-1
480206	Block - Terminal .....	6-2
480366	Fastener.....	2-18
480978	Extension - Valve .....	5-6
482222	Shaft - Drive .....	3-1
482262	Support .....	2-20
482270	Washer .....	2-19
482271	Washer .....	2-19
482272	Spacer .....	2-19
482273	Collar .....	2-19
482274	Spacer .....	2-19
482275	Gear.....	2-19
482277	Spacer .....	2-19
482283	Nut .....	2-20
484668	Guard - Fan.....	5-6

Part Number	Description	Figure Number
484674	Tube - Air.....	2-1, 2-20
484688	Handle .....	1-3
484689	Heater Element Assembly - M35A Processor .....	4-1
484690	Guard - Circuit Board .....	7-1
484692	ESD Jack Assembly.....	6-2
485291	Handle - Support .....	1-3
485293	Guard - Overtemperature .....	4-1
485391	Cover - Receiving End .....	7-1
485399	Heater - M35A Processor .....	5-3
485406	Roller .....	2-1, 2-6, 2-7
485766	Block - Terminal .....	6-2
486265	Screw.....	6-2
486472	Screw.....	3-1
486689	Fan - Drive Motor .....	3-1
486742	Fastener - Bin.....	1-4
488151	Weir - Beige.....	5-7
488169	Spacer .....	3-1
488190	Tube.....	5-1
489726	Bolt - Hook.....	1-4
489727	Stud .....	2-19
489735	Weir - Red .....	5-7
489736	Weir - Blue.....	5-7
489744	Guard - Motor.....	3-1
489788	Tube.....	5-1, 5-2
489997	Standoff .....	2-3, 2-4
490092	Bearing .....	2-6, 2-7
490096	Screw.....	2-16
490123	Sideplate - Drive Side .....	2-18, 2-20
492260	Seal.....	5-4
493505	Washer .....	5-5
495710	Support .....	2-20
499753	Retainer .....	1-3, 1-4, 7-1
520381	Fan.....	5-6
520388	O-Ring .....	5-6
520390	Elbow .....	5-6
520394	Washer .....	5-6
520397	Cover - Splash.....	5-6
527068	Tube.....	5-1
531263	Orifice - 0.109 ID .....	5-1
531270	Tube.....	5-1
532007	Body - Valve .....	5-6
532008	Bellows - Pump .....	5-6
532033	Adapter .....	5-3
532040	Screw - Cover, and washer .....	6-2
532071	Support .....	3-1
532165	Gear.....	2-19
532247	Sprocket - 19 Tooth .....	3-1
532363	Sprocket - 16 Tooth .....	3-1
532378	Seal.....	5-4
532379	Washer .....	5-4
532390	Bracket.....	5-6
534791	Spacer .....	2-12

Part Number	Description	Figure Number
535004	Washer - Lock .....	3-1, 4-1, 5-3, 5-5, 5-7, 6-2, 7-1
535639	O-Ring .....	5-6
536827	Filter Assembly .....	5-1, 7-2
539138	O-Ring .....	5-7
539151	Orifice - 0.250 ID .....	5-1
539152	Orifice - 0.209 ID .....	5-2
540928	Screw .....	6-2
543884	Pin .....	2-19
543891	Pin .....	2-19
543993	Bearing .....	2-19
544081	Pin .....	2-6
544132	Screw .....	2-19
544154	Lamp .....	6-2
544194	Screw .....	1-3, 2-3, 2-4, 6-2
550774	Gear - Drive .....	2-12, 2-13
550781	Gear - Drive, crossover .....	2-3, 2-6, 2-9
551400	Elbow .....	5-2
552361	Block - Terminal .....	6-2
554780	Seal - Tank .....	5-7, 7-1
556104	Adapter .....	5-2
557422	100 Circuit Board .....	6-2
562334	Relay .....	6-2
562609	Spring .....	2-20
562693	Relay .....	6-2
562790	Cartridge - Filter .....	7-2
562891	Nut - Gland .....	5-4
562892	Nut .....	5-4
564694	Washer .....	1-4
571241	Bearing .....	2-19
575821	Screw .....	2-3, 2-4
575822	Washer .....	2-3, 2-4, 7-1
579383	Elbow .....	5-1, 5-2
579424	Circuit Breaker .....	6-1
581241	Seal .....	5-4
585721	Knob - Dryer Temperature Control .....	1-4
592380	J-Tube .....	7-2
594534	Washer .....	5-1, 5-2
594535	Gasket .....	5-1, 5-2
594752	Block - Terminal .....	6-2
594795	Overtemperature - Dryer Thermostat, safety .....	4-1
594837	Rod - Connecting, and bearing .....	5-6
594838	Cone .....	5-6
595425	Support Assembly .....	3-1
595426	Bearing .....	3-1
597096	Collar - Split .....	2-13
598808	Lug - Ground .....	6-2
603538	Capacitor .....	5-5
607748	Header - Thermowell .....	5-3
607750	Fitting .....	5-4
607793	Locator - Heater .....	5-3

Part Number	Description	Figure Number
609817	Valve - Poppet.....	5-6
609969	Fitting.....	7-4
613276	Fitting - Small .....	5-4
613277	Fitting - Large .....	5-4
613278	Nut .....	5-4
619251	Fitting - Quick Release, female.....	5-1, 5-2
619252	Insert - Quick Release, male .....	5-1, 5-2
650701	Bearing .....	2-9, 2-10, 2-13
650702	Bearing .....	2-13, 2-16
650703	Bearing .....	2-3, 2-4, 2-9, 2-10
650707	Bearing .....	2-3, 2-4
650710	Bearing .....	2-12
650733	Shim.....	3-1
650876	Actuator - Magnet.....	2-3, 2-4
650939	Gasket .....	7-2
651850	Transformer - M35 Processor .....	6-2
651851	Filter - EMI.....	7-1
651853	Buzzer.....	6-2
651860	Switch - Run/Standby.....	6-1
651861	Replenishment Pump Assembly - M35 Processor .....	5-1, 5-2, 5-6
651862	Heater - M35 Processor.....	5-3
651863	Drive Motor Assembly - M35 Processor.....	3-1
651864	Blower Assembly - M35 Processor.....	4-1
651865	Cable Assembly.....	5-5
651868	Thermostat - Overtemperature.....	5-3
651869	Thermistor.....	5-3
651872	Potentiometer Assembly.....	1-4
651873	Quencharc .....	6-2
651875	Switch - Run/Standby.....	6-2
651881	Chain .....	6-2
651890	Support - Bin .....	7-1
651892	Heater Element Assembly - M35 Processor.....	4-1
651893	Main Harness Assembly - M35A Processor.....	6-2
655290	Relay.....	6-2
748126	Roller .....	2-1, 2-16
748147	Roller .....	2-1, 2-9, 2-10
748165	Fixer Rack Assembly.....	1-4, 2-12, 2-15
748955	Gear - Worm, left hand .....	3-1
748956	Gear - Worm, right hand.....	3-1
760476	Tubing - Bulk, 1/2-inch ID .....	7-2
760477	Tubing - Bulk, 3/4-inch ID .....	7-2
779002	Tank - Developer.....	5-1, 5-2
779003	Tank - Fixer .....	5-1, 5-2
779214	Water Inlet Tube and Tab Assembly .....	5-2, 7-1
779215	Bracket - Blower Mounting.....	4-1
779216	Support - Rack .....	5-7
852558	Setscrew .....	3-1

Part Number	Description	Figure Number
852611	Washer .....	1-3, 1-4, 2-3, 2-4, 2-6, 2-7, 2-9, 3-1, 4-1, 7-1, 2-10, 2-12, 2-13, 2-19, 2-20
852618	Nut .....	7-1
852620	Nut .....	1-3
852621	Nut .....	3-1
852623	Nut - Hook .....	1-4
852682	Screw .....	1-3, 1-4, 2-3, 2-4, 2-6, 2-7, 2-9, 4-1, 2-10, 2-12, 2-13, 2-14, 2-15, 2-16, 2-18, 2-20
852683	Screw .....	3-1, 5-6, 5-7, 6-2, 7-1
852799	Washer .....	1-3, 3-1, 4-1, 5-3, 5-5, 5-7, 6-2, 7-1
852805	Screw .....	1-3
852807	Screw .....	2-3, 2-4, 4-1, 7-1, 2-12, 2-13, 2-16
852831	Washer .....	6-1
852835	Screw .....	6-2
852868	Screw .....	6-2
852871	Screw .....	2-20
852888	Screw .....	4-1
852889	Setscrew .....	2-12
852941	Screw .....	2-3, 2-4, 2-7, 2-9, 2-10, 2-16
852946	Screw .....	5-5
853000	Pin .....	3-1
853080	Nut .....	1-3, 7-1
853086	Washer - Lock .....	1-3
853087	Washer - Lock .....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10, 2-12, 2-13, 2-19, 2-20
853096	Washer - Lock .....	1-3, 2-3, 2-4, 6-1, 6-2
853100	Washer - Lock .....	1-3, 1-4, 3-1, 4-1, 6-2, 7-1
853165	Screw .....	3-1, 6-2

Part Number	Description	Figure Number
911809	Sideplate - Drive.....	2-12, 2-14, 2-15
911845	Sideplate - Non-drive.....	2-12, 2-14, 2-15
914375	Clamp .....	7-1
914441	Circuit Breaker.....	1-4, 6-2
914565	Plate - Nut .....	6-1
914568	Tube.....	5-1
963312	Magnet.....	1-3
963315	Motor Assembly - M35 Processor.....	5-6
963316	Crank Assembly .....	5-6
963317	Screw.....	5-6
968802	800 Circuit Board and Cable Assembly.....	7-1

## SECTION 9

### Alphabetical Index

Part Number	Description	Figure Number
557422	100 Circuit Board.....	6-2
968802	800 Circuit Board and Cable Assembly.....	7-1
650876	Actuator - Magnet.....	2-3, 2-4
459681	Adapter .....	7-4
532033	Adapter .....	5-3
556104	Adapter .....	5-2
468535	Adapter - Exhaust.....	1-3
261929	Anchor .....	7-5
240060	Bearing .....	2-6, 2-7
333543	Bearing .....	2-19
490092	Bearing .....	2-6, 2-7
543993	Bearing .....	2-19
571241	Bearing .....	2-19
595426	Bearing .....	3-1
650701	Bearing .....	2-9, 2-10, 2-13
650702	Bearing .....	2-13, 2-16
650703	Bearing .....	2-3, 2-4, 2-9, 2-10
650707	Bearing .....	2-3, 2-4
650710	Bearing .....	2-12
472592	Bearing - Rocker .....	2-3, 2-4
532008	Bellows - Pump .....	5-6
261183	Bin - Receiving .....	1-4
187296	Block - Terminal .....	6-2
480206	Block - Terminal .....	6-2
485766	Block - Terminal .....	6-2
552361	Block - Terminal .....	6-2
594752	Block - Terminal .....	6-2
651864	Blower Assembly - M35 Processor.....	4-1
240225	Blower Assembly - M35A Processor .....	4-1
532007	Body - Valve .....	5-6
489726	Bolt - Hook.....	1-4
188623	Bolt - Stainless Steel.....	7-5
240104	Bracket.....	7-5
532390	Bracket.....	5-6
779215	Bracket - Blower Mounting.....	4-1
474596	Bracket - Guide Shoe.....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10, 2-16
287730	Bracket - Water Inlet .....	5-2
473220	Bushing.....	2-12
651853	Buzzer.....	6-2
651865	Cable Assembly.....	5-5
603538	Capacitor .....	5-5
562790	Cartridge - Filter .....	7-2
458240	Chain .....	2-12, 2-13
651881	Chain .....	6-2
480168	Chain - Drive .....	3-1
579424	Circuit Breaker.....	6-1

Part Number	Description	Figure Number
914441	Circuit Breaker .....	1-4, 6-2
475409	Circuit Breaker - M35 Processor .....	6-2
264464	Circuit Breaker - M35A Processor .....	6-2
246800	Clamp .....	5-1, 5-2
246801	Clamp .....	5-1, 5-2
246806	Clamp .....	4-1
246808	Clamp .....	5-1, 5-2
914375	Clamp .....	7-1
287677	Clip .....	7-1
287679	Clip - Rack End .....	7-1
459347	Collar .....	2-12
482273	Collar .....	2-19
597096	Collar - Split .....	2-13
594838	Cone .....	5-6
180281	Connector - Tee .....	5-1
472477	Control - Flow .....	5-2
287695	Cover - Dryer, bottom .....	2-18
287696	Cover - Dryer, top .....	2-18
287680	Cover - Evaporation .....	1-3
333975	Cover - Pump Access .....	1-4
485391	Cover - Receiving End .....	7-1
520397	Cover - Splash .....	5-6
264445	Cover Assembly .....	1-3
963316	Crank Assembly .....	5-6
479821	Cylinder - Graduate .....	7-2
261185	Deflector .....	1-4
333794	Detector Crossover Assembly .....	1-4, 2-3, 2-4
261275	Developer Rack Assembly .....	1-4, 2-12, 2-14
333795	Developer/Fixer Crossover Assembly .....	1-4, 2-6, 2-7
651863	Drive Motor Assembly - M35 Processor .....	3-1
246839	Drive Motor Assembly - M35A Processor .....	3-1
333796	Dryer Rack Assembly .....	1-4, 2-18
484692	ESD Jack Assembly .....	6-2
520390	Elbow .....	5-6
551400	Elbow .....	5-2
579383	Elbow .....	5-1, 5-2
240733	Elbow - Exhaust .....	7-2
264436	Electrical Box Assembly - M35 Processor .....	6-2
246840	Electrical Box Assembly - M35A Processor .....	6-2
287053	Exchanger - Heat .....	5-1, 5-2, 5-4
333994	Exit Panel Assembly - M35 Processor .....	1-4
333995	Exit Panel Assembly - M35A Processor .....	1-4
480978	Extension - Valve .....	5-6
520381	Fan .....	5-6
486689	Fan - Drive Motor .....	3-1
480366	Fastener .....	2-18
486742	Fastener - Bin .....	1-4
240726	Feed Shelf Assembly .....	1-3
651851	Filter - EMI .....	7-1
536827	Filter Assembly .....	5-1, 7-2
607750	Fitting .....	5-4
609969	Fitting .....	7-4



Part Number	Description	Figure Number
613277	Fitting - Large .....	5-4
619251	Fitting - Quick Release, female.....	5-1, 5-2
613276	Fitting - Small .....	5-4
748165	Fixer Rack Assembly.....	1-4, 2-12, 2-15
261276	Fixer/Wash Crossover Assembly .....	1-4, 2-9, 2-10
287731	Foam.....	7-1
287741	Foam.....	7-1
379381	Fuse - ¼ Amp, 250 volts.....	6-2
594535	Gasket .....	5-1, 5-2
650939	Gasket .....	7-2
458384	Gear.....	2-13
482275	Gear.....	2-19
532165	Gear.....	2-19
550774	Gear - Drive.....	2-12, 2-13
550781	Gear - Drive, crossover.....	2-3, 2-6, 2-9
748955	Gear - Worm, left hand .....	3-1
748956	Gear - Worm, right hand.....	3-1
287728	Guard - Chain.....	3-1
484690	Guard - Circuit Board .....	7-1
484668	Guard - Fan.....	5-6
489744	Guard - Motor.....	3-1
485293	Guard - Overtemperature .....	4-1
287684	Guard - Splash .....	7-2
418739	Guide - Cup.....	5-6
287682	Guide - Exit.....	7-1
240518	Guide - Film, right edge .....	1-3
287018	Guide Rod Assembly.....	2-14, 2-15
484688	Handle .....	1-3
485291	Handle - Support .....	1-3
607748	Header - Thermowell.....	5-3
651862	Heater - M35 Processor.....	5-3
485399	Heater - M35A Processor .....	5-3
651892	Heater Element Assembly - M35 Processor.....	4-1
484689	Heater Element Assembly - M35A Processor .....	4-1
264425	Hose - Exhaust.....	4-1
418700	Housing.....	5-5
472606	Housing - L.H. ....	5-5
472605	Housing - R.H.....	5-5
418701	Housing and Impeller Assembly .....	5-5
474362	Impeller.....	5-5
619252	Insert - Quick Release, male .....	5-1, 5-2
592380	J-Tube.....	7-2
246558	KODAK M35/M35A X-OMAT Lighttight Feed Tray.....	7-3
452044	Key.....	2-3, 2-6, 2-9
454354	Key.....	2-12, 2-13
261650	Kit - Flow Control Valve .....	5-2
264461	Kit - Tubing.....	5-1, 5-2
585721	Knob - Dryer Temperature Control .....	1-4
470363	Label .....	1-3
544154	Lamp.....	6-2
607793	Locator - Heater .....	5-3
598808	Lug - Ground .....	6-2

Part Number	Description	Figure Number
963312	Magnet.....	1-3
264453	Main Harness Assembly - M35 Processor .....	6-2
651893	Main Harness Assembly - M35A Processor.....	6-2
963315	Motor Assembly - M35 Processor.....	5-6
474881	Motor Assembly - M35A Processor .....	5-6
246875	Mount - Cable.....	6-2
240565	Nameplate - M35 Processor .....	1-4
240566	Nameplate - M35A Processor .....	1-4
185101	Nipple.....	5-2
480130	Nut .....	5-6
482283	Nut .....	2-20
562892	Nut .....	5-4
613278	Nut .....	5-4
852618	Nut .....	7-1
852620	Nut .....	1-3
852621	Nut .....	3-1
853080	Nut .....	1-3, 7-1
246001	Nut - Coupling .....	5-6
562891	Nut - Gland.....	5-4
852623	Nut - Hook .....	1-4
472755	Nut - Tie Rod, nylon.....	2-4, 2-7, 2-10
472756	Nut - Tie Rod, nylon.....	2-3, 2-6, 2-9
144097	Nut - Wing .....	5-5
182391	O-Ring .....	2-19
183851	O-Ring .....	2-19
463363	O-Ring .....	5-5
463950	O-Ring .....	2-13
473085	O-Ring .....	2-19
473118	O-Ring .....	7-2
520388	O-Ring .....	5-6
535639	O-Ring .....	5-6
539138	O-Ring .....	5-7
531263	Orifice - 0.109 ID.....	5-1
539152	Orifice - 0.209 ID.....	5-2
539151	Orifice - 0.250 ID.....	5-1
240736	Overlay - Dryer Temperature .....	1-4
594795	Overttemperature - Dryer Thermostat, safety.....	4-1
469403	Pad - Motor.....	5-5
333978	Panel - Front.....	1-3
333980	Panel - Front.....	1-3
264439	Panel - Side.....	1-3
175381	Pin.....	2-13
543884	Pin.....	2-19
543891	Pin.....	2-19
544081	Pin.....	2-6
853000	Pin.....	3-1
474186	Plate.....	3-1
261898	Plate - Floor.....	7-5
459548	Plate - Floor.....	1-4
473221	Plate - Keeper .....	2-12
472265	Plate - Locking.....	2-16
914565	Plate - Nut .....	6-1
287697	Plenum.....	2-18

Part Number	Description	Figure Number
651872	Potentiometer Assembly.....	1-4
240226	Power Cord Assembly.....	1-4, 7-3
287685	Protector .....	1-3
651873	Quencharc .....	6-2
264339	Receptacle - Safelight .....	6-1
419787	Receptacle - Wall .....	7-3
418703	Recirculation Pump Assembly - M35 Processor .....	5-1, 5-2, 5-5
240500	Recirculation Pump Assembly - M35A Processor .....	5-1, 5-2, 5-5
562334	Relay.....	6-2
562693	Relay.....	6-2
655290	Relay.....	6-2
161777	Relief - Strain.....	1-4
651861	Replenishment Pump Assembly - M35 Processor .....	5-1, 5-2, 5-6
240227	Replenishment Pump Assembly - M35A Processor.....	5-1, 5-2, 5-6
499753	Retainer .....	1-3, 1-4, 7-1
594837	Rod - Connecting, and bearing.....	5-6
287002	Rod - Tie.....	2-12, 2-13, 2-16
287035	Rod - Tie.....	2-3, 2-4
287036	Rod - Tie.....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10
287676	Rod - Tie.....	2-20
287689	Rod - Tie.....	2-20
240747	Roller .....	2-1, 2-6, 2-7
246917	Roller .....	2-1, 2-13
246918	Roller .....	2-1, 2-13
287004	Roller .....	2-1, 2-16
287005	Roller .....	2-1, 2-16
287020	Roller .....	2-1, 2-14, 2-15
287028	Roller .....	2-1, 2-12
287030	Roller .....	2-1, 2-12
287032	Roller .....	2-1, 2-12
287048	Roller .....	2-1, 2-9, 2-10
287059	Roller .....	2-1, 2-14, 2-15
287066	Roller .....	2-1, 2-14, 2-15
287067	Roller .....	2-1, 2-19
287078	Roller .....	2-1, 2-19
287081	Roller .....	2-1, 2-19
287083	Roller .....	2-1, 2-19
287656	Roller .....	2-1, 2-19
419788	Roller .....	2-1, 2-15
485406	Roller .....	2-1, 2-6, 2-7
748126	Roller .....	2-1, 2-16
748147	Roller .....	2-1, 2-9, 2-10
246883	Roller - Detector, drive .....	2-1, 2-3, 2-4
246882	Roller - Detector, driven .....	2-1, 2-3, 2-4
165626	Screw.....	6-1
166856	Screw.....	2-20
180126	Screw.....	7-1

Part Number	Description	Figure Number
183322	Screw.....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10, 2-16
183624	Screw.....	2-12, 2-13, 2-14, 2-15
187235	Screw.....	5-3
188807	Screw.....	3-1
190596	Screw.....	2-16
264429	Screw.....	4-1, 5-5
486265	Screw.....	6-2
486472	Screw.....	3-1
490096	Screw.....	2-16
540928	Screw.....	6-2
544132	Screw.....	2-19
544194	Screw.....	1-3, 2-3, 2-4, 6-2
575821	Screw.....	2-3, 2-4
852682	Screw.....	1-3, 1-4, 2-3, 2-4, 2-6, 2-7, 2-9, 4-1, 2-10, 2-12, 2-13, 2-14, 2-15, 2-16, 2-18, 2-20
852683	Screw.....	3-1, 5-6, 5-7, 6-2, 7-1
852805	Screw.....	1-3
852807	Screw.....	2-3, 2-4, 4-1, 7-1, 2-12, 2-13, 2-16
852835	Screw.....	6-2
852868	Screw.....	6-2
852871	Screw.....	2-20
852888	Screw.....	4-1
852941	Screw.....	2-3, 2-4, 2-7, 2-9, 2-10, 2-16
852946	Screw.....	5-5
853165	Screw.....	3-1, 6-2
963317	Screw.....	5-6
261180	Screw - Captive, and washer.....	1-3, 1-4, 7-1
532040	Screw - Cover, and washer.....	6-2
459229	Screw - Leveling.....	1-4
492260	Seal.....	5-4
532378	Seal.....	5-4
581241	Seal.....	5-4
554780	Seal - Tank.....	5-7, 7-1
287683	Seal - Tank Separator.....	7-1
261413	Seismic Kit.....	7-5
852558	Setscrew.....	3-1
852889	Setscrew.....	2-12
287003	Shaft.....	2-12, 2-16

Part Number	Description	Figure Number
287027	Shaft .....	2-12
287037	Shaft .....	2-3, 2-4, 2-9, 2-10
287047	Shaft .....	2-9, 2-10
287079	Shaft .....	2-19
287085	Shaft .....	2-19
287088	Shaft .....	2-19
287039	Shaft - Drive .....	2-3, 2-4
482222	Shaft - Drive .....	3-1
650733	Shim.....	3-1
287006	Shoe - Guide .....	2-16
287009	Shoe - Guide .....	2-16
287041	Shoe - Guide .....	2-3, 2-4
287045	Shoe - Guide .....	2-6, 2-7, 2-9, 2-10, 2-20
287049	Shoe - Guide .....	2-6, 2-7, 2-9, 2-10
333981	Side Panel Assembly .....	1-3, 1-4
477005	Sideplate .....	2-6, 2-7, 2-9, 2-10
246879	Sideplate - Detector Crossover .....	2-3, 2-4
286912	Sideplate - Drive.....	2-13, 2-14
911809	Sideplate - Drive.....	2-12, 2-14, 2-15
490123	Sideplate - Drive Side .....	2-18, 2-20
286910	Sideplate - Non-drive.....	2-13, 2-14
911845	Sideplate - Non-drive.....	2-12, 2-14, 2-15
264432	Sideplate - Non-drive Side .....	2-18, 2-20
477001	Sideplate - Turnaround, drive side.....	2-16
477000	Sideplate - Turnaround, non-drive .....	2-16
183643	Spacer .....	7-1
240065	Spacer .....	2-6
456215	Spacer .....	4-1
458174	Spacer .....	2-3, 2-9
458205	Spacer .....	2-12, 2-13
458236	Spacer .....	2-4
459355	Spacer .....	2-12
463004	Spacer .....	2-12, 2-16
473538	Spacer .....	2-13
474100	Spacer .....	2-13
477092	Spacer .....	2-12
477093	Spacer .....	2-13
482272	Spacer .....	2-19
482274	Spacer .....	2-19
482277	Spacer .....	2-19
488169	Spacer .....	3-1
534791	Spacer .....	2-12
287691	Spacer - Sideplate, exit.....	2-18
287692	Spacer - Sideplate, lower entrance.....	2-18
287694	Spacer - Sideplate, upper entrance .....	2-18
459344	Spring .....	2-6, 2-7
467843	Spring .....	2-12

Part Number	Description	Figure Number
474645	Spring .....	2-16
479820	Spring .....	2-13
562609	Spring .....	2-20
454285	Sprocket.....	2-12, 2-13
532363	Sprocket - 16 Tooth .....	3-1
466640	Sprocket - 17 Tooth .....	3-1
532247	Sprocket - 19 Tooth .....	3-1
489997	Standoff .....	2-3, 2-4
472261	Strainer Assembly .....	7-4
287089	Strip - Light Lock .....	1-4
459060	Stud .....	2-20
474777	Stud .....	2-14, 2-15
489727	Stud .....	2-19
474180	Support .....	2-3, 2-4
482262	Support .....	2-20
495710	Support .....	2-20
532071	Support .....	3-1
651890	Support - Bin .....	7-1
779216	Support - Rack .....	5-7
595425	Support Assembly .....	3-1
240514	Switch - Film Detector.....	6-1
240513	Switch - Interlock.....	6-1
651860	Switch - Run/Standby.....	6-1
651875	Switch - Run/Standby.....	6-2
779002	Tank - Developer.....	5-1, 5-2
779003	Tank - Fixer .....	5-1, 5-2
287000	Tank - Wash.....	5-1, 5-2
651869	Thermistor.....	5-3
651868	Thermostat - Overtemperature.....	5-3
240059	Tie - Blue.....	5-2, 2-12
240058	Tie - Red.....	5-1, 2-12
182915	Tie - Wire.....	6-1
651850	Transformer - M35 Processor .....	6-2
240229	Transformer - M35A Processor.....	6-2
287681	Tray - Drip .....	7-2
240002	Tube.....	5-1
240003	Tube.....	5-2
240004	Tube.....	5-1
240005	Tube.....	5-2
287733	Tube.....	5-2
287735	Tube.....	5-1
287736	Tube.....	5-1
287740	Tube.....	5-1
463029	Tube.....	5-1
471393	Tube.....	5-2
488190	Tube.....	5-1
489788	Tube.....	5-1, 5-2
527068	Tube.....	5-1
531270	Tube.....	5-1
914568	Tube.....	5-1
484674	Tube - Air.....	2-1, 2-20
240494	Tubing - Bulk .....	7-2
760476	Tubing - Bulk, 1/2-inch ID .....	7-2

Part Number	Description	Figure Number
760477	Tubing - Bulk, 3/4-inch ID .....	7-2
452990	Tubing - Bulk, 3/8-inch ID .....	7-2
609817	Valve - Poppet.....	5-6
261277	Wash Rack Assembly .....	1-4, 2-13, 2-14
165627	Washer .....	1-3, 2-3, 2-4, 6-2
459343	Washer .....	2-13, 2-16
482270	Washer .....	2-19
482271	Washer .....	2-19
493505	Washer .....	5-5
520394	Washer .....	5-6
532379	Washer .....	5-4
564694	Washer .....	1-4
575822	Washer .....	2-3, 2-4, 7-1
594534	Washer .....	5-1, 5-2
852611	Washer .....	1-3, 1-4, 2-3, 2-4, 2-6, 2-7, 2-9, 3-1, 4-1, 7-1, 2-10, 2-12, 2-13, 2-19, 2-20
852799	Washer .....	1-3, 3-1, 4-1, 5-3, 5-5, 5-7, 6-2, 7-1
852831	Washer .....	6-1
459943	Washer - Identification.....	2-12
459944	Washer - Identification.....	2-12
459945	Washer - Identification.....	2-13
459946	Washer - Identification.....	2-6
459947	Washer - Identification.....	2-9
168424	Washer - Lock .....	6-2
178145	Washer - Lock .....	2-20
187213	Washer - Lock .....	6-2
187283	Washer - Lock .....	2-3, 2-4, 6-2, 7-1
433708	Washer - Lock .....	4-1
535004	Washer - Lock .....	3-1, 4-1, 5-3, 5-5, 5-7, 6-2, 7-1
853086	Washer - Lock .....	1-3
853087	Washer - Lock .....	2-3, 2-4, 2-6, 2-7, 2-9, 2-10, 2-12, 2-13, 2-19, 2-20
853096	Washer - Lock .....	1-3, 2-3, 2-4, 6-1, 6-2
853100	Washer - Lock .....	1-3, 1-4, 3-1, 4-1, 6-2, 7-1

Part Number	Description	Figure Number
082248	Washer - Rubber .....	3-1
173824	Washer - Stainless Steel.....	7-5
463100	Washer - Thrust.....	2-12, 2-13, 2-16
261590	Water Inlet Assembly .....	5-2
779214	Water Inlet Tube and Tab Assembly .....	5-2, 7-1
488151	Weir - Beige.....	5-7
489736	Weir - Blue.....	5-7
489735	Weir - Red .....	5-7



**SECTION 10**  
**Publication Change Table**

<b>Rev. Date</b>	<b>ECO No.</b>	<b>PCN No.</b>	<b>Pub. No.</b>	<b>Affected Pages</b>	<b>Description</b>
September 1992	4014-318	1	981778	All	Supersedes Publications No. 635818 and 635039. The previous parts lists for the M35 and M35A Processors were combined into one manual, and the information updated.

3047pl\_a.txt

3047pl\_a.txt

*Kodak and X-Omat are trademarks.*

Printed in USA

EASTMAN KODAK COMPANY • ROCHESTER, N.Y. 14650

**Health Sciences Division**

